



IAU Headquarters

Delta Electronics, Inc.
Taoyuan Technology Center
No.18, Xinglong Rd., Taoyuan City,
Taoyuan County 33068, Taiwan
TEL: 886-3-362-6301 / FAX: 886-3-371-6301

Asia

Delta Electronics (Jiangsu) Ltd.
Wujiang Plant 3
1688 Jiangxing East Road,
Wujiang Economic Development Zone
Wujiang City, Jiang Su Province,
People's Republic of China (Post code: 215200)
TEL: 86-512-6340-3008 / FAX: 86-769-6340-7290

Delta Greentech (China) Co., Ltd.
238 Min-Xia Road, Pudong District,
Shanghai, P.R.C.
Post code : 201209
TEL: 86-21-58635678 / FAX: 86-21-58630003

Delta Electronics (Japan), Inc.
Tokyo Office
2-1-14 Minato-ku Shibadaimon,
Tokyo 105-0012, Japan
TEL: 81-3-5733-1111 / FAX: 81-3-5733-1211

Delta Electronics (Korea), Inc.
1511, Byucksan Digital Valley 6-cha, Gasan-dong,
Geumcheon-gu, Seoul, Korea, 153-704
TEL: 82-2-515-5303 / FAX: 82-2-515-5302

Delta Electronics Int'l (S) Pte Ltd
4 Kaki Bukit Ave 1, #05-05, Singapore 417939
TEL: 65-6747-5155 / FAX: 65-6744-9228

Delta Electronics (India) Pvt. Ltd.
Plot No 43 Sector 35, HSIIDC
Gurgaon, PIN 122001, Haryana, India
TEL : 91-124-4874900 / FAX : 91-124-4874945

Americas

Delta Products Corporation (USA)
Raleigh Office
P.O. Box 12173, 5101 Davis Drive,
Research Triangle Park, NC 27709, U.S.A.
TEL: 1-919-767-3800 / FAX: 1-919-767-8080

Delta Greentech (Brasil) S.A
Sao Paulo Office
Rua Itapeva, 26 - 3º andar Edifício Itapeva One-Bela Vista
01332-000- São Paulo-SP-Brazil
TEL: +55 11 3568-3855 / FAX: +55 11 3568-3865

Europe

Deltronics (The Netherlands) B.V.
Eindhoven Office
De Witbogt 15, 5652 AG Eindhoven, The Netherlands
TEL: 31-40-2592850 / FAX: 31-40-2592851

We reserve the right to change the information in this catalogue without prior notice.

5012604602
2012 03



CP2000 Series User Manual

Delta Intelligent Sensorless Vector Control Drive CP2000 Series User Manual

www.delta.com.tw/ia



PLEASE READ PRIOR TO INSTALLATION FOR SAFETY.



- ☑ AC input power must be disconnected before any wiring to the AC motor drive is made.
- ☑ Even if the power has been turned off, a charge may still remain in the DC-link capacitors with hazardous voltages before the POWER LED is OFF. Please do not touch the internal circuit and components.
- ☑ There are highly sensitive MOS components on the printed circuit boards. These components are especially sensitive to static electricity. Please do not touch these components or the circuit boards before taking anti-static measures. Never reassemble internal components or wiring.
- ☑ Ground the AC motor drive using the ground terminal. The grounding method must comply with the laws of the country where the AC motor drive is to be installed.
- ☑ DO NOT install the AC motor drive in a place subjected to high temperature, direct sunlight and inflammables.



- ☑ Never connect the AC motor drive output terminals U/T1, V/T2 and W/T3 directly to the AC mains circuit power supply.
- ☑ Only qualified persons are allowed to install, wire and maintain the AC motor drives.
- ☑ Even if the 3-phase AC motor is stop, a charge may still remain in the main circuit terminals of the AC motor drive with hazardous voltages.
- ☑ If the AC motor drive is stored in no charge condition for more than 3 months, the ambient temperature should not be higher than 30 °C. Storage longer than one year is not recommended, it could result in the degradation of the electrolytic capacitors.



The content of this manual may be revised without prior notice. Please consult our distributors or download the most updated version at <http://www.delta.com.tw/industrialautomation>

Table of Contents

CHAPTER 1 INTRODUCTION	1-1
CHAPTER 2 INSTALLATION	2-1
CHAPTER 3 UNPACKING	3-1
CHAPTER 4 WIRING	4-1
CHAPTER 5 MAIN CIRCUIT TERMINALS	5-1
CHAPTER 6 CONTROL TERMINALS	6-1
CHAPTER 7 OPTIONAL ACCESSORIES	7-1
CHAPTER 8 OPTION CARDS	8-1
CHAPTER 9 SPECIFICATION	9-1
CHAPTER 10 DIGITAL KEYPAD	10-1
CHAPTER 11 SUMMARY OF PARAMETERS	11-1
CHAPTER 12 DESCRIPTION OF PARAMETER SETTINGS	12-1
CHAPTER 13 APPLICATION OF CP2000	13-1
CHAPTER 14 WARNING CODES	14-1
CHAPTER 15 FAULT CODES AND DESCRIPTIONS	15-1
CHAPTER 16 CANOPEN OVERVIEW	16-1
CHAPTER 17 PLC FUNCTIONS	17-1
CHAPTER 18 INTRODUCTION TO BACNET	18-1
CHAPTER 19 PT100 THERMISTOR	19-1

Application

Control BD V1.01

Keypad V1.022

Publication History

Please include the Issue Edition and the Firmware Version, both shown below, when communicating with Technical Support regarding this publication.

Issue Edition: 02

Firmware Version: 1.01

Keypad Version: 1.022

Issue date : March 2012

Page1-3: Add RFI Jumper
Page41,Page4-2,Page4-3, Change AVI1 (AVI) to AVI1, AVI2(AUI) to aAVI2
Page41,Page4-2,Page4-3, Change AFM2 to 0~10V or 0/4~20mA
Page5-6: Add VFD450CP23A-21 and VFD900CP43A-21 must use 90°C wire
Page5-8: State that VFD1600CP43A-21's maximum and minimum wiring gauges are 4/0 AWG*2.
Page6-4: Change AVI1(AVI) to AVI1 and change AVI2(AUI) to AVI2.
Page7-13: Add Class, Motor Cable Length & Carrier Frequency Setting for the Filters
Page7-24: Specify that VFD150CP23A-21 uses fan # MKC-BFKM3
Page9-4: Add explanation on IEC/EN 60068-2-27 impact standard testing
Page11-11: Remove Pr02-57 and Pr02-58
Page11-16: Remove Pr05-00=7
Page 12-48: Remove Pr02-57 and Pr02-58
Page12-133, Page12-140, Page12-146: Change RY00 to R6AA


01 Introduction

Receiving and Inspection


After receiving the AC motor drive, please check for the following:

1. Please inspect the unit after unpacking to assure it was not damaged during shipment.
2. Make sure that the part number printed on the package corresponds with the part number indicated on the nameplate.
3. Make sure that the voltage for the wiring lie within the range as indicated on the nameplate.
4. Please install the AC motor drive according to this manual.
5. Before applying the power, please make sure that all the devices, including power, motor, control board and digital keypad, are connected correctly.
6. When wiring the AC motor drive, please make sure that the wiring of input terminals “R/L1, S/L2, T/L3” and output terminals”U/T1, V/T2, W/T3” are correct to prevent drive damage.
7. When power is applied, select the language and set the parameter groups via the digital keypad (KPC-CC01).
8. After applying the power, please trial run with the low speed and then increase the speed gradually to the desired speed.


Nameplate Information:



Model Name:



Serial Number:





RFI Jumper

RFI Jumper: The AC motor drive may emit the electrical noise. The RFI jumper is used to suppress the interference (Radio Frequency Interference) on the power line.

Frame A~C


Screw Torque: 8~10kg-cm(6.9-8.7 lb -in.)

Loosen the screws and remove the MOV-PLATE. Fasten the screws back to the original position after MOV-PLATE is removed.



Frame D~H

Remove the MOV-PLATE by hands, no screws need to be loosen



Main power isolated from earth:

If the AC motor drive is supplied from an isolated power (IT power), the RFI jumper must be cut off. Then the RFI capacities (filter capacitors) will be disconnected from ground to prevent circuit damage (according to IEC 61800-3) and reduce earth leakage current.




1. When power is applied to the AC motor drive, do not cut off the RFI jumper.
2. Make sure main power is switched off before cutting the RFI jumper.
3. The gap discharge may occur when the transient voltage is higher than 1,000V. Besides, electro-magnetic compatibility of the AC motor drives will be lower after cutting the RFI jumper.
4. Do NOT cut the RFI jumper when main power is connected to earth.
5. The RFI jumper cannot be cut when Hi-pot tests are performed. The mains power and motor must be separated if high voltage test is performed and the leakage currents are too high.
6. To prevent drive damage, the RFI jumper connected to ground shall be cut off if the AC motor drive is installed on an ungrounded power system or a high resistance-grounded (over 30 ohms) power system or a corner grounded TN system.

Dimensions:

Frame A, Corresponding models:

VFD007CP23A-21; VFD015CP23A-21, VFD022CP23A-21, VFD037CP23A-21, VFD055CP23A-21,
 VFD007CP43A-21, VFD015CP43A-21, VFD022CP43A-21, VFD037CP43A-21,
 VFD040CP43A-21, VFD055CP43A-21, VFD075CP43A-21, VFD007CP4EA-21, VFD015CP4EA-21,
 VFD022CP4EA-21, VFD037CP4EA-21; VFD040CP4EA-21, VFD055CP4EA-21, VFD075CP4EA-21








Frame	W	H	D	W1	H1	D1*	S1	$\phi 1$	$\phi 2$	$\phi 3$
A1	130.0 [5.12]	250.0 [9.84]	170.0 [6.69]	116.0 [4.57]	236.0 [9.29]	45.8 [1.80]	6.2 [0.24]	22.2 [0.87]	34.0 [1.34]	28.0 [1.10]

Unit : mm [inch]
 D1* : Flange mounting

Frame B

Corresponding models:

VFD075CP23A-21, VFD110CP23A-21, VFD150CP23A-21, VFD110CP43A-21,
 VFD150CP43A-21, VFD185CP43A-21, VFD110CP4EA-21, VFD150CP4EA-21,
 VFD185CP4EA-21



Unit : mm [inch]





Frame	W	H	D	W1	H1	D1*	S1	$\Phi 1$	$\Phi 2$	$\Phi 3$
B	190.0 [7.48]	320.0 [12.60]	190.0 [7.48]	173.0 [6.81]	303.0 [11.93]	77.9 [3.07]	8.5 [0.33]	22.2 [0.87]	34.0 [1.34]	43.8 [1.72]

D1* : Flange mounting

Frame C

Corresponding models:

VFD185CP23A-21, VFD220CP23A-21, VFD300CP23A-21, VFD220CP43A-21,
 VFD300CP43A-21, VFD370CP43A-21, VFD220CP4EA-21, VFD300CP4EA-21,
 VFD370CP4EA-21



Unit : mm [inch]

Frame	W	H	D	W1	H1	D1*	S1	$\phi 1$	$\phi 2$	$\phi 3$
C	250.0 [9.84]	400.0 [15.75]	210.0 [8.27]	231.0 [9.09]	381.0 [15.00]	92.9 [3.66]	8.5 [0.33]	22.2 [0.87]	34.0 [1.34]	50.0 [1.97]

D1* : Flange mounting

Frame D

Corresponding models:




Frame D1:

VFD370CP23A-00, VFD450CP23A-00, VFD450CP43A-00,
VFD550CP43A-00, VFD750CP43A-00, VFD900CP43A-00,


Frame D2:

VFD370CP23A-21, VFD450CP23A-21, VFD450CP43A-21,
VFD550CP43A-21, VFD750CP43A-21, VFD900CP43A-21

FRAME_D1



FRAME_D2



Unit : mm[inch]

Frame	W	H	D	W1	H1	H2	H3	D1*	D2	S1	S2	$\Phi 1$	$\Phi 2$	$\Phi 3$
D1	330.0 [12.99]	-	275.0 [10.83]	285.0 [11.22]	550.0 [21.65]	525.0 [20.67]	492.0 [19.37]	107.2 [4.22]	16.0 [0.63]	11.0 [0.43]	18.0 [0.71]	-	-	-
D2	330.0 [12.99]	688.3 [27.10]	275.0 [10.83]	285.0 [11.22]	550.0 [21.65]	525.0 [20.67]	492.0 [19.37]	107.2 [4.22]	16.0 [0.63]	11.0 [0.43]	18.0 [0.71]	76.2 [3.00]	34.0 [1.34]	22.0 [0.87]

D1* : Flange mounting

Frame E

Corresponding models:





Frame E1:

VFD550CP23A-00, VFD750CP23A-00, VFD900CP23A-00, VFD1100CP43A-00, VFD1320CP43A-00



Frame E2:

VFD550CP23A-21, VFD750CP23A-21, VFD900CP23A-21, VFD1100CP43A-21, VFD1320CP43A-21


FRAME_E1



FRAME_E2



Detail A (Mounting Hole)



Detail B (Mounting Hole)

Unit : mm [inch]

Frame	W	H	D	W1	H1	H2	H3	D1*	D2	S1, S2	S3	Φ1	Φ2	Φ3
E1	370.0 [14.57]	-	300.0 [11.81]	335.0 [13.19]	589 [23.19]	560.0 [22.05]	528.0 [20.80]	143.0 [5.63]	18.0 [0.71]	13.0 [0.51]	18.0 [0.71]	-	-	-
E2	370.0 [14.57]	715.8 [28.18]	300.0 [11.81]	335.0 [13.19]	589 [23.19]	560.0 [22.05]	528.0 [20.80]	143.0 [5.63]	18.0 [0.71]	13.0 [0.51]	18.0 [0.71]	22.0 [0.87]	34.0 [1.34]	92.0 [3.62]

D1* : Flange mounting




Frame F

Corresponding models:


Frame F1: VFD1600CP43A-00, VFD1850CP43A-00,

Frame F2: VFD1600CP43A-21, VFD1850CP43A-21

FRAME_F1







Detail A (Mounting Hole)



Detail B (Mounting Hole)

FRAME_F2



Unit : mm [inch]

Frame	W	H	D	W1	H1	H2	H3	D1*	D2	S1	S2	S3
F1	420.0 [16.54]	-	300.0 [11.81]	380.0 [14.96]	800.0 [31.50]	770.0 [30.32]	717.0 [28.23]	124.0 [4.88]	18.0 [0.71]	13.0 [0.51]	25.0 [0.98]	18.0 [0.71]
F2	420.0 [16.54]	940.0 [37.00]	300.0 [11.81]	380.0 [14.96]	800.0 [31.50]	770.0 [30.32]	717.0 [28.23]	124.0 [4.88]	18.0 [0.71]	13.0 [0.51]	25.0 [0.98]	18.0 [0.71]
Frame	$\Phi 1$	$\Phi 2$	$\Phi 3$									
F1	-	-	-									
F2	92.0 [3.62]	35.0 [1.38]	22.0 [0.87]									

D1* : Flange mounting


Frame G

Corresponding models:


Frame G1: VFD2200CP43A-00, VFD2800CP43A-00

Frame G2: VFD2200CP43A-21, VFD2800CP43A-21

FRAME_G1



FRAME_G2



Unit : mm [inch]

Frame	W	H	D	W1	H1	H2	H3	S1	S2	S3	Φ1	Φ2	Φ3
G1	500.0 [19.69]	-	397.0 [15.63]	440.0 [217.32]	1000.0 [39.37]	963.0 [37.91]	913.6 [35.97]	13.0 [0.51]	26.5 [1.04]	27.0 [1.06]	-	-	-
G2	500.0 [19.69]	1240.2 [48.83]	397.0 [15.63]	440.0 [217.32]	1000.0 [39.37]	963.0 [37.91]	913.6 [35.97]	13.0 [0.51]	26.5 [1.04]	27.0 [1.06]	22.0 [0.87]	34.0 [1.34]	117.5 [4.63]

Frame H


Corresponding models:

Frame H1: VFD3150CP43A-00, VFD3550CP43A-00, VFD4000CP43A-00




Frame H2: VFD3150CP43C-00, VFD3550CP43C-00, VFD4000CP43C-00,

Frame H3: VFD3150CP43C-21, VFD3550CP43C-21, VFD4000CP43C-21

FRAME_H1




FRAME_H2



See Detail A(Mounting Hole)

See Detail B(Mounting Hole)

FRAME_H3




Unit : mm [inch]

Frame	W	H	D	W1	W2	W3	W4	W5	W6	H1	H2	H3	H4
H1	700.0 [27.56]	1435.0 [56.5]	398.0 [15.67]	630.0 [24.8]	290.0 [11.42]	-	-	-	-	1403.0 [55.24]	1346.6 [53.02]	-	-
H2	700.0 [27.56]	1745.0 [68.70]	404.0 [15.90]	630.0 [24.8]	500.0 [19.69]	630.0 [24.80]	760.0 [29.92]	800.0 [31.5]	-	1729.0 [68.07]	1701.6 [66.99]	-	-
H3	700.0 [27.56]	1745.0 [68.70]	404.0 [15.91]	630.0 [24.80]	500.0 [19.69]	630.0 [24.80]	760.0 [29.92]	800.0 [31.5]	-	1729.0 [68.07]	1701.6 [66.99]	-	-
Frame	H5	D1	D2	D3	D4	D5	D6	S1	S2	S3	ϕ1	ϕ2	ϕ3
H1		45.0 [1.77]	-	-	-	-	-	13.0 [0.51]	26.5 [1.04]	25.0 [0.98]	-	-	-
H2		51.0 [2.00]	38.0 [1.50]	65.0 [2.56]	204.0 [8.03]	68.0 [2.68]	137.0 [5.40]	13.0 [0.51]	26.5 [1.04]	25.0 [0.98]	-	-	-
H3		51.0 [2.00]	38.0 [1.50]	65.0 [2.56]	204.0 [8.03]	68.0 [2.68]	137.0 [5.40]	13.0 [0.51]	26.5 [1.04]	25.0 [0.98]	22.0 [0.87]	34.0 [1.34]	117.5 [4.63]



Digital Keypad


KPC-CC01




02 Installation

The appearances shown in the following figures are for reference only.


Airflow direction:  (Blue arrow) inflow  (Red arrow) outflow



Multiple drives: side-by-side installation (Frame A,B,C, G, H)




Multiple drives: side-by-side installation (Frame D, E, F) Install a barrier between the drives is required.



Multiple drives side-by-side installation in rows (Frame A,B,C)

Ta: Frame A~G Ta*: Frame H

For installation in rows, it is recommended installing a barrier between the drives. Adjust the size/depth of the barrier till the temperature measured at the fan's inflow side is lower than the operation temperature. Operation temperature is the defined as the temperature measured 50mm away from the fan's inflow side. (As shown in the figure below)




Minimum mounting clearance

Frame	A (mm)	B (mm)	C (mm)	D (mm)
A~C	60	30	10	0
D~F	100	50	-	0
G	200	100	-	0
H	350	0	0	200 (100, Ta=40°C)

Frame A	VFD007CP23A-21; VFD007CP43A/4EA-21; VFD015CP23A-21; VFD015CP43A/4EA-21; VFD022CP23A-21; VFD022CP43A/4EA-21; VFD037CP23A-21; VFD037CP43A/4EA-21; VFD040C43A/4EA-21; VFD055CP23A-21; VFD055CP43A/4EA-21; VFD075CP43A/4EA-21
Frame B	VFD075CP23A-21; VFD110CP23A-21; VFD110CP43A/4EA -21; VFD150CP23A-21; VFD150CP43A/4EA -21; VFD185CP43A/4EA -21
Frame C	VFD185CP23A-21; VFD220CP23A-21; VFD220CP43A/4EA -21; VFD300CP23A-21; VFD300CP43A/4EA -21; VFD370CP43A/4EA -21
Frame D	VFD370CP23A-00/23A-21; VFD450CP23A-00/23A-21; VFD450CP43A-00/43A-21; VFD550CP43A-00/43A-21; VFD750CP43A-00/43A-21; VFD900CP43A-00/43A-21
Frame E	VFD550CP23A-00/23A-21; VFD750CP23A-00/23A-21; VFD900CP23A-00/23A-21; VFD1100CP43A-00/43A-21; VFD1320CP43A-00/43A-21;
Frame F	VFD1600CP43A-00/43A-21; VFD1850CP43A-00/43A-21
Frame G	VFD2200CP43A-00/43A-21; VFD2800CP43A-00/43A-21
Frame H	VFD3150CP43A-00/43C-00/43C-21; VFD3550CP43A-00/43C-00/43C-21; VFD4000CP43A-00/43C-00/43C-21

NOTE

1. It is the minimum distance required for frame A~D. If drives are installed closer than the minimum mounting clearance, the fan may not function properly.


 **NOTE**

- ※ The mounting clearances shown in the left figure are **NOT** for installing the drive in a confined space (such as cabinet or electric box). When installing in a confined space, besides the same minimum mounting clearances, it needs to have the ventilation equipment or air conditioner to keep the surrounding temperature lower than the operation temperature.
- ※ The following table shows heat dissipation and the required air volume when installing a single drive in a confined space. When installing multiple drives, the required air volume shall be multiplied by the number the drives.
- ※ Refer to the chart (Air flow rate for cooling) for ventilation equipment design and selection.
- ※ Refer to the chart (Power dissipation) for air conditioner design and selection.

Model No.	Air flow rate for cooling						Power Dissipation		
	Flow Rate (cfm)			Flow Rate (m ³ /hr)			Power Dissipation (watt)		
	External	Internal	Total	External	Internal	Total	Loss External (Heat sink)	Internal	Total
VFD007CP23A-21	-	-	-	-	-	-	40	31	71
VFD015CP23A-21	-	-	-	-	-	-	61	39	100
VFD022CP23A-21	14	-	14	24	-	24	81	45	126
VFD037CP23A-21	14	-	14	24	-	24	127	57	184
VFD055CP23A-21	10	-	10	17	-	17	158	93	251
VFD075CP23A-21	40	14	54	68	24	92	291	101	392
VFD110CP23A-21	66	14	80	112	24	136	403	162	565
VFD150CP23A-21	58	14	73	99	24	124	570	157	727
VFD185CP23A-21	166	12	178	282	20	302	622	218	840
VFD220CP23A-21	166	12	178	282	20	302	777	197	974
VFD300CP23A-21	146	12	158	248	20	268	878	222	1100
VFD370CP23A-00/23A-21	179	30	209	304	51	355	1271	311	1582
VFD450CP23A-00/23A-21	179	30	209	304	51	355	1550	335	1885
VFD550CP23A-00/23A-21	228	73	301	387	124	511	1762	489	2251
VFD750CP23A-00/23A-21	228	73	301	387	124	511	2020	574	2594
VFD900CP23A-00/23A-21	246	73	319	418	124	542	2442	584	3026
VFD007CP43A/4EA-21	-	-	-	-	-	-	35	32	67
VFD015CP43A/4EA-21	-	-	-	-	-	-	44	31	75
VFD022CP43A/4EA-21	-	-	-	-	-	-	58	43	101
VFD037CP43A/4EA-21	14	-	14	24	-	24	92	60	152
VFD040CP43A/4EA-21	10	-	10	17	-	17	124	81	205

Air flow rate for cooling							Power Dissipation		
VFD055CP43A/4EA-21	10	-	10	17	-	17	135	99	234
VFD075CP43A/4EA-21	10	-	10	17	-	17	165	98	263
VFD110CP43A/4EA-21	40	14	54	68	24	92	275	164	439
VFD150CP43A/4EA-21	66	14	80	112	24	136	370	194	564
VFD185CP43A/4EA-21	58	14	73	99	24	124	459	192	651
VFD220CP43A/4EA-21	99	21	120	168	36	204	455	358	813
VFD300CP43A/4EA-21	99	21	120	168	36	204	609	363	972
VFD370CP43A/4EA-21	126	21	147	214	36	250	845	405	1250
VFD450CP43A-00/43A-21	179	30	209	304	51	355	1056	459	1515
VFD550CP43A-00/43A-21	179	30	209	304	51	355	1163	669	1832
VFD750CP43A-00/43A-21	179	30	209	304	51	355	1639	657	2296
VFD900CP43A-00/43A-21	186	30	216	316	51	367	1787	955	2742
VFD1100CP43A-00/43A-21	257	73	330	437	124	561	2112	1084	3196
VFD1320CP43A-00/43A-21	223	73	296	379	124	503	2417	1157	3574
VFD1600CP43A-00/43A-21	224	112	336	381	190	571	3269	1235	4504
VFD1850CP43A-00/43A-21	289	112	401	491	190	681	3632	1351	4983
VFD2200CP43A-00/43A-21			454			771			6358
VFD2800CP43A-00/43A-21			454			771			7325
VFD3150CP43A-00/43C-00/43C-21			769			1307			8513
VFD3550CP43A-00/43C-00/43C-21			769			1307			9440
VFD4000CP43A-00/43C-00/43C-21			769			1307			10642
※ The required airflow shown in chart is for installing single drive in a confined space. ※ When installing the multiple drives, the required air volume should be the required air volume for single drive X the number of the drives.							※ The heat dissipation shown in the chart is for installing single drive in a confined space. ※ When installing the multiple drives, volume of heat dissipation should be the heat dissipated for single drive X the number of the drives. ※ Heat dissipation for each model is calculated by rated voltage, current and default carrier.		

03 Unpacking


The AC motor drive should be kept in the shipping carton or crate before installation. In order to retain the warranty coverage, the AC motor drive should be stored properly when it is not to be used for an extended period of time.

The AC motor drive is packed in the crate. Follows the following step for unpack:

Frame D


Crate 01 (VFDXXXCPXXA-00)

Loosen the 12 cover screws to open the crate.




Crate 02 (VFDXXXCPXXA-21)


Loosen all of the screws on the 4 iron plates at the four bottom corners of the crate. 4 screws on each of the iron plate (total 16 screws)




Remove the EPEs and manual.




Remove the crate cover, EPEs, rubber and manual.




Loosen the 8 screws that fastened on the pallet, remove the wooden plate.




Lift the drive by hooking the lifting hole. It is now ready for installation.



Loosen the 10 screws on the pallet, remove the wooden plate.




Lift the drive by hooking the lifting hole. It is now ready for installation.



Frame E


Crate 01 (VFDXXXXCPXXA-00)

Loosen the 4 screws on the iron plates. There are 4 iron plates and in total of 16 screws.




Crate 02 (VFDXXXXCPXXA-21)


Loosen the 4 screws on the iron plates. There are 4 iron plates and in total of 16 screws.




Remove the crate cover, EPEs and manual.




Remove the crate cover, EPEs, rubbers and manual.




Loosen the 8 screws on the pallet as shown in the following figure.




Loosen the 10 screws on the pallet and remove the wooden plate.



Lift the drive by hooking the lifting hole. It is now ready for installation.




Lift the drive by hooking the lifting hole. It is now ready for installation.



Frame F


Crate 01 (VFDXXXXCPXXA-00)

Remove the 6 clips on the side of the crate with a flat-head screwdriver. (As shown in figure below.)




Crate 02 (VFDXXXXCPXXA-21)


Remove the 6 clips on the side of the crate with a flat-head screwdriver. (As shown in figure below.)




Remove the crate cover, EPEs and manual.




Remove the crate cover, EPEs, rubbers and manual.




Loosen the 5 screws on the pallet as shown in the following figure.




Loosen the 9 screws on the pallet and remove the wooden plate.



Lift the drive by hooking the lifting hole. It is now ready for installation.




Lift the drive by hooking the lifting hole. It is now ready for installation.



Frame G


Crate 01 (VFDXXXXCPXXA-00)

Remove the 6 clips on the side of the crate with a flathead screwdriver. (As shown in figure below.)




Crate 02 (VFDXXXXCPXXA-21)


Remove the 6 clips on the side of the crate with a flathead screwdriver. (As shown in figure below.)




Remove the crate cover, EPEs and manual.




Remove the crate cover, EPEs, rubber and manual




Loosen the 5 screws as shown in following figure:




Loosen the 9 screws and remove the wooden plate.



Lift the drive by hooking the lifting hole. It is now ready for installation.




Lift the drive by hooking the lifting hole. It is now ready for installation.




Frame H


Crate 01 (VFDXXXXCPXXA-00)
Remove the 8 clips on the side of the crate with a flathead screwdriver. (As shown in figure below.)




Crate 02 (VFDXXXXCPXXC-00)
Remove the 8 clips on the side of the crate with a flathead screwdriver. (As shown in figure below.)




Remove the crate cover, EPEs and manual.




Remove the crate cover, EPEs, rubbers and manual.




Loosen the 6 screws on the top then remove 6 metal washers and 6 plastic washers as shown in figure below.




Loosen the 6 screws on the top then remove 6 metal washers and 6 plastic washers as shown in figure below.



Lift the drive by hooking the lifting hole. It is now ready for installation.




Loosen 6 of the M6 screws on the side and remove the 2 plates, as shown in below. The removed screws and plates can be used to secure the AC motor drive from the external.




Secure the drive from the external. (Skip to the next step if it is not necessary in your case.)

Loosen 8 of M8 screws on the both sides and place the 2 plates that were removed from the last step. Fix the plates to AC motor drive by fasten 8 of the M8 screws. (As shown in below)

Torque: 150~180kg-cm (130.20~156.24lb-in.)




Lift the drive by hooking the lifting hole. It is now ready for installation.




Frame H

Crate 03 (VFDXXXXCPXXC-21)


Use flathead screwdriver to remove the clips on the side of the crate, 8 clips in total.




Remove the crate cover, EPEs, rubber and manual.



Loosen the 6 screws on the cover, remove 6 metal washers and 6 plastic washers as shown in below:



Loosen 6 of the M6 screws on the side and removes the 2 plates, as shown in following figure. The removed screws and plates can be used to secure AC motor drive from the external.



Secure the drive from the internal.

Loosen 18 of the M6 screws and remove the top cover as shown in figure 2. Mount the cover (figure 1) back to the drive by fasten the M6 screws to the two sides of the drive, as shown in figure 2.
Torque: 35~45kg-cm (30.38~39.06lb-in.)




Figure 1
Top cover (Use M12 screws)

Secure the drive from the external.

Loosen 8 of the M8 screws on the both sides and place the 2 plates that were removed from the last step. Fix the plates to rive by fasten 8 of the M8 screws. (As shown in figure below).

Torque: 150~180kg-cm (130.20~156.24lb-in.)







Figure 2

Fasten 6 of the M6 screws that were removed from last step back to the AC motor drive. As shown in figure below:




Lift the drive by hooking the lifting hole. It is now ready for installation.




Frame H: Secure the drive

(VFDXXXXCPXXA-00) Screw: M12*6; Torque: 340-420kg-cm [295.1-364.6lb-in.]




VFDXXXXCPXXC-00




Secure the drive from internal.

Screw: M12*8

Torque: 340-420kg-cm [295.1-364.6lb-in.]




VFDXXXXCPXXC-21



Secure the drive from the external.






Screw: M12*8

Torque: 340-420kg-cm [295.1-364.6lb-in.]




The Lifting Hook


The arrows indicate the lifting holes, as in figure below: (Frame D~H).





Ensure the lifting hook properly goes through the lifting hole, as shown in the following diagram.
(Applicable for Frame D~G)




(Applicable to Frame H)



Ensure the angle between the lifting holes and the lifting device is within the specification, as shown in the following diagram.




(Applicable to Frame H)




Weight


VFDXXXCPXXA-00 **D** 37.6 kg(82.9 lbs.)




VFDXXXCPXXA-21 **D** 40 kg(88.2 lbs.)




VFDXXXCPXXA-00 **E** 63.6 kg(140.2 lbs.)




VFDXXXCPXXA-21 **E** 66 kg(145.5 lbs.)




VFDXXXCPXXA-00 **F** 85kg(187.2 lbs.)




VFDXXXCPXXA-21 **F** 88kg(193.8 lbs.)




VFDXXXCPXXA-00 **G** 130kg(286.5 lbs.)




VFDXXXCPXXA-21 **G** 138kg(303.9 lbs)




H1: VFD3150CP43A-00; VFD3550CP43A-00; VFD4000CP43A-00; 235kg (518.1lbs)



H2: VFD3150CP43C-00; VFD3550CP43C-00; VFD4000CP43C-00; 257kg (566.6lbs)




H3: VFD3150CP43C-21; VFD3550CP43C-21; VFD4000CP43C-21; 263kg (579.8lbs)



04 Wiring


Wiring Diagram for Frame A~C

3-phase power is provided



Wiring Diagram for Frame D

3-phase power is provided



Wiring diagram for frame E and above

3-phase power is provided





Figure 1

Input power terminals for frame G and H
Provides 3-phase power

Fuse or NFB (non-fuse breaker)



It provides 12-pulse power






Figure 2

SINK (NPN) /SOURCE (PNP) Mode


① Sink Mode with internal power (+24VDC)



② Source Mode with internal power (+24VDC)



③ Sink Mode with external power



④ Source Mode with external power





Figure 3

Frame E~H, remove terminal r and terminal s before using DC-Link. (As circled in dotted line, uninstall the gray section and properly store cable r and cable s. Cable r and cable s are not available in optional accessories, do not dispose them.)



05 Main Circuit Terminal

Figure 01: Main Circuit Terminal of Frame A ~ C

Wiring Diagram for Frame A~C

3-phase power is provided




Figure 02: Main Circuit Terminal of Frame D

Wiring Diagram for Frame D

3-phase power is provided







Figure 03: Main Circuit Terminal of Frame E and above

Wiring diagram for frame E and above

3-phase power is provided




Terminals	Descriptions
R/L1, S/L2, T/L3	AC line input terminals 3-phase
U/T1, V/T2, W/T3	AC drive output terminals for connecting 3-phase induction motor
+1, +2	Applicable to frame A~C Connections for DC reactor to improve the power factor. It needs to remove the jumper for installation.
+1/DC+, -/DC-	Connections for brake unit (VFDB series) (for 230V models: $\leq 22\text{kW}$, built-in brake unit) (for 460V models: $\leq 30\text{kW}$, built-in brake unit) Common DC Bus When connecting DC+ and DC-, please follow the required wired gauge in CP2000 user manual. But when connecting DC+ and DC- to brake modules, please follow VFDB Instruction Sheet. Download VFDB Instruction Sheet Brake Modules, English version
B1, B2	Connections for brake resistor (optional)
	Earth connection, please comply with local regulations.
	Main power terminals
	<ul style="list-style-type: none"> ☑ Do not connect 3-phase model to one-phase power. It is unnecessary to consider phase-sequence for these terminals R/L1, S/L2 and T/L3. ☑ It is recommended to add a magnetic contactor (MC) in the power input wiring to cut off power quickly and reduce malfunction when activating the protection function of the AC motor drive. Both ends of the MC should have an R-C surge absorber. ☑ Please make sure to fasten the screw of the main circuit terminals to prevent sparks which is made by the loose screws due to vibration. ☑ Please use voltage and current within the specification. ☑ When using a general GFCI (Ground Fault Circuit Interrupter), select a current sensor with sensitivity of 200mA or above and not less than 0.1-second operation time to avoid nuisance tripping. ☑ Please use the shield wire or tube for the power wiring and ground the two ends of the shield wire or tube. ☑ Do NOT run/stop AC motor drives by turning the power ON/OFF. Run/stop AC motor drives by RUN/STOP command via control terminals or keypad. If you still need to run/stop AC motor drives by turning power ON/OFF, it is recommended to do so only ONCE per hour.
	Output terminals for main circuit
	<ul style="list-style-type: none"> ☑ When it needs to install the filter at the output side of terminals U/T1, V/T2, W/T3 on the AC motor drive. Please use inductance filter. Do not use phase-compensation capacitors or L-C (Inductance-Capacitance) or

R-C (Resistance-Capacitance), unless approved by Delta.


- ☑ DO NOT connect phase-compensation capacitors or surge absorbers at the output terminals of AC motor drives.
- ☑ Use well-insulated motor, suitable for inverter operation.

Terminals for connecting DC reactor, external brake resistor, external brake resistor and DC circuit

- ☑ This is the terminals used to connect the DC reactor to improve the power factor. For the factory setting, it connects the short-circuit object. Please remove this short-circuit object before connecting to the DC reactor.




- ☑ Connect a brake resistor or brake unit in applications with frequent deceleration ramps, short deceleration time, too low brake torque or requiring increased brake torque.



- ☑ The external brake resistor should connect to the terminals (B1, B2) of AC motor drives.
- ☑ For those models without built-in brake resistor, please connect external brake unit and brake resistor (both of them are optional) to increase brake torque.
- ☑ When the terminals +1, +2 and - are not used, please leave the terminals open.
- ☑ DO NOT connect [+1, -], [+2, -], [+1/DC+, -/DC-] or brake resistor directly to prevent drive damage.

Specifications of the Main Circuit Terminals

Frame A




Main Circuit Terminals :

R/L1, S/L2, T/L3, U/T1, V/T2, W/T3, ⊕, B1, B2, +1, +2,-

Model	Max. Wire Gauge	Min. Wire Gauge	Torque(±10%)
VFD007CP23A-21	8 AWG (8.4mm ²)	14 AWG (2.1mm ²)	M4 20kg-cm (17.4 lb-in.) (1.96Nm)
VFD015CP23A-21		14 AWG (2.1mm ²)	
VFD022CP23A-21		14 AWG (2.1mm ²)	
VFD037CP23A-21		10 AWG (5.3mm ²)	
VFD055CP23A-21		10 AWG (5.3mm ²)	
VFD007CP43A-21		14 AWG (2.1mm ²)	
VFD015CP43A-21		14 AWG (2.1mm ²)	
VFD022CP43A-21		14 AWG (2.1mm ²)	
VFD037CP43A-21		14 AWG (2.1mm ²)	
VFD040CP43A-21		14 AWG (2.1mm ²)	
VFD055CP43A-21		12 AWG (3.3mm ²)	
VFD075CP43A-21		12 AWG (3.3mm ²)	
VFD007CP4EA-21		14 AWG (2.1mm ²)	
VFD015CP4EA-21		14 AWG (2.1mm ²)	
VFD022CP4EA-21		14 AWG (2.1mm ²)	
VFD037CP4EA-21		14 AWG (2.1mm ²)	
VFD040CP4EA-21		12 AWG (3.3mm ²)	
VFD055CP4EA-21	10 AWG (5.3mm ²)		
VFD075CP4EA-21	10 AWG (5.3mm ²)		

UL installations must use 600V, 75°C or 90°C wire. Use copper wire only.

Frame B



Main Circuit Terminals:

R/L1, S/L2, T/L3, U/T1, V/T2, W/T3, ⊕, B1, B2, +1, +2,-

Model	Max. Wire Gauge	Min. Wire Gauge	Torque(±10%)
VFD075CP23A-21	4 AWG (21.2mm ²)	8 AWG (8.4mm ²)	M5 35kg-cm (30.4 lb-in.) (3.434Nm)
VFD110CP23A-21		6 AWG (13.3mm ²)	
VFD150CP23A-21		4 AWG (21.2mm ²)	
VFD110CP43A-21		8 AWG (8.4mm ²)	
VFD150CP43A-21		8 AWG (8.4mm ²)	
VFD185CP43A-21		6 AWG (13.3mm ²)	
VFD110CP4EA-21		8 AWG (8.4mm ²)	
VFD150CP4EA-21		8 AWG (8.4mm ²)	
VFD185CP4EA-21		6 AWG (13.3mm ²)	


UL installations must use 600V, 75°C or 90°C wire. Use copper wire only.

NOTE

Terminal D+ [+2 & +1]: Torque: 45 kg-cm [39.0lb-in.] (4.415Nm) (±10%)

VFD150CP23A-21 must use 600V, 90°C wire when surrounding temperature exceeds 45°C.

Frame C



Main circuit terminals:
 R/L1, S/L2, T/L3, U/T1, V/T2, W/T3, ⊕, B1, B2, +1, +2,-


Model	Max. Wire Gauge	Min. Wire Gauge	Torque(±10%)
VFD185CP23A -21	1/0 AWG (53.5mm ²)	1 AWG (42.4mm ²)	M8 80kg-cm (69.4 lb-in.) (7.85Nm)
VFD220CP23A-21		1/0 AWG (53.5mm ²)	
VFD300CP23A-21		1/0 AWG (53.5mm ²)	
VFD220CP43A-21		4 AWG (21.2mm ²)	
VFD300CP43A-21		3 AWG (26.7mm ²)	
VFD370CP43A-21		2 AWG (33.6mm ²)	
VFD220CP4EA-21		4 AWG (21.2mm ²)	
VFD300CP4EA-21		3 AWG (26.7mm ²)	
VFD370CP4EA-21		2 AWG (33.6mm ²)	

UL installations must use 600V, 75°C or 90°C wire. Use copper wire only.

NOTE

Terminal D+ [+2 & +1]: Torque: 90 kg-cm [78.2lb-in.] (8.83Nm) (±10%)
 VFD300CP23A-21 must use 600V, 90°C wire when surrounding temperature exceeds 45°C

Frame D



Main Circuit Terminals:
 R/L1, S/L2, T/L3, U/T1, V/T2, W/T3, ⊕, +1/DC+, -/DC-

Model	Max. Wire Gauge	Min. Wire Gauge	Torque(±10%)
VFD370CP23A-00	300MCM (152 mm ²)	4/0 AWG (107mm ²)	M8 80kg-cm (173 lb-in.) (19.62Nm)
VFD450CP23A-00		300MCM(152mm ²)	
VFD450CP43A-00		1/0 AWG (53.5mm ²)	
VFD550CP43A-00		2/0 AWG (67.4mm ²)	
VFD750CP43A-00		3/0AWG (85mm ²)	
VFD900CP43A-00		300MCM(152mm ²)	
VFD370CP23A-21	4/0 AWG (107mm ²)	4/0AWG(107mm ²)	
VFD450CP23A-21		4/0 AWG (107mm ²)	
VFD450CP43A-21		1/0 AWG (53.5mm ²)	
VFD550CP43A-21		2/0 AWG (67.4mm ²)	
VFD750CP43A-21		3/0 AWG (85mm ²)	
VFD900CP43A-21		4/0 AWG (107mm ²)	

1. UL installations must use 600V, 75°C or 90°C wires. Use copper wire only. VFD450CP23A-21 and VFD900CP43A-21 must use 90°C wire
2. Figure 1 shows the terminal specification.
3. Figure 2 shows the specifications of insulated heat shrink tubing that comply with UL (600C, YDPU2).
4. Specification of grounding wire (⊕): It needs to be at least as the same size as the Min. Wire Gauge listed above.

Figure 1






Figure 2



Frame E



Main Circuit Terminals:

R/L1, S/L2, T/L3, U/T1, V/T2, W/T3, ⊕, +1/DC+, -/DC-

Model	Max. Wire Gauge	Min. Wire Gauge	Torque(±10%)
VFD550CP23A-00	300MCM*2 (152mm ² *2)	2/0AWG*2 (67.4mm ² *2)	M8 200kg-cm (173 lb-in.) (19.62Nm)
VFD750CP23A-00		3/0AWG*2 (85mm ² *2)	
VFD900CP23A-00		4/0 AWG*2 (107mm ² *2)	
VFD1100CP43A-00	2/0AWG*2 (67.4mm ² *2)		
VFD1320CP43A-00	2/0AWG*2 (67.4mm ² *2)		
VFD550CP23A-21	4/0 AWG*2 (107mm ² *2)	2/0AWG*2 (67.4mm ² *2)	
VFD750CP23A-21		3/0AWG*2 (85mm ² *2)	
VFD900CP23A-21		4/0 AWG*2 (107mm ² *2)	
VFD1100CP43A-21		2/0AWG*2 (67.4mm ² *2)	
VFD1320CP43A-21		2/0AWG*2 (67.4mm ² *2)	

1. UL installations must use 600V, 75°C or 90°C wires. Use copper wire only.
2. Figure 01 shows the specification for ring lug.
3. Specification of grounding wire ⊕: It needs to be at least as the same size as the Min. Wire Gauge listed above. Torque: M8 200kg-cm (173 lb-in.) (19.62Nm) (±10%), as shown in Figure 02.
4. Figure 03 shows the specifications of insulated heat shrink tubing that comply with UL (600C, YDPU2).

Figure01




Figure02






Figure03



Frame F



Main circuit terminals:
R/L1, S/L2, T/L3, U/T1, V/T2, W/T3, +1/DC+, -/DC-

Model	Max. Wire Gauge	Min. Wire Gauge	Torque(±10%)
VFD1600CP43A-00	300MCM*2 (152mm ² *2)	4/0 AWG*2(107mm ² *2)	M8 200kg-cm (173 lb-in.) (19.62Nm)
VFD1850CP43A-00		300MCM*2 (152mm ²)	
VFD1600CP43A-21	4/0 AWG*2 (107mm ² *2)	4/0AWG*2 (107mm ² *2)	
VFD1850CP43A-21		4/0AWG*2 (107mm ² *4)	

1. VFD1850CP43A-21 installations must use 90°C wire.
2. For other model, UL installations must use 600V, 75°C or 90°C wire. Use copper wire only.
3. Specification of grounding wire (⊕): It needs to be at least as the same size as the Min. Wire Gauge listed above.
Torque: M8 200kg-cm (173 lb-in.) (19.62Nm) (±10%)
- 4 Figure 1 shows the specification for ring lug.
- 5 Figure 2 shows the specifications of insulated heat shrink tubing that comply with UL (600C, YDPU2).

Figure01






Figure02



Frame G



Main Circuit Terminals:
R/L11, R/L12, S/L2, S/L22, T/L31, T/L32

Model	Max. Wire Gauge	Min. Wire Gauge	Torque(±10%)
VFD2200CP43A-00	300MCM*4 (152mm ² *4)	2/0AWG*4 (67.4mm ² *4)	M8 200kg-cm (173 lb-in.) (19.62Nm)
VFD2800CP43A-00		3/0AWG*4 (85mm ² *4)	
VFD2200CP43A-21	300MCM*4 (152mm ² *4)	2/0AWG*4 (67.4mm ² *4)	
VFD2800CP43A-21		3/0AWG*4 (85mm ² *4)	

Main Circuit Terminals:
U/T1, V/T2, W/T3, +1/DC+, -/DC-

Model	Max. Wire Gauge	Min. Wire Gauge	Torque(±10%)
VFD2200CP43A-00	500MCM*2 (253mm ² *2)	400M CM*2 (203mm ² *2)	M12 408kg-cm (354 lb-in.) (40Nm)
VFD2800CP43A-00		500MCM*2 (253mm ² *2)	
VFD2200CP43A-21	500MCM*2 (253mm ² *2)	400MCM*2 (203mm ² *2)	
VFD2800CP43A-21		500MCM*2 (253mm ² *2)	

1. UL installations must use 600V, 75°C or 90°C wire. Use copper wire only.
2. Figure 1 and Figure 2 show the specification for using ring lug.
3. Specification for grounding wire \oplus : It needs to be at least as the same size as the Min. Wire Gauge listed above. Torque: M8 200kg-cm (173 lb-in.) (19.62Nm) (±10%), as shown in Figure 1.
4. Figure 3 and Figure 4 shows the specification of insulated heat shrink tubing that comply with UL (600C, YDPU2).

Figure01
R/L11, R/L12, S/L2, S/L22, T/L31,
T/L32,




Figure02
U/T1, V/T2, W/T3, +1/DC+, -/DC-




Figure03






Figure04



Frame H



Main circuit terminals:

R/11,R12,S/21,S/22,T/31,T/32, U/T1, V/T2, W/T3, +1/DC+, -/DC-

Model	Max. Wire Gauge	Min. Wire Gauge	Torque(±10%)
VFD3150CP43A-00	300MCM*4 (152mm ² *4)	4/0 AWG*4(107mm ² *4)	M8 200kg-cm (173 lb-in.) (19.62Nm)
VFD3550CP43A-00		250MCM*4(127mm ² *4)	
VFD4000CP43A-00		300MCM*4(152mm ² *4)	
VFD4000CP43C-00		300MCM*4(152mm ² *4)	
VFD3150CP43C-00		4/0 AWG*4(107mm ² *4)	
VFD3550CP43C-00		250MCM*4(127mm ² *4)	
VFD3150CP43C-21		4/0 AWG*4(107mm ² *4)	
VFD3550CP43C-21		250MCM*4(127mm ² *4)	
VFD4000CP43C-21		300MCM*4(152mm ² *4)	

1. UL installations must use 600V, 75°C or 90°C wire. Use copper wire only.
2. Figure 1 shows the specification for using the ring lug.
3. Specification of grounding wire (⊖) : 300MCM*4 [152 mm²*4], Torque: M8 180kg-cm (156 lb-in.) (17.64Nm) (±10%), as shown in figure 1.
4. Figure 2 shows the specifications of heat shrink tubing that comply with UL (600C, YDPU2).

Figure01





Figure02



06 Control Circuit Terminal


For multi-function input and output terminal, remove the top cover before wiring

The figures shown in the diagram below are for reference only.

Remove the cover for wiring. Frame A~H


Frame A&B

Loosen the screws and press the tabs on both sides to remove the cover.
Screw torque: 12~15Kg-cm [10.4~13lb-in.]




Frame C&D

Screw torque: 12~15Kg-cm [10.4~13lb-in.]




Frame E

Screw torque: 12~15Kg-cm [10.4~13lb-in.] Slightly lift the cover then pull outward for removal.




Frame F


Screw torque: 12~15Kg-cm [10.4~13lb-in.]
Slightly lift the cover then pull outward for removal.


**Frame G**

Screw torque: 12~15Kg-cm [10.4~13lb-in.]
Slightly lift the cover then pull outward for removal.

**Frame H**

Screw torque: 14~16Kg-cm [12.15~13.89lb-in.] Slightly lift the cover then pull outward for removal.





Removable Terminal Block

Control Terminal Specifications

Wire Gauge: 26~16AWG (0.1281-1.318mm²),





Torque: (A) 5kg-cm [4.31lb-in.] (0.49Nm) (As shown in figure above)

(B) 8kg-cm [6.94lb-in.] (0.78Nm) (As shown in figure above)

Wiring precautions:

- Reserves 5mm and properly install the wire into the terminal; fasten the installation by a slotted screwdriver. If the wire is stripped, sort the wire before install into the terminal.
- Flathead screwdriver: blade width 3.5mm, tip thickness 0.6mm
- In the figure above, the factory setting for S1-SCM is short circuit. The factory setting for +24V-COM is short circuit and SINK mode (NPN); please refer to Chapter 4 Wiring for more detail.


Terminals	Terminal Function	Factory Setting (NPN mode)
+24V	Digital control signal common (Source)	+24V±5% 200mA
COM	Digital control signal common (Sink)	Common for multi-function input terminals
FWD	Forward-Stop command	FWD-DCM: ON→ forward running OFF→ deceleration to stop
REV	Reverse-Stop command	REV-DCM: ON→ reverse running OFF→ deceleration to stop
MI1 ~ MI8	Multi-function input 1~8	Refer to parameters 02-01~02-08 to program the multi-function inputs MI1~MI8. ON: the activation current is 6.5mA ≥ 11Vdc OFF: leakage current tolerance is 10μA ≤ 11Vdc
DCM	Digital frequency signal common	
RA1	Multi-function relay output 1 (N.O.) a	Resistive Load: 5A(N.O.)/3A(N.C.) 250VAC
RB1	Multi-function relay output 1 (N.C.) b	5A(N.O.)/3A(N.C.) 30VDC

RC1	Multi-function relay common (Relay)	Inductive Load (COS 0.4): 2.0A(N.O.)/1.2A(N.C.) 250VAC 2.0A(N.O.)/1.2A(N.C.) 30VDC It is used to output each monitor signal, such as drive is in operation, frequency attained or overload indication.
RA2	Multi-function relay output 2 (N.O.) a	
RC2	Multi-function relay common (Relay)	
RA3	Multi-function relay output 3 (N.O.) a	
RC3	Multi-function relay common (Relay)	
+10V	Potentiometer power supply	Analog frequency setting: +10Vdc 20mA
AVI1	Analog voltage input 	Impedance: 20kΩ Range: 0~ 20mA/0~10V =0~ Max. Output Frequency (Pr.01-00) AVI switch, factory setting is 0~10V
ACI	Analog current input 	Impedance: 250Ω Range: 0 ~ 20mA/0~10V=0~ Max. Output Frequency (Pr.01-00) ACI Switch, factory setting is 0~20mA
AVI2	Auxiliary analog voltage input 	Impedance: 20kΩ Range: 0 ~ +10VDC=0~ Max. Output Frequency (Pr.01-00)
AFM1		Impedance: 100Ω (current output) Output current: 20mA max Resolution: 0~10V corresponds to Max. operation frequency Range: 0~10V → 0~20mA AFM Switch: factory setting is 0~10V
AFM2		
ACM	Analog Signal Common	Common for analog terminals
S1	Factory setting: short-circuit	
SCM	Power removal safety function for emergency stop.	
SG+	Modbus RS-485	
SG-	PIN 1,2,7,8 : Reserved PIN 4: SG-	PIN 3, 6: GND PIN 5: SG+

* NOTE: Wire size of analog control signals: 18 AWG (0.75 mm²) with shielded wire

Analog input terminals (AVI 1, ACI, AVI 2, ACM)


- ☑ Analog input signals are easily affected by external noise. Use shielded wiring and keep it as short as possible (less than 20 meters (65.6168 feet)) with proper grounding. If the noise is inductive, connecting the shield to terminal ACM can bring improvement.
- ☑ This way of using contacts in a circuit should be able to process weak signals at the bifurcated contacts. Besides, don't use contacts to control the terminal ACM.
- ☑ If the analog input signals are affected by noise from the AC motor drive, please connect a capacitor and ferrite core as indicated in the following diagram.

**Digital inputs (FWD, REV, MI1~MI8, COM)**


- ☑ When using contacts or switches to control the digital inputs, please use high quality components to avoid contact bounce.

Remove the Terminal Block

1. Loosen the screws by screwdriver. (As shown in figure below)



2. Remove the control board by pulling it out for a distance 6~8 cm (as 1 in the figure) then lift the control board upward (as 2 in the figure).



07 Optional Components

The components listed in this chapter are optional (not built-in) and available upon request. Installing additional components to your drive would substantially improve its performance. Please select applicable components according to your need or contact the local distributor for suggestions.

List of Optional Components:

- [All Brake Resistors and Brake Units Used in AC Motor Drives](#)
- [Non-fuse Circuit Breaker](#)
- [Fuse \(Specification Chart\)](#)
- [AC Reactor \(Choke\)](#)
- [Zero Phase Reactor \(Choke\)](#)
- [DC Reactor \(Choke\)](#)
- [EMI filter](#)
- [Digital Keypad](#)
- [Panel Mounting Kit](#)
- [Conduit Box Kit](#)
- [Fan Kit](#)
- [Flange Mounting Kit](#)
- [IFD6530: USB/RS-485 Communication Interface](#)

All Brake Resistors and Brake Units Used in AC Motor Drives

230V

Applicable Moto		* ¹ 125%Braking Torque 10%ED					* ² Max. Braking Torque			
HP	kW	Braking Torque (kg-m)	Brake Unit * ⁴ VFDB	* ³ Braking Resistor series for each Brake Unit	Resistor value spec. for each AC motor Drive	Total Braking Current (A)	Min. Resistor Value (Ω)	Max. Total Braking Current (A)	Peak Power (kW)	
1	0.7	0.5	-	BR080W200*1	80W200Ω	1.9	63.3	6	2.3	
2	1.5	0.5	-	BR080W200*1	80W200Ω	1.9	63.3	6	2.3	
3	2.2	1.0	-	BR200W091*1	200W91Ω	4.2	47.5	8	3.0	
5	3.7	1.5	-	BR300W070*1	300W70Ω	5.4	38.0	10	3.8	
7.5	5.5	2.5	-	BR400W040*1	400W40Ω	9.5	19.0	20	7.6	
10	7.5	3.7	-	BR1K0W020*1	1000W20Ω	19	14.6	26	9.9	
15	11	5.1	-	BR1K0W020*1	1000W20Ω	19	14.6	26	9.9	
20	15	7.5	-	BR1K5W013*1	1500W13Ω	29	13.6	28	10.6	
25	18	10.2	-	BR1K0W4P3*2	2 series	2000W8.6Ω	44	8.3	46	17.5
30	22	12.2	-	BR1K0W4P3*2	2 series	2000W8.6Ω	44	8.3	46	17.5
40	30	14.9	-	BR1K5W3P3*2	2 series	3000W6.6Ω	58	5.8	66	25.1
50	37	20.3	2015*2	BR1K0W5P1*2	2 series	4000W5.1Ω	75	4.8	80	30.4
60	45	25.1	2022*2	BR1K2W3P9*2	2 series	4800W3.9Ω	97	3.2	120	45.6
75	55	30.5	2022*2	BR1K5W3P3*2	2 series	6000W3.3Ω	118	3.2	120	45.6
100	75	37.2	2022*3	BR1K2W3P9*2	2 series	7200W2.6Ω	145	2.1	180	68.4
125	90	50.8	2022*4	BR1K2W3P9*2	2 series	9600W2Ω	190	1.6	240	91.2

460V

Applicable Motors		* ¹ 125%Braking Torque 10%ED					* ² Max. Braking Torque			
HP	kW	Braking Torque (kg-m)	Brake Unit VFDB* ⁴	* ³ Braking Resistor series for each Brake Unit	Resistor value spec. for each AC motor Drive	Total Braking Current (A)	Min. Resistor Value (Ω)	Max. Total Braking Current (A)	Peak Power (kW)	
1	0.75	0.5	-	BR080W750*1	80W750Ω	1	190.0	4	3.0	
2	1.5	0.5	-	BR080W750*1	80W750Ω	1	190.0	4	3.0	
3	2.2	1.0	-	BR200W360*1	200W360Ω	2.1	126.7	6	4.6	
5	3.7	1.5	-	BR300W250*1	300W250Ω	3	108.6	7	5.3	
5	4.0	2.5	-	BR400W150*1	400W150Ω	5.1	84.4	9	6.8	
7.5	5.5	2.7	-	BR1K0W075*1	1000W75Ω	10.2	54.3	14	10.6	
10	7.5	3.7	-	BR1K0W075*1	1000W75Ω	10.2	54.3	14	10.6	
15	11	5.1	-	BR1K0W075*1	1000W75Ω	10.2	47.5	16	12.2	
20	15	7.5	-	BR1K5W043*1	1500W43Ω	17.6	42.2	18	13.7	
25	18	10.2	-	BR1K0W016*2	2 series	2000W32Ω	24	26.2	29	22.0
30	22	12.2	-	BR1K0W016*2	2 series	2000W32Ω	24	23.0	33	25.1
40	30	14.9	-	BR1K5W013*2	2 series	3000W26Ω	29	23.0	33	25.1
50	37	20.3	-	BR1K0W016*4	2 parallel, 2 series	4000W16Ω	47.5	14.1	54	41.0
60	45	25.1	4045*1	BR1K2W015*4	2 parallel, 2 series	4800W15Ω	50	12.7	60	45.6
75	55	30.5	4045*1	BR1K5W013*4	2 parallel, 2 series	6000W13Ω	59	12.7	60	45.6
100	75	37.2	4030*2	BR1K0W5P1*4	4 series	8000W 10.2Ω	76	9.5	80	60.8
125	90	50.8	4045*2	BR1K2W015*4	2 parallel, 2 series	9600W7.5Ω	100	6.3	120	91.2
150	110	60.9	4045*2	BR1K5W013*4	2 parallel, 2 series	12000W6.5Ω	117	6.3	120	91.2
175	132	74.5	4110*1	BR1K2W015*10	5 parallel, 2 series	12000W6Ω	126	6.0	126	95.8

460V		*1 125%Braking Torque 10%ED						*2 Max. Braking Torque		
HP	kW	Braking Torque (kg-m)	Brake Unit	*3Braking Resistor series for each Brake Unit		Resistor value spec. for each AC motor Drive	Total Braking Current (A)	Min. Resistor Value (Ω)	Max. Total Braking Current (A)	Peak Power (kW)
215	160	89.4	4160*1	BR1K5W012*12	6 parallel, 2 series	18000W4Ω	190	4.0	190	144.4
250	185	108.3	4160*1	BR1K5W012*12	6 parallel, 2 series	18000W4Ω	190	4.0	190	144.4
300	220	125.3	4185*1	BR1K5W012*14	7 parallel, 2 series	21000W3.4Ω	225	3.4	225	171.0
375	280	148.9	4110*2	BR1K2W015*10	5 parallel, 2 series	24000W3Ω	252	3.0	252	191.5
425	315	189.6	4160*2	BR1K5W012*12	6 parallel, 2 series	36000W2Ω	380	2.0	380	288.8
475	355	213.3	4160*2	BR1K5W012*12	6 parallel, 2 series	36000W2Ω	380	2.0	380	288.8
536	400	240.3	4185*2	BR1K5W012*14	7 parallel, 2 series	42000W1.7Ω	450	1.7	450	342.0

*1 Calculation for 125% braking torque: (kw)*125%*0.8; where 0.8 is motor efficiency.

Because there is a resistor limit of power consumption, the longest operation time for 10%ED is 10sec (on: 10sec/ off: 90sec).

*2 Please refer to the Brake Performance Curve for "Operation Duration & ED" vs. "Braking Current".


*3 For heat dissipation, a resistor of 400W or lower should be fixed to the frame and maintain the surface temperature below 50°C; a resistor of 1000W and above should maintain the surface temperature below 350°C.

*4 Please refer to VFDB series Braking Module Instruction for more detail on braking resistor.


NOTE

1. Definition for Brake Usage ED%

Explanation: The definition of the brake usage ED (%) is for assurance of enough time for the brake unit and brake resistor to dissipate away heat generated by braking. When the brake resistor heats up, the resistance would increase with temperature, and brake torque would decrease accordingly. Recommended cycle time is one minute.




For safety concern, install an overload relay (O.L) between the brake unit and the brake resistor together with the magnetic contactor (MC) prior to the drive to protect the drive from abnormal functions. The purpose of installing the thermal overload relay is to protect the brake resistor from damages due to frequent brakes, or caused by brake unit's continuous conduction resulted from unusual high input voltage. Under such circumstance, just turn off the power to prevent damaging the brake resistor.



Note1: When using the AC drive with DC reactor, please refer to wiring diagram in the AC drive user manual for the wiring of terminal +(P) of Braking unit.

Note2: Do NOT wire terminal -(N) to the neutral point of power system.

2. If damage to the drive or other equipment is due to the fact that the brake resistors and brake modules in use are not provided by Delta, the warranty will be void.
3. Please take into consideration the safety of the environment when installing the brake resistors. If the minimum resistance value is to be utilized, consult local dealers for the calculation of Watt figures.
4. When using more than 2 brake units, equivalent resistor value of parallel brake unit can't be less than the value in the column "Minimum Equivalent Resistor Value for Each AC Drive" (the right-most column in the table). Please read the wiring information in the user manual of brake unit thoroughly prior to operation
5. This chart is for normal usage; if the AC motor drive will be applied for frequent braking, it is recommended to enlarge 2~3 times of the Watts.
6. Thermal Relay:
 Thermal relay selection is based on its overload capability. A standard braking capacity for CP2000 is 10%ED (Tripping time=10s). The figure below is an example of 460V, 110kw AC motor drive. It requires the thermal relay to take 260% overload capacity in 10s (Host starting) and the braking current is 126A. In this case, user should select a rated 50A thermal relay. The property of each thermal relay may vary among different manufacturer, please read carefully specification provided by the manufacturer.



Non-fuse Circuit Breaker

To comply with UL standard: Per UL 508, paragraph 45.8.4, part a:

The rated current of the breaker shall be 2~4 times of the maximum rated input current of AC motor drive.

3-phase 230V		3-phase 460V	
Model	Recommended non-fuse breaker (A)	Model	Recommended non-fuse breaker (A)
VFD007CP23A-21	15	VFD007CP43A-21/4EA-21	5
VFD015CP23A-21	20	VFD015CP43A-21/4EA-21	10
VFD022CP23A-21	30	VFD022CP43A-21/4EA-21	15
VFD037CP23A-21	40	VFD040CP43A-21/4EA-21	20
VFD055CP23A-21	50	VFD037CP43A-21/4EA-21	20
VFD075CP23A-21	60	VFD055CP43A-21/4EA-21	30
VFD110CP23A-21	100	VFD075CP43A-21/4EA-21	40
VFD150CP23A-21	125	VFD110CP43A-21/4EA-21	50
VFD185CP23A-21	150	VFD150CP43A-21/4EA-21	60
VFD220CP23A-21	200	VFD185CP43A-21/4EA-21	75
VFD300CP23A-21	225	VFD220CP43A-21/4EA-21	100
VFD370CP23A-00/23A-21	250	VFD300CP43A-21/4EA-21	125
VFD450CP23A-00/23A-21	300	VFD370CP43A-21/4EA-21	150
VFD550CP23A-00/23A-21	400	VFD450CP43A-00/43A-21	175
VFD750CP23A-00/23A-21	450	VFD550CP43A-00/43A-21	250
VFD900CP23A-00/23A-21	600	VFD750CP43A-00/43A-21	300
		VFD900CP43A-00/43A-21	300
		VFD1100CP43A-00/43A-21	400
		VFD1320CP43A-00/43A-21	500
		VFD1600CP43A-00/43A-21	600
		VFD1850CP43A-00/43A-21	600
		VFD2200CP43A-00/43A-21	800
		VFD2800CP43A-00/43A-21	1000
		VFD3150CP43A-00/43C-00/43C-21	1200
		VFD3550CP43A-00/43C-00/43C-21	1350
		VFD4000CP43A-00/43C-00/43C-21	1500

Fuse (Specification Chart)

Fuses with specification smaller than the data in the following table are allowed.

Model 230V	Input Current I(A)		Line Fuse	
	Light duty	Normal duty	I (A)	Bussmann P/N
VFD007CP23A-21	6.4	3.9	15	JJN-15
VFD015CP23A-21	9.6	6.4	20	JJN-20
VFD022CP23A-21	15	12	30	JJN-30
VFD037CP23A-21	22	16	40	JJN-40
VFD055CP23A-21	25	20	50	JJN-50
VFD075CP23A-21	35	28	60	JJN-60
VFD110CP23A-21	50	36	100	JJN-100
VFD150CP23A-21	65	52	125	JJN-125
VFD185CP23A-21	83	72	150	JJN-150
VFD220CP23A-21	100	83	200	JJN-200
VFD300CP23A-21	116	99	225	JJN-225
VFD370CP23A-00/23A-21	146	124	250	JJN-250
VFD450CP23A-00/23A-21	180	143	300	JJN-300
VFD550CP23A-00/23A-21	215	171	400	JJN-400
VFD750CP23A-00/23A-21	276	206	450	JJN-450
VFD900CP23A-00/23A-21	322	245	600	JJN-600

Model 460V	Input current (A)		Line Fuse	
	Light duty	Normal duty	I (A)	Bussmann P/N
VFD007CP43A-21/4EA-21	4.3	3.5	10	JJS-10
VFD015CP43A-21/4EA-21	5.4	4.3	10	JJS-10
VFD022CP43A-21/4EA-21	7.4	5.9	15	JJS-15
VFD037CP43A-21/4EA-21	11	8.7	20	JJS-20
VFD040CP43A-21/4EA-21	16	14	30	JJS-20
VFD055CP43A-21/4EA-21	18	15.5	30	JJS-30
VFD075CP43A-21/4EA-21	20	17	40	JJS-40
VFD110CP43A-21/4EA-21	25	20	50	JJS-50
VFD150CP43A-21/4EA-21	33	26	60	JJS-60
VFD185CP43A-21/4EA-21	39	35	75	JJS-75
VFD220CP43A-21/4EA-21	47	40	100	JJS-100
VFD300CP43A-21/4EA-21	58	47	125	JJS-125
VFD370CP43A-21/4EA-21	76	63	150	JJS-150
VFD450CP43A-00/43A-21	91	74	175	JJS-175
VFD550CP43A-00/43A-21	110	101	250	JJS-250
VFD750CP43A-00/43A-21	144	114	300	JJS-300
VFD900CP43A-00/43A-21	180	157	300	JJS-300
VFD1100CP43A-00/43A-21	220	167	400	JJS-400
VFD1320CP43A-00/43A-21	246	207	500	JJS-500
VFD1600CP43A-00/43A-21	310	240	600	JJS-600
VFD1850CP43A-00/43A-21	343	300	600	JJS-600
VFD2200CP43A-00/43A-21	460	380	800	JJS-800
VFD2800CP43A-00/43A-21	530	400	1000	KTU-1000
VFD3150CP43A-00/43C-00/43C-21	616	494	1200	KTU-1200
VFD3550CP43A-00/43C-00/43C-21	683	555	1350	KTU-1350
VFD4000CP43A-00/43C-00/43C-21	770	625	1500	KTU-1500

AC Reactor (Choke)

230V, 50/60Hz, 3-phase

kW	HP	Nominal Amperes	Max. continuous amperes	Inductance (mh) 3~5% impedance	
				3% of impedance	5% of impedance
0.75	1	5.0	9.2	2.022	3.369
1.5	2	7.5	13.8	1.348	2.246
2.2	3	10.0	18.4	1.011	1.685
3.7	5	15.0	27.6	0.674	1.123
5.5	7.5	21.0	38.6	0.481	0.802
7.5	10	31.0	57.0	0.326	0.543
11	15	46.0	84.6	0.220	0.366
15	20	61.0	112.1	0.166	0.276
18.5	25	75.0	137.9	0.135	0.225
22	30	90.0	165.4	0.112	0.187
30	40	105.0	193.0	0.096	0.160
37	50	146.0	268.4	0.069	0.115
45	60	180.0	330.9	0.056	0.094
55	75	215.0	395.2	0.047	0.078
75	100	276.0	507.3c	0.037	0.061
90	125	322.0	591.9	0.031	0.052


460V, 50/60Hz, 3-phase

kW	HP	Nominal Amperes	Max. continuous amperes	Inductance (mh) 3~5% of impedance	
				3% of impedance	5% of impedance
0.75	1	3.0	5.5	7.351	12.252
1.5	2	3.7	6.8	5.960	9.934
2.2	3	5.0	9.2	4.411	7.351
3.7	5	7.5	13.8	2.940	4.901
4	5	10.5	19.3	2.100	3.501
5.5	7.5	12.0	22.1	1.838	3.063
7.5	10	14.0	25.7	1.575	2.625
11	15	22.5	41.4	0.980	1.634
15	20	30.0	55.1	0.735	1.225
18.5	25	36.0	66.2	0.613	1.021
22	30	45.0	82.7	0.490	0.817
30	40	56.0	102.9	0.394	0.656
37	50	72.0	132.4	0.306	0.510
45	60	91.0	167.3	0.242	0.404
55	75	110.0	202.2	0.200	0.334
75	100	144.0	264.7	0.153	0.255
90	125	180.0	330.9	0.123	0.204
110	150	220.0	404.4	0.100	0.167
132	175	246.0	452.2	0.090	0.149
160	215	310.0	569.8	0.071	0.119
185	250	343.0	630.5	0.064	0.107
220	300	460.0	845.6	0.048	0.080
280	375	530.0	974.2	0.042	0.069
315	425	616.0	1132.3	0.036	0.060
355	475	683.0	1255.5	0.032	0.054
400	536	770.0	1415.4	0.029	0.048

Zero Phase Reactor (Choke)

RF220X00A

UNIT: mm(inch)



Cable type (Note)	Recommended Wire Size (mm ²)			Qty.	Wiring Method
	AWG	mm ²	Nominal (mm ²)		
Single-core	≤10	≤5.3	≤5.5	1	Diagram A
	≤2	≤33.6	≤38	4	Diagram B
Three-core	≤12	≤3.3	≤3.5	1	Diagram A
	≤1	≤42.4	≤50	4	Diagram B

Diagram A

Please wind each wire around the core for 4 times. The reactor must be placed at the AC motor drive output side as close as possible.





Diagram B

Please put wires through 4 cores in series without winding.



NOTE

600V insulated cable wire

1. The table above gives approximate wire size for the zero phase reactors but the selection is ultimately governed by the type and the diameter of the cable, i.e. the cable diameter must small enough to go through the center of the zero phase reactor.
2. When wiring, do NOT go through the earth ground wire. It only needs to pass through the motor cable or the power cable.
3. When a long motor cable for output is used, a zero phase reactor may be necessary to reduce the radiated emission.

DC Reactor (Choke)

230V DC Reactor (Choke)

Input Voltage	kW	HP	DC Amps	Inductance (mh)
230Vac 50/60Hz 3-Phase	0.75	1	9.4	3.43
	1.5	2	18	1.83
	2.2	3	24	1.37
	3.7	5	30	1.1
	5.5	7.5	42	0.78
	7.5	10	53	0.61
	11	15	76	0.42
	15	20	106	0.31
	18.5	25	122	0.26
	22	30	145	0.22

460V DC Choke

Input Voltage	kW	HP	DC Amps	Inductance (mh)
460Vac 50/60Hz 3-Phase	0.75	1	6	9.77
	1.5	2	9	7.12
	2.2	3	13	4.83
	3.7	5	23	2.7
	5.5	7.5	25	2.47
	7.5	10	30	2.1
	11	15	38	1.62
	15	20	52	1.2
	18.5	25	60	1.05
	22	30	70	0.89
	30	40	93	0.67

EMI Filter

Model	Corresponding EMI filter	Web site for your reference (PDF files to download)
VFD007CP23A-21; VFD015CP23A-21; VFD022CP23A-21; VFD037CP23A-21;	KMF325A	http://www.dem-uk.com/roxburgh/Data/Product_Downloads/KMF325A.pdf KMF325A Three Phase Industrial Mains Filters - High Performance 25 Amps
VFD055C23A-21;	KMF336A	http://www.dem-uk.com/roxburgh/Data/Product_Downloads/KMF336A.pdf KMF370A Three Phase Industrial Mains Filters - High Performance 70 Amps
VFD075CP23A-21; VFD110CP23A-21; VFD150CP23A-21;	KMF3100A	http://www.dem-uk.com/roxburgh/Data/Product_Downloads/KMF3100A.pdf KMF3100A Three Phase Industrial Mains Filters - High Performance 100 Amps
VFD185CP23A-21; VFD220CP23A-21; VFD300CP23A-21;	KMF3150A+Qty2 TOR221	http://www.dem-uk.com/roxburgh/Data/Product_Downloads/KMF3150Aiss3.pdf KMF3150A Three Phase Industrial Mains Filters - High Performance 150 Amps MIF3150 Three Phase Industrial Multi Stage Drive Filters - Very High Performance 150 Amps
VFD370CP23A-00/ 23A-21; VFD450CP23A-00/ 23A-21;	MIF3180	http://www.dem-uk.com/roxburgh/Data/Product_Downloads/KMF3180Aiss4.pdf MIF3400 Three Phase Industrial Drive Filters - Very High Performance 340 Amps
VFD550CP23A-00/23A-21; VFD750CP23A-00/23A-21; VFD900CP23A-00/23A-21	MIF3400B	http://www.dem-uk.com/roxburgh/Data/Product_Downloads/MIF3400B.pdf KMF318 Three Phase Industrial Mains Filters - General Purpose 18 Amps
VFD007CP43A-21/4EA-21; VFD015CP43A-21/4EA-21; VFD022CP43A-21/4EA-21; VFD037CP43A-21/4EA-21;	KMF318A	http://www.dem-uk.com/roxburgh/Data/Product_Downloads/KMF318A.pdf KMF350 Three Phase Industrial Mains Filters - General Purpose 50 Amps
VFD040CP43A-21/4EA-21; VFD055CP43A-21/4EA-21; VFD075CP43A-21/4EA-21;	KMF325A	http://www.dem-uk.com/roxburgh/Data/Product_Downloads/KMF325A.pdf KMF370 Three Phase Industrial Mains Filters - General Purpose 70 Amps
VFD110CP43A-21/4EA-21; VFD150CP43A-21/4EA-21; VFD185CP43A-21/4EA-21;	KMF350A	http://www.dem-uk.com/roxburgh/Data/Product_Downloads/KMF350A.pdf MIF3150 Three Phase Industrial Multi Stage Drive Filters - Very High Performance 150 Amps
VFD220CP43A-21/4EA-21; VFD300CP43A-21/4EA-21; VFD370CP43A-21/4EA-21;	KMF370A	http://www.dem-uk.com/roxburgh/Data/Product_Downloads/KMF370A.pdf MIF3400B Three Phase Industrial Multi Stage Drive Filters - Very High Performance 400 Amps
VFD450CP43A-00/43A-21; VFD550CP43A-00/43A-21; VFD750CP43A-00/43A-21; VFD900CP43A-00/43A-21;	MIF3180	http://www.dem-uk.com/roxburgh/Data/Product_Downloads/KMF3180Aiss4.pdf
VFD1100CP43A-00/43A-21; VFD1320CP43A-00/43A-21	MIF3400B	http://www.dem-uk.com/roxburgh/Data/Product_Downloads/MIF3400B.pdf
VFD1600CP43A-00/43A-21; VFD1850CP43A-00/43A-21;	MIF3400B	http://www.dem-uk.com/roxburgh/Data/Product_Downloads/MIF3400B.pdf
VFD2200CP43A-00/43A-21; VFD2800CP43A-00/43A-21;	MIF3800+Qty3 TOR254	http://www.dem-uk.com/roxburgh/Data/Product_Downloads/MIF3800curves.pdf
VFD3150CP43A-00/43C-00/43c-21; VFD3550CP43A-00/43C-00/43c-21; VFD4000CP43A-00/43C-00/43c-21;	MIF3800+Qty2 TOR254	http://www.dem-uk.com/roxburgh/Data/Product_Downloads/MIF3800curves.pdf

EMI Filter Installation

Preface

All electrical equipment, including AC motor drives, generates high-frequency/low-frequency noise and interferes with peripheral equipment by radiation or conduction when in normal operation. By using an EMI filter with correct installation, much interference can be eliminated. It is recommended to use DELTA EMI filter to have the best interference elimination performance.

We assure that it can comply with following rules when AC motor drive and EMI filter are installed and wired according to user manual:

1. EN61000-6-4
2. EN61800-3: 1996
3. EN55011 (1991) Class A Group 1

General precaution

To ensure an EMI Filter can maximize its performance on eliminating noise generated by an AC motor drive, it is not only necessary to follow instruction on installation and wiring in a user manual, but the following points need to be kept in mind. .

- EMI filter and AC motor drive should be installed on the same metal plate
- Install AC motor drive on the footprint of the EMI filter or install EMI filter as close as possible to the AC motor drive.
- Wiring should be as short as possible.
- Metal plate should be grounded.
- The cover of the AC motor drive or grounding should be fixed on the metal plate and their contact area should be as large as possible.

Choose suitable motor & precautions

Improper installation and choice of motor cable will affect the performance of EMI filter. Be sure to follow exactly precautions listed below when selecting motor cable.

- Use a cable with shielding (double shielding is the best).
- The shielding on both ends of the motor's cable should be grounded with the minimum length and maximum contact area.
- Remove any paint on the metal saddle for better ground contact with the metal plate and shielding (See diagram 1).
- The shielding of motor's cable should be connected properly to a metal plate. The shielding on both end of the motor's cable should be fixed on a metal plate by a metal saddle. (See diagram 2)

Remove any paint on metal saddle for good ground contact with the plate and shielding.




Diagram 1




Diagram 2

The Length of a motor's cable

When motor is driven by an AC motor drive of PWM type, the motor terminals will easily experience surge voltages due to components conversion of AC motor drive and cable capacitance. When the motor cable is very long (especially for the 460V series), surge voltages may reduce insulation quality. To prevent this situation to happen, please follow the rules below:

- Use a motor with enhanced insulation.
- Connect an output reactor (optional) to the output terminals of the AC motor drive
- The length of the cable between the AC motor drive and the motor should be as short as possible (10m (32.81 feet) to 20 m (65.62 feet) or less)
- For models 7.5hp/5.5kW and above:

Insulation level of motor	1000V	1300V	1600V
460VAC input voltage	66 ft (20m)	328 ft (100m)	1312 ft (400m)
230VAC input voltage	1312 ft (400m)	1312 ft (400m)	1312 ft (400m)

- For models 5hp/3.7kW and less:

Insulation level of motor	1000V	1300V	1600V
460VAC input voltage	66 ft (20m)	165 ft (50m)	165 ft (50m)
230VAC input voltage	328 ft (100m)	328 ft (100m)	328 ft (100m)

If motor is driven by an AC motor drive of PWM type, the motor terminals will easily experience surge voltages due to components conversion of AC motor drive and cable capacitance. Especially when the motor's cable is very long, surge voltages may reduce insulation quality. To prevent this situation to happen, please consider the following measures:

If the wiring is too long, the amount of stray capacitance between the electrical wires will increase and probably cause leakage of current.

- ☑ Then the display of the current will not be accurate. If so, the AC motor drive will activate the over current protection. The worst case caused by leakage of current will be the break down of the AC motor drive.
- ☑ If an AC motor drive is connected to more than one motor, the length of the wiring should be the total length of wiring from the AC motor drive to each motor.
- ☑ When a thermal O/L relay protected by motor is used between AC motor drive and motor, it may malfunction (especially for 460V series), even if the length of motor cable is only 165 ft (50m) or less. To prevent it, please use AC reactor and/or lower the carrier frequency (Pr. 00-17 PWM carrier frequency).

NOTE

- When a thermal O/L relay protected by motor is used between AC motor drive and motor, it may malfunction (especially for 460V series), even if the length of motor cable is only 165 ft (50m) or less. To prevent it, please use AC reactor and/or lower the carrier frequency (Pr. 00-17 PWM carrier frequency).
- Never connect phase lead capacitors or surge absorbers to the output terminals of the AC motor drive.

Class, Motor Cable Length & Carrier Frequency Setting for the Filters

	EMC Standard (IEC 61800-3)	Motor Cable length	Carrier frequency
Built-in filter	class C3	non-shielded cable 50m	default (8KHz)
external DEM filter	class C2	shielded cable 50m	15KHz

Digital Keypad

KPC-CE01 digital keypad



A: LED Display

Display frequency, current, voltage and error etc.

B: Status Indicator


F: Frequency Command
H: Output Frequency
U: User Defined Units
ERR: CAN Error Indicator
RUN: CAN Run Indicator

C: Function

(Refer to the chart follows for detail description)

Key	Description
ESC	ESC Key When ESC key is pressed, it will return to the previous menu. It is also functioned as a return key in the sub-menu.
MENU	Menu Key It can return to the main menu after pressing MENU key. Menu content: 1. Parameter Detail 2. Copy Parameter 3. Keypad locked 4. PLC Function
ENTER	ENTER Key Press ENTER and go to the next level. If it is the last level then press ENTER to execute the command.
HAND	HAND ON Key 1. This key is executed by the parameter settings of the source of Hand frequency and hand operation. The factory settings of both source of Hand frequency and hand operation are the digital keypad. 2. If pressed at stop status, it will switch to Hand setting of frequency source and operation source. If HAND ON key is pressed during operation, it will stop the AC motor drive first then switch to Hand setting. 3. Hand mode display: H/A LED is ON.
AUTO	Auto Operation Key 1. This key is executed by the parameter settings of the source of AUTO frequency and AUTO operation. The factory setting is the external terminal (source of operation is 4-20mA). 2. If auto is pressed in steady status, it will switch to the auto-setting. However if auto key is pressed during operation, it will stop AC motor drive first then switch to auto-setting. 3. Switch is complete: H/A LED is OFF
FWD/REV	Operation Direction Key 1. This key is only control the operation direction NOT for activate the drive. FWD: forward, REV: reverse. 2. Refer to the LED descriptions for more details.
RUN	Start Key 1. It is only valid when the source of operation command is from the keypad. 2. It can operate the AC motor drive by the function setting and the RUN LED will be ON. 3. It can be pressed again and again during stop. When enabling "HAND" mode, it is only valid when the source of operation command is from the keypad.
STOP	Stop Key. (When Stop key is pressed, all operation will stop in all condition.) This key has the highest priority in all condition. 1. When a STOP command is given, the AC motor drive's operation will stop under any condition. 2. The RESET key can be used to reset the drive when faults occur. If the RESET key is not responding, check MENU → Fault Records search for the most recent fault.





Dimensions: mm [inch]




Panel Mounting Kit (MKC-KPPK)

For MKC-KPPK model, user can choose wall mounting or embedded mounting, protection level is IP56.

Applicable to the digital keypads (KPC-CC01 & KPC-CE01).

Wall Mounting	Embedded Mounting																
accessories*1 	accessories*2 																
Screw *4 ~M4*p 0.7 *L8mm Torque: 10-12kg-cm (8.7-10.4lb-in.)	Screw *4 ~M4*p 0.7 *L8mm Torque: 10-12kg-cm (8.7-10.4lb-in.)																
Panel cutout dimension Unit: mm [inch]	Panel cutout dimension Unit: mm [inch]																
																	
	<table border="1"> <thead> <tr> <th colspan="4">Normal cutout dimension</th> </tr> <tr> <th>Panel thickness</th> <th>1.2mm</th> <th>1.6mm</th> <th>2.0mm</th> </tr> </thead> <tbody> <tr> <td>A</td> <td colspan="3">66.4 [2.614]</td> </tr> <tr> <td>B</td> <td>110.2 [4.339]</td> <td>111.3 [4.382]</td> <td>112.5 [4.429]</td> </tr> </tbody> </table> <p style="text-align: right;">*Deviation: ±0.15mm /±0.0059inch</p>	Normal cutout dimension				Panel thickness	1.2mm	1.6mm	2.0mm	A	66.4 [2.614]			B	110.2 [4.339]	111.3 [4.382]	112.5 [4.429]
Normal cutout dimension																	
Panel thickness	1.2mm	1.6mm	2.0mm														
A	66.4 [2.614]																
B	110.2 [4.339]	111.3 [4.382]	112.5 [4.429]														
	<table border="1"> <thead> <tr> <th colspan="4">Cutout dimension (Waterproof level: IP56)</th> </tr> <tr> <th>Panel thickness</th> <th>1.2mm</th> <th>1.6mm</th> <th>2.0mm</th> </tr> </thead> <tbody> <tr> <td>A</td> <td colspan="3">66.4 [2.614]</td> </tr> <tr> <td>B</td> <td colspan="3">110.8 [4.362]</td> </tr> </tbody> </table> <p style="text-align: right;">*Deviation: ±0.15mm /±0.0059inch</p>	Cutout dimension (Waterproof level: IP56)				Panel thickness	1.2mm	1.6mm	2.0mm	A	66.4 [2.614]			B	110.8 [4.362]		
Cutout dimension (Waterproof level: IP56)																	
Panel thickness	1.2mm	1.6mm	2.0mm														
A	66.4 [2.614]																
B	110.8 [4.362]																



Conduit Box Kit


Outer appearance of conduit box

Frame D

VFD370CP23A-00;VFD450CP23A-00;VFD450CP43A-00;VFD550CP43A-00;
VFD750CP43A-00;VFD900CP43A-00;VFD370CP23A-21;VFD450CP23A-21;
VFD450CP43A-21;VFD550CP43A-21;VFD750CP43A-21;VFD900CP43A-21

Model name: 『MKC-DN1CB』

ITEM	Description	Qty.
1	Screw M5*0.8*10L	4
2	Rubber 28	2
3	Rubber 44	2
4	Rubber 88	2
5	Conduit box cover	1
6	Conduit box base	1




Frame E

VFD550CP23A-00;VFD750CP23A-00;VFD900CP23A-00;
VFD1100CP43A-00;VFD1320CP43A-00;VFD550CP23A-21;
VFD750CP23A-21;VFD900CP23A-21;VFD1100CP43A-21;
VFD1320CP43A-21;

Model name: 『MKC-EN1CB』

ITEM	Description	Qty.
1	Screw M5*0.8*10L	6
2	Bushing Rubber 28	2
3	Bushing Rubber 44	4
4	Bushing Rubber 100	2
5	Conduit box cover	1
6	Conduit box base	1




Frame F

VFD1600CP43A-00;VFD1850CP43A-00;

VFD1600CP43A-21;VFD1850CP43A-21

Model name: 『MKC-FN1CB』

ITEM	Description	Qty.
1	Screw M5*0.8*10L	8
2	Bushing Rubber 28	2
3	Bushing Rubber 44	4
4	Bushing Rubber 100	2
5	Conduit box cover	1
6	Conduit box base	1




Frame G

VFD2200CP43A-00;VFD2800CP43A-00

VFD2200CP43A-21;VFD2800CP43A-21

Model name: 『MKC-GN1CB』


ITEM	Description	Qty.
1	Screw M5*0.8*10L	12
2	Bushing Rubber 28	2
3	Bushing Rubber 44	2
4	Bushing Rubber 130	3
5	Conduit box base	1
6	Conduit box cover	1




■ Installation of conduit box

Frame D


1. Loosen the cover screws and press the tabs on each side of the cover to remove the cover, as shown in the following figure. Screw torque: 10~12kg-cm (8.66~10.39Ib-in)




2. Remove the 5 screws shown in the following figure. Screw torque: 24~26kg-cm (20.8~22.6Ib-in).



3. Install the conduit box by fasten the 5 screws shown in the following figure. Screw torque: 24~26kg-cm (20.8~22.6Ib-in).




4. Fasten the 2 screws shown in the following figure. Screw torque: 10~12kg-cm (8.66~10.39Ib-in).




Frame E


1. Loosen the 4 cover screws and lift the cover; Screw torque: 12~ 15 kg-cm (10.4~13Ib-in).



2. Fasten the 6 screws shown in the following figure and place the cover back to the original position. Screw torque: 25~30kg-cm (20.8~30Ib-in)




3. Fasten the 4 screws shown in the following figure. Screw torque: 12~15kg-cm (10.4~13Ib-in)




Frame F


1. Loosen the cover screws and press the tabs on each side of the cover to remove the cover, as shown in the following figure. Screw torque: 14~16kg-cm (12.2~13.9lb-in).



2. Install the conduit box by fastens the 4 screws, as shown in the following figure. Screw torque: 24~26kg-cm (20.8~22.6lb-in).




3. Install the conduit box by fasten all the screws shown in the following figure.




Frame G


1. On the conduit box, loosen 7 of the cover screws and remove the cover. On the drive, loosen 4 of the cover screws and press the tabs on each side of the cover to remove the cover, as shown in the following figure. Screw torque: 12~15kg-cm (10.4~13lb-in).




2. Remove the top cover and loosen the screws. Screw torque: 12~15kg-cm (10.4~13lb-in).




3. Install the conduit box by fastening all the screws shown in the following figure. Screw torque: 25~30kg-cm (20.8~30lb-in); Screw torque: 12~15kg-cm (10.4~13lb-in)



4. Fasten all the screws. Screw torque: 25~30kg-cm (20.8~30lb-in).














5. Place the cover back to the top and fasten the screws (as shown in the figure). Screw torque: 12~15kg-cm (10.4~13lb-in).







Fan Kit

■ outer appearance of fans

<p>Frame A</p> <p>VFD022CP23A-21 VFD037CP23A-21 VFD055CP23A-21 VFD037CP43A/4EA-21 VFD040CP43A/4EA-21 VFD055CP43A/4EA-21 VFD075CP43A/4EA-21</p>	<p>Model 『MKC-AFKM』</p> 
<p>Frame B</p> <p>VFD075CP23A-21 VFD110CP43A-21 VFD110CP4EA-21</p>	<p>Model 『MKC-BFKM1』</p> 
<p>Frame B</p> <p>VFD110CP23A-21 uses MKC-BFKM2 VFD150CP23A-21 uses MKC-BFKM3 VFD150CP43A-21 uses MKC-BFKM2 VFD150CP4EA-21 uses MKC-BFKM2 VFD185CP43A-21 uses MKC-BFKM2 VFD185CP4EA-21 uses MKC-BFKM2 (MKC-BFKM2 and MKC-BFKM3 have the same look.)</p>	<p>Model 『MKC-BFKM2』 Model 『MKC-BFKM3』</p> 
<p>Frame B</p> <p>VFD075CP23A-21 VFD110CP23A-21 VFD110CP43A-21 VFD110CP4EA-21 VFD150CP23A-21 VFD150CP43A-21 VFD150CP4EA-21 VFD185CP43A-21 VFD185CP4EA-21</p>	<p>Model 『MKC-BFKB』</p> 
<p>Frame C</p> <p>VFD185CP23A-21 VFD220CP23A-21 VFD300CP23A-21</p>	<p>Model 『MKC-CFKB1』</p> 

<p>Frame C</p> <p>VFD220CP43A-21 VFD220CP4EA-21 VFD300CP43A-21 VFD300CP4EA-21 VFD370CP43A-21 VFD370CP4EA-21</p>	<p>Model 『MKC-CFKB2』</p> 	
<p>Frame D</p> <p>VFD370CP23A-00; VFD370CP23A-21; VFD450CP23A-00; VFD450CP23A-21; VFD450CP43A-00; VFD450CP43A-21; VFD550CP43A-00; VFD550CP43A-21; VFD750CP43A-00; VFD750CP43A-21; VFD900CP43A-00; VFD900CP43A-21;</p>	<p>Model 『MKC-DFKM』</p> 	<p>Model 『MKC-DFKB』</p> 
<p>Frame E</p> <p>VFD550CP23A-00 VFD750CP23A-21 VFD750CP23A-00 VFD750CP23A-21</p>	<p>Model 『MKC-EFKM1』</p> 	
<p>Frame E</p> <p>Corresponding models:</p> <p>VFD900CP23A-00; VFD900CP23A-21; VFD1100CP43A-00; VFD1100CP43A-21; VFD1320CP43A-00; VFD1320CP43A-21;</p>	<p>Model 『MKC-EFKM2』</p> 	
<p>Frame E</p> <p>VFD550CP23A-00 VFD750CP23A-21 VFD750CP23A-00 VFD750CP23A-21; VFD900CP23A-00; VFD900CP23A-21; VFD1100CP43A-00; VFD1100CP43A-21; VFD1320CP43A-00; VFD1320CP43A-21;</p>	<p>Model 『MKC-EFKB』</p> 	

<p>Frame F</p> <p>VFD1600CP43A-00; VFD1600CP43A-21 VFD1850CP43A-00; VFD1850CP43A-21</p>	<p>Model 『MKC-FFKM』</p> 
<p>Frame F</p> <p>VFD1600CP43A-00; VFD1600CP43A-21; VFD1850CP43A-00; VFD1850CP43A-21</p>	<p>Model 『MKC-FFKB』</p> 
<p>Frame G</p> <p>VFD2200CP43A-00; VFD2200CP43A-21; VFD2800CP43A-00; VFD2800CP43A-21;</p>	<p>Model 『MKC-GFKM』</p> 
<p>Frame H</p> <p>VFD3150CP43A-00; VFD3550CP43A-00; VFD4000CP43A-00;</p> <p>VFD3150CP43C-21 VFD3550CP43C-21; VFD4000CP43C-21</p> <p>VFD3150CP43C-00 VFD3550CP43C-00 VFD4000CP43C-00</p>	<p>Model 『MKC-HFKM』</p> 

■ Fan Removal


Frame A

Corresponding models:

VFD022CP23A-21; VFD037CP23A-21; VFD055CP23A-21; VFD037CP43A/4EA-21;

VFD040CP43A/4EA-21; VFD055CP43A/4EA-21; VFD075CP43A/4EA-21

1. As shown by the arrow sign, press the tabs on both side of the fan to remove the fan.
2. As shown by the partially enlarged image below, disconnect the fan's power before removing the fan.





Frame B

Corresponding models:

VFD075CP23A-21; VFD110CP23A-21; VFD110CP43A-21;
 VFD110CP4EA-21; VFD150CP23A-21; VFD150CP43A-21;
 VFD150CP4EA-21; VFD185CP43A-21; VFD185CP4EA-21;

1. As shown by the arrow sign, press the tabs on both side of the fan to remove the fan.

2. As shown by the partially enlarged image below, disconnect the fan's power before removing the fan.

**Frame B&C**

Corresponding models:

Frame B:


VFD075CP23A-21; VFD110CP23A-21; VFD110CP43A-21;
 VFD110CP4EA-21; VFD150CP23A-21; VFD150CP43A-21;
 VFD150CP4EA-21; VFD185CP43A-21; VFD185CP4EA-21;

Frame C:

VFD185CP23A-21; VFD220CP23A-21; VFD300CP23A-21;
 VFD220CP43A-21; VFD220CP4EA-21; VFD300CP43A-21;
 VFD300CP4EA-21; VFD370CP43A-21; VFD370CP4EA-21

As shown by the partially enlarged image, disconnect the fan's power,

then use a screwdriver to unclinch and to remove the fan.



Frame D

Corresponding models:

VFD370CP23A-00; VFD370CP23A-21; VFD450CP23A-00;
 VFD450CP23A-21; VFD450CP43A-00; VFD450CP43A-21;
 VFD550CP43A-00; VFD550CP43A-21; VFD750CP43A-00;
 VFD750CP43A-21; VFD900CP43A-00; VFD900CP43A-21;

1. (Figure 1) Loosen screw 1 and screw 2, press the on the right and the left to remove the cover, follow the direction the arrows indicate. Press on top of digital keypad KPC-CE01 to properly remove the keypad. Screw torque: 10~12kg-cm (8.6~10.4in-lbf).




Figure 1

2. (Figure 2) Loosen screw 3 and screw 4, press the tab on the right and the left to remove the cover. Screw torque: 6~8kg-cm (5.2~6.9in-lbf).




Figure 2

3. (Figure 3) Loosen screw 5 and disconnect the fan's power. Screw torque: 10~12kg-cm (8.6~10.4in-lbf).




Figure 3

4. (Figure 4) Loosen the screws 1~4. Screw torque: 24~26kg-cm (20.8~22.6in-lbf).

5. Disconnect fan's power (as shown in the partially enlarged picture) and pull out the fan (as shown in the larger picture).




Figure 4


Frame E

Corresponding models:

VFD550CP23A-00; VFD750CP23A-21; VFD750CP23A-00;
 VFD750CP23A-21; VFD900CP23A-00; VFD900CP23A-21;
 VFD1100CP43A-00; VFD1100CP43A-21; VFD1320CP43A-00;
 VFD1320CP43A-21;


For fan model 『MKC-EFKM1』

Loosen screw 1~4 (as shown in the figure below), and disconnect the fan's power then remove the fan.
 Screw torque: 24~26kg-cm (20.8~22.6in-lbf).




For fan model 『MKC-EFKM2』

Loosen screw 1~4 (as shown in the figure below), and disconnect the fan's power then remove the fan.
 Screw torque: 24~26kg-cm (20.8~22.6in-lbf).



Loosen screw 1 and screw 2 (as shown in the figure below), and disconnect fan's power before removing the fan.
 Screw torque: 24~26kg-cm (20.8~22.6in-lbf).



Frame F Corresponding models:

VFD1600CP43A-00; VFD1600CP43A-21; VFD1850CP43A-00; VFD1850CP43A-21;
 VFD1600CP43A-00; VFD1600CP43A-21; VFD1850CP43A-00; VFD1850CP43A-21

For fan model 『MKC-FFKM』 As shown in the partially enlarged picture, disconnect the fan's power before you remove it.
 Loosen the screws 1~4 and remove the fan (as shown in figure below). Screw torque: 24~26kg-cm (20.8~22.6lb-in)』

For fan model 『MKC-FFKB』
 (1) Loosen the screws 1~4 (as shown in figure below) and remove the cover. Screw torque: 14~16kg-cm (12.2~13.9lb-in).

(2) Loosen the screws 5~8 (as shown in figure below) and remove the cover. Screw torque: 24~26kg-cm (20.8~22.6lb-in).

(3) As shown in the partially enlarged image, disconnect the fan's power.
 (4) Loosen the screws 9~11 (figure 3) and remove the fan (figure 4). Screw torque: 24~26kg-cm (20.8~22.6lb-in)

Figure3

Figure 4


Frame G

Corresponding models:

VFD2200CP43A-00; VFD2200CP43A-21;
 VFD2800CP43A-00; VFD2800CP43A-21;


For fan model 『MKC-GFKM』

(1) Loosen the screws 1~4 (as shown in figure below) and remove the cover. Screw torque: 24~26kg-cm (20.8~22.6lb-in).




(2) Loosen the screws 1~8 (as shown in the figure below). Screw torque: 35~40kg-cm (30.4~34.7lb-in)


Then loosen screws 9~10 (as shown in the figure below). Then remove the cover. Screw torque: 24~26kg-cm (20.8~22.6lb-in)



(3) Loosen screws 1~3 and remove snap bushing 4~5 (as shown in the figure below) Screw torque: 15~20kg-cm (12.2~13.9lb-in)



(4) Hook your index fingers to the two snap bushing holes 1~2 (as shown in the figure below), then lift to remove the fan.




Frame H

Corresponding models:


VFD3150CP43A-00; VFD3550CP43A-00; VFD4000CP43A-00;
 VFD3150CP43C-00; VFD3550CP43C-00; VFD4000CP43C-00
 VFD3150CP43C-21; VFD3550CP43C-21; VFD4000CP43C-21

Model 『MKC-HFKM』


- (1) Loosen the screws 1~4 and remove the top cover.
 Screw torque: 14~16kg-cm (12.2~13.9lb-in)




- (2) Loosen the screws 5~12 and remove the top cover.
 Screw torque: 24~26kg-cm (20.83~22.57lb-in)



- (3) Disconnect the fan's power



- (4) Loosen the screws 13~18 and remove the fan. Make sure fan's is properly disconnected before removal. Screw torque: 24~26kg-cm (20.8~22.6lb-in).




Flange Mounting Kit

Corresponding frames: Frames A ~F


Frame A

『MKC-AFM1』


Corresponding models: VFD022CP23A-21; VFD037CP23A-21; VFD037CP43A-21



Accessories 1*1 piece



Accessories 2*2 pieces




Accessories 3*2 pieces

Screw 1 *4 pieces
M3*P 0.5; L=6mm


Screws 2*8 pieces
M6*P 1.0; L=16mm

『MKC-AFM』

Corresponding models: VFD007CP23A-21; VFD015CP23A-21; VFD055CP23A-21;
VFD007CP43A/4EA-21; VFD015CP43A/4EA-21; VFD022CP43A/4EA-21;
VFD040CP43A/4EA-21; VFD055CP43A/4EA-21; VFD075CP43A/4EA-21



Accessories 1*2 pieces




Accessories 2*2 pieces

Screw 1*8 pieces
M6*P 1.0; L=16mm


Panel Cutout Diagrams

Unit: mm [inch]




Installation of 『MKC-AFM1』


Step1. Install accessory 1 by fastening 4 of the screw 1(M3). Screw torque: 6~8kg-cm (5.21~6.95lb-in).




Step2. Install accessory 2&3 by fastening 2 of the screw 2(M6). Screw torque:25~30kg-cm (21.7~ 26.lb-in) 』



Step3. Install accessory 2&3 by fastening 2 of the screw 2(M6). Screw torque:25~30kg-cm (21.7~26 lb-in) 』




Step4. Plate installation, place 4 of the screw 2 (M6) through accessory 2&3 and the plate then fasten the screws. Screw torque: 25~30kg-cm (5.21~6.94lb-in).25~30kg-cm (21.7~26lb-in) 』




Installation of 『MKC-AFM』


1. Install accessory 1 & 2 by fastening 2 of the screw 1 (M3). Screw torque: 25~30kg-cm (21.7~26lb-in) (As shown in the figures below)



2. Install accessory 1 & 2 by fastening 2 of the screw 1 (M3). 25~30kg-cm (21.7~26lb-in) (As shown in the figures below)




3. Plate installation, place 4 of the screw 2 (M6) through accessory 1 & 2 and the plate then fasten the screws. Screw torque: 25~30kg-cm (21.7~26 lb-in) (As shown in the figures below)




Frame B

『MKC-BFM』

Corresponding models: All Frame B models



Accessories 1*2 pieces




Accessories 2*2pce

Screw 1 *4 pieces ~ M8*P 1.25;
Screw 2*6 pieces ~ M6*P 1.0;


Panel cutout diagram

Unit : mm [inch]




Installation of 『MKC-BFM』

1. Install accessory 1& 2 by fastening 4 of the screw 1(M8). Screw torque: 40~45kg-cm (34.7~39.0lb-in). (As shown in the following figure)





2. Plate installation, place 6 of the screw 2 (M6) through accessory 1&2 and the plate then fasten the screws. Screw torque: 25~30kg-cm (21.7~26lb-in). (As shown in the following figure)



Frame C

『MKC-CFM』


Corresponding models: All Frame C models.



Screw 1*4pce ~ M8*P 1.25;
Screw 2*8 pieces~ M6*P 1.0;


Panel cutout diagram

Unit: :mm [inch]




Installation of 『MKC-CFM』

1. Install accessory 1 & 2 by fastening 4 of the screw 1 (M8). Screw torque: 50~55kg-cm (43.4~47.7lb-in). (As shown in the figures below)




2. Plate installation, place 8 of the screw 2 (M6) through accessories 1&2 and the plate then fasten the screws. Screw torque: 25~30kg-cm (21.7~26.0lb-in). (As shown in the figures below)



Frame D

Panel Cutout Diagrams


Unit: mm [inch]



Frame E


Panel Cutout Diagrams

Unit :mm [inch]




Installation for Frame D&E


Step1. Loosen 8 screws and remove Fixture 2 (as shown in the following figure) ◦




Step5. Fasten 4 screws (as shown in the following figure). Screw torque: 24~26kg-cm (20.8~22.6lb-in)




Step2. Loosen 10 screws and remove Fixture 1 (as shown in the figure below.)




Step6. Fasten 5 screws (as shown in the figure below). Screw torque: 24~26kg-cm (20.8~22.6lb-in).




Step3. Fasten 4 screws (as shown in the figure below). Screw torque: 30~32kg-cm (26.0~27.8lb-in).



Step7. Place 4 screws (M10) through Fixture 1&2 and the plate then fasten the screws. (as shown in the following figure) Screw torque: 200~240kg-cm (173.6~208.3lb-in).




Step4. Fasten 5 screws (as shown in the figure below). Screw torque: 30~32kg-cm (26.0~27.8lb-in).



Frame F

Panel Cutout Diagram


Unit: mm [inch]




UNIT:mm[inch]

Installation for Frame


Step1. Loosen 12 screws and remove Fixture 2.




Step4. Install Fixture 1 by fasten screw 13 ~26
Screw torque: 24~26kg-cm (20.8~22.6lb-in).




Step2. Loosen 12 screws and remove Fixture 2.
Screw torque: 24~26kg-cm (20.8~22.6lb-in).



Step5. Place 4 of the M12 screws through Fixture 1&2 and plate then fasten the screws.
Screw torque: 300~400kg-cm (260~347lb-in).



Step3. Loosen screw 13~ 26 and remove Fixture 1.



IFD6530: USB/RS-485 Communication Interface

⚠ Warning


- ✓ Please read throughly this instruction sheet before installation and putting it into use.
- ✓ The content of this instruction sheet and the driver file may be revised without prior notice. Please consult our distributors or download the most updated instruction/driver version at http://www.delta.com.tw/product/em/control/cm/control_cm_main.asp

1. Introduction

IFD6530 is a convenient RS-485-to-USB converter, which does not require external power-supply and complex setting process. It supports baud rate from 75 to 115.2kbps and auto switching direction of data transmission. In addition, it adopts RJ-45 in RS-485 connector for users to wire conveniently. And its tiny dimension, handy use of plug-and-play and hot-swap provide more conveniences for connecting all DELTA IABU products to your PC.

Applicable Models: All DELTA IABU products.

■ Application & Dimension



2. Specification

Power supply	No external power is needed
Power consumption	1.5W
Isolated voltage	2,500VDC
Baud rate	75, 150, 300, 600, 1,200, 2,400, 4,800, 9,600, 19,200, 38,400, 57,600, 115,200 bps
RS-485 connector	RJ-45
USB connector	A type (plug)
Compatibility	Full compliance with USB V2.0 specification
Max. cable length	RS-485 Communication Port: 100 m
Support RS-485 half-duplex transmission	

RJ-45




PIN	Description
1	Reserved
2	Reserved
3	GND
4	SG-

PIN	Description
5	SG+
6	GND
7	Reserved
8	+9V

3. Preparation before installing the driver

Extract the driver file (IFD6530_Drivers.exe) by following the steps below. You could find driver file (IFD6530_Drivers.exe) in the CD supplied with IFD6530.

Note : Do NOT connect the IFD6530 to a computer before extracting the driver file.

STEP 1**STEP 2****STEP 3****STEP 4****STEP 5**

You should have a folder marked SiLabs under drive C (c:\ SiLabs).


4. Driver Installation

Now connect the IFD6530 to a USB port on your computer. Then follow the steps below to install the driver of IFD6530.



STEP 1




STEP 2



OR



Browse and select directory, or enter
C:\SiLabs\MCU\CP210x\WIN



5. LED Display


1. Steady Green LED ON: power is ON.
2. Blinking orange LED: data is transmitting.

08 Installation of the Option Cards (all optional)


Select applicable option cards for your drive or contact local distributor for professional advice. To prevent drive damage during installation, please remove the digital keypad and the cover before wiring. Refer to the instructions below.

Remove cover & keypad


Frame A, B and C: Screw Torque: 8~10Kg-cm [6.9~8.7lb-in.]




Frame D: Screw Torque: 8~10Kg-cm [6.9~8.7lb-in.]




Frame E: Screw Torque: 12~15Kg-cm [10.4~13lb-in.] As shown below, lift the cover then pull to remove it.




Frame F: Screw Torque: 12~15Kg-cm [10.4~13lb-in.] As shown below, lift the cover then pull to remove it.




Frame G: Screw Torque: 12~15Kg-cm [10.4~13lb-in.] As shown below, lift the cover then pull to remove it.



Frame H: Screw Torque: 14~16Kg-cm [12.15~13.89lb-in.]





1	<p>RJ45 (Socket) for digital keypad KPC-CC01; KPC-CE01</p> <ul style="list-style-type: none"> ☑ <u>Please refer to CH10 Digital Keypad for more details on KPC-CE01.</u> ☑ <u>Please refer to CH10 Digital Keypad for more details on optional accessory RJ45 extension cable.</u>
2	<p>Communication Expansion Cards (Slot 1)</p> <p>CMC-MOD01; CMC-PD01; CMC-DN01; CMC-EIP01; EMC-COP01;</p>
3	<p>I/O & Relay Expansion Card (Slot 3)</p> <p>EMC-D42A; EMC-D611A; EMC-R6AA;</p>
4	No Function

EMC-D42A

	Terminals	Descriptions
I/O Expansion Card	COM	Common for Multi-function input terminals Select SINK (NPN) /SOURCE (PNP) in J1 jumper / external power supply
	MI10~ MI13	Refer to parameters 02-27~02-30 in Chapter 11 to program the multi-function inputs MI10~MI13. Internal power is applied from terminal E24: +24Vdc±5% 200mA, 5W External power +24VDC: max. voltage 30VDC, min. voltage 19VDC, 30W ON: the activation current is 6.5mA OFF: leakage current tolerance is 10μA
	MO10~MO11	Multi-function output terminals (photocoupler) Duty-cycle: 50% Max. output frequency: 100Hz Max. current: 50mA Max. voltage: 48Vdc
	MXM	Common for multi-function output terminals MO10, MO11(photocoupler) Max 48VDC 50mA

EMC-D611A

	Terminals	Descriptions
	I/O Expansion Card	AC
MI9~ MI14		Refer to Pr. 02.26~ Pr. 02.31 in Chapter 11 for multi-function input selection Input voltage: 100~130VAC Input frequency: 57~63Hz Input impedance: 27Kohm Terminal response time: ON: 10ms OFF: 20ms

EMC-R6AA

	Terminals	Descriptions
	Relay Expansion Card	MO3 ~ MO13

Screw Specifications for Option Cards' Terminals:


EMC-D42A	Wire Gauge	24~12AWG (0.205~3.31mm ²)
	Torque	4Kg-cm [3.47lb-in]
EMC-R6AA	Wire Gauge	24~16AWG (0.205~1.31mm ²)
	Torque	6Kg-cm [5.21lb-in]

CMC-MOD01

■ **Features**

1. Supports Modbus TCP protocol
2. MDI/MDI-X auto-detect
3. Baud rate: 10/100Mbps auto-detect
4. E-mail alarm
5. AC motor drive keypad/Ethernet configuration
6. Virtual serial port.

■ **Product Introduction**



①	I/O CARD & Relay Card
②	No function
③	Comm. Card
④	RJ-45 connection port
⑤	Removable control circuit terminal

■ **Specifications**

Network Interface

Interface	RJ-45 with Auto MDI/MDIX
Number of ports	1 Port
Transmission method	IEEE 802.3, IEEE 802.3u
Transmission cable	Category 5e shielding 100M
Transmission speed	10/100 Mbps Auto-Detect
Network protocol	ICMP, IP, TCP, UDP, DHCP, SMTP, MODBUS OVER TCP/IP, Delta Configuration

Electrical specifications

Power supply voltage	5VDC (provided by the AC drive)
Insulation voltage	2KV
Power consumption	0.8W
Weight	25g


Environment Specifications

Noise Immunity	ESD(IEC 61800-5-1,IEC 6100-4-2) EFT(IEC 61800-5-1,IEC 6100-4-4) Surge Teat(IEC 61800-5-1,IEC 6100-4-5) Conducted Susceptibility Test(IEC 61800-5-1,IEC 6100-4-6)
----------------	---

Operation/Storage	Operation : -10°C ~ 50°C (Temperature) , 90% (Humidity) Storage : -25°C ~ 70°C (Temperature) , 95% (Humidity)
Shock/Vibration resistance	International Standard: IEC 61800-5-1,IEC 60068-2-6 / IEC 61800-5-1,IEC 60068-2-27

- **Install CMC-MOD01 on VFD-CP2000**

1. Switch off the power supply of VFD-CP2000.
2. Open the front cover of VFD-CP2000.
3. Place the insulation spacer into the positioning pin at Slot 1 (shown in Figure 3), and aim the two holes on the PCB at the positioning pin. Press the pin to clip the holes with the PCB (see Figure 4).
4. Screw up at torque 6 ~ 8 kg-cm (5.21 ~ 6.94 in-lbs) after the PCB is clipped with the holes (see Figure 5).




■ Communication parameter for VFD-CP2000 to connect to an Ethernet

Before VFD-CP2000 is linked to an Ethernet, set up the communication parameters shown in the table below. Then Ethernet master will be able to read/write the frequency characters and control characters from/into VFD-CP2000 after communication parameters are set.


CP2000	Functions	Factory setting	Explanation
00-20	Set up source of frequency	0	Frequency command from keypad
00-21	Set up source of operation command	5	Operation command from communication card.
09-30	Communication decoding method	0	The decoding method for Delta AC Motor Drive (Delta AMD).
09-75	IP configuration	0	Static IP(0) / Dynamic IP (DHCP) (1)
09-76	IP address-1	192	IP address <u>192.168.1.5</u>
09-77	IP address-2	168	IP address 192. <u>168.1.5</u>
09-78	IP address-3	1	IP address 192.168. <u>1.5</u>
09-79	IP address-4	5	IP address 192.168.1. <u>5</u>
09-80	Net mask-1	255	Net mask <u>255.255.255.0</u>
09-81	Net mask-2	255	Net mask 255. <u>255.255.0</u>
09-82	Net mask-3	255	Net mask 255.255. <u>255.0</u>
09-83	Net mask-4	0	Net mask 255.255.255. <u>0</u>
09-84	Default gateway-1	192	Default gateway <u>192.168.1.1</u>
09-85	Default gateway-2	168	Default gateway 192. <u>168.1.1</u>
09-86	Default gateway-3	1	Default gateway 192.168. <u>1.1</u>
09-87	Default gateway-4	1	Default gateway 192.168.1. <u>1</u>

■ Remove CMC- MOD01 from VFD-CP2000


1. Switch off the power supply of VFD-C2000.
2. Remove the two screws (see Figure 6).
3. Twist opens the card clip and inserts the slot type screwdriver to the hollow to prize the PCB off the card clip (see Figure 7).
4. Twist opens the other card clip to remove the PCB (see Figure 8).



[Figure 6]



[Figure 7]



[Figure 8]

■ Basic Registers

BR number	Property	Content	Explanation
#0	R	Model name	Set up by the system; read only. The model code of CMC-MOD01=H'0203
#1	R	Firmware version	Displaying the current firmware version in hex, e.g. H'0100 indicates the firmware version V1.00.
#2	R	Release date of the version	Displaying the data in decimal form. 10,000s digit and 1,000s digit are for "month"; 100s digit and 10s digit are for "day". For 1 digit: 0 = morning; 1 = afternoon.
#11	R/W	Modbus Timeout	Preset : 500 (ms)
#13	R/W	Keep Alive Time	Preset : 30 (s)

■ LED Indicators & Troubleshooting

LED Indicators

LED	Status	Indication	Action	
POWER	Green	On	Power supply in normal status	No action required
		Off	No power supply	Check if the power supply is plugged.
LINK	Green	On	Network connection in normal status	No action required
		Flashes	Network in operation	No action required
		Off	Network not connected	Check if the network cable is connected

Troubleshooting

Abnormality	Cause	Action
POWER LED off	AC motor drive not powered	Check if AC motor drive is powered, and if the power supply is normal.
	CMC-MOD01 not connected to AC motor drive	Make sure CMC-MOD01 is connected to AC motor drive.
LINK LED off	CMC-MOD01 not connected to network	Make sure the network cable is correctly connected to network.
	Poor contact to RJ-45 connector	Make sure RJ-45 connector is connected to Ethernet port.
No module found	CMC-MOD01 not connected to network	Make sure CMC-MOD01 is connected to network.
	PC and CMC-MOD01 in different networks and blocked by network firewall.	Search by IP or set up relevant settings by AC motor drive keypad.
Fail to open CMC-MOD01 setup page	CMC-MOD01 not connected to network	Make sure CMC-MOD01 is connected to the network.
	Incorrect communication setting in DCISoft	Make sure the communication setting in DCISoft is set to Ethernet.
	PC and CMC-MOD01 in different networks and blocked by network firewall.	Conduct the setup by AC motor drive keypad.


Abnormality	Cause	Action
Able to open CMC-MOD01 setup page but fail to utilize webpage monitoring	Incorrect network setting in CMC-MOD01	Check if the network setting for CMC-MOD01 is correct. For the Intranet setting in your company, please consult your IT staff. For the Internet setting in your home, please refer to the network setting instruction provided by your ISP.
Fail to send e-mail	Incorrect network setting in CMC-MOD01	Check if the network setting for CMC-MOD01 is correct.
	Incorrect mail server setting	Please confirm the IP address for SMTP-Server.

CMC-PD01

■ **Features**

1. Supports PZD control data exchange.
2. Supports PKW polling AC motor drive parameters.
3. Supports user diagnosis function.
4. Auto-detects baud rates; supports Max. 12Mbps.

■ **Product Introduction**



- 1. NET indicator
- 2. POWER indicator
- 3. Positioning hole
- 4. AC motor drive connection port
- 5. PROFIBUS DP connection port
- 6. Screw fixing hole
- 7. Fool-proof groove

■ **Specifications**

PROFIBUS DP Communication Connector

Interface	DB9 connector
Transmission method	High-speed RS-485
Transmission cable	Shielded twisted pair cable
Electrical isolation	500VDC

Communication

Message type	Data exchange periodically
Module name	CMC-PD01
GSD document	DELTA08DB.GSD
Company ID	08DB(HEX)
Serial transmission speed supported (auto-detection)	Support 9.6kbps; 19.2kbps; 93.75kbps; 187.5kbps; 500kbps; 1.5Mbps; 3Mbps; 6Mbps; 12Mbps (bits per second)

Electrical Specification

Power supply	5VDC (provided by AC Motor Drive)
Insulation	500VDC
Power	1W
Weight	28g


Environment Specification

Noise immunity	ESD(IEC 61800-5-1,IEC 6100-4-2) EFT(IEC 61800-5-1,IEC 6100-4-4) Surge Teat(IEC 61800-5-1,IEC 6100-4-5) Conducted Susceptibility Test(IEC 61800-5-1,IEC 6100-4-6)
Operation /storage	Operation : -10°C ~ 50°C (Temperature) , 90% (Humidity) Storage : -25°C ~ 70°C (Temperature) , 95% (Humidity)
Shock / vibration resistance	International standard IEC61131-2, IEC68-2-6 (TEST Fc) / IEC61131-2 & IEC 68-2-27(TEST Ea)

- **Installation**

PROFIBUS DP Communication Connector: Definition of pins

Pin	Name	Definition
1	-	Not defined
2	-	Not defined
3	Rxd/Txd-P	Sending/receiving data P(B)
4	-	Not defined
5	DGND	Data reference ground
6	VP	Power voltage – positive
7	-	Not defined
8	Rxd/Txd-N	Sending/receiving data N(A)
9	-	Not defined



- **LED Indicator and Troubleshooting**

There are 2 LED indicators on CMC-PD01. POWER LED displays the status of the working power. NET LED displays the connection status of the communication.

POWER LED

LED status	Indication	Action
Green light on	Power supply in normal status.	No action required
Off	No power	Check if CMC-PD01 and AC motor drive are properly connected.

NET LED


LED status	Indication	Action
Green light on	Normal status	No action required
Red light on	CMC-PD01 is not connected to PROFIBUS DP bus.	Connect CMC-PD01 to PROFIBUS DP bus.
Red light flashes	Invalid PROFIBUS communication address	Set the PROFIBUS address of CMC-PD01 between 1 ~ 125 (decimal)
Orange light flashes	CMC-PD01 fails to communication with AC motor drive.	Switch off the power and check whether CMC-PD01 is correctly and normally connected to AC motor drive.

CMC-DN01

■ Features

1. Based on the high-speed communication interface of Delta HSSP protocol, able to conduct immediate control to AC motor drive.
2. Supports Group 2 only connection and polling I/O data exchange.
3. For I/O mapping, supports Max. 32 words of input and 32 words of output.
4. Supports EDS file configuration in DeviceNet configuration software.
5. Supports all baud rates on DeviceNet bus: 125kbps, 250kbps, 500kbps and extendable serial transmission speed mode.
6. Node address and serial transmission speed can be set up on AC motor drive.
7. Power supplied from AC motor drive.

■ Product introduction



1. NS indicator
2. MS indicator
3. POWER indicator
4. Positioning hole
5. DeviceNet connection port
6. Screw fixing hole
7. Fool-proof groove
8. AC motor drive connection port

■ Specifications

DeviceNet Connector

Interface	5-PIN open removable connector. Of 5.08mm PIN interval
Transmission method	CAN
Transmission cable	Shielded twisted pair cable (with 2 power cables)
Transmission speed	125kbps, 250kbps, 500kbps and extendable serial transmission speed mode
Network protocol	DeviceNet protocol

AC Motor Drive Connection Port

Interface	50 PIN communication terminal
Transmission method	SPI communication
Terminal function	1. Communicating with AC motor drive 2. Transmitting power supply from AC motor drive
Communication protocol	Delta HSSP protocol

Electrical Specifications


Power supply	5VDC (provided by AC motor drive)
Insulation	500VDC
Communication	0.85W
Power	1W
Weight	23g

Environmental Specifications

Noise immunity	ESD (IEC 61800-5-1, IEC 6100-4-2) EFT (IEC 61800-5-1, IEC 6100-4-4) Surge Teat (IEC 61800-5-1, IEC 6100-4-5) Conducted Susceptibility Test (IEC 61800-5-1, IEC 6100-4-6)
Operation /storage	Operation: -10°C ~ 50°C (temperature), 90% (humidity), pollution degree 2 Storage: -25°C ~ 70°C (temperature), 95% (humidity, non-condensing)
Shock / vibration resistance	International standards: IEC61131-2, IEC68-2-6 (TEST Fc)/IEC61131-2 & IEC 68-2-27 (TEST Ea)

DeviceNet Connector: Definition of Pins

PIN	Signal	Color	Definition
1	V+	Red	DC24V
2	H	White	Signal+
3	S	-	Earth
4	L	Blue	Signal-
5	V-	Black	0V



- **LED Indicator & Troubleshooting**

There are 3 LED indicators on CMC-DN01. POWER LED displays the status of power supply. MS LED and NS LED are dual-color LED, displaying the connection status of the communication and error messages.

POWER LED

LED status	Indication	Action
On	Power supply in abnormal status.	Check the power supply of CMC-DN01.
Off	Power supply in normal status	No action required

NS LED

LED status	Indication	Action
Off	No power supply or CMC-DN01 has not completed MAC ID test yet.	<ol style="list-style-type: none"> 1. Check the power of CMC-DN01 and see if the connection is normal. 2. Make sure at least one or more nodes are on the bus. 3. Check if the serial transmission speed of CMC-DN01 is the same as that of other nodes.
Green light flashes	CMC-DN01 is on-line but has not established connection to the master.	<ol style="list-style-type: none"> 1. Configure CMC-DN01 to the scan list of the master. 2. Re-download the configured data to the master.
Green light on	CMC-DN01 is on-line and is normally connected to the master	No action required

Red light flashes	CMC-DN01 is on-line, but I/O connection is timed-out.	<ol style="list-style-type: none"> 1. Check if the network connection is normal. 2. Check if the master operates normally.
Red light on	<ol style="list-style-type: none"> 1. The communication is down. 2. MAC ID test failure. 3. No network power supply. 4. CMC-DN01 is off-line. 	<ol style="list-style-type: none"> 1. Make sure all the MAC IDs on the network are not repeated. 2. Check if the network installation is normal. 3. Check if the baud rate of CMC-DN01 is consistent with that of other nodes. 4. Check if the node address of CMC-DN01 is illegal. 5. Check if the network power supply is normal.

MS LED


LED status	Indication	How to correct
Off	No power supply or being off-line	Check the power supply of CMC-DN01 and see if the connection is normal.
Green light flashes	Waiting for I/O data	Switch the master PLC to RUN status
Green light on	I/O data are normal	--
Red light flashes	Mapping error	<ol style="list-style-type: none"> 1. Reconfigure CMC-DN01 2. Re-power AC motor drive
Red light on	Hardware error	<ol style="list-style-type: none"> 1. See the error code displayed on AC motor drive. 2. Send back to the factory for repair if necessary.
Orange light flashes	CMC-DN01 is establishing connection with AC motor drive.	If the flashing lasts for a long time, check if CMC-DN01 and AC motor drive are correctly installed and normally connected to each other.

CMC-EIP01

■ **Features**

1. Supports Modbus TCP and Ethernet/IP protocol
2. MDI/MDI-X auto-detect
3. Baud rate: 10/100Mbps auto-detect
4. AC motor drive keypad/Ethernet configuration
5. Virtual serial port

■ **Product Introduction**



[Figure1]

1. Screw fixing hole
2. Positioning hole
3. AC motor drive connection port
4. LINK indicator
5. RJ-45 connection port
6. POWER indicator
7. Fool-proof groove

■ **Specifications**

Network Interface

Interface	RJ-45 with Auto MDI/MDIX
Number of ports	1 Port
Transmission	IEEE 802.3, IEEE 802.3u
Transmission cable	Category 5e shielding 100M
Transmission speed	10/100 Mbps Auto-Detect
Network protocol	ICMP, IP, TCP, UDP, DHCP, HTTP, SMTP, MODBUS OVER TCP/IP, Ethernet/IP, Delta Configuration

Electrical Specifications

Weight	25g
Insulation Voltage	500VDC
Power Consumption	0.8W
Power Supply Voltage	5VDC


Environment Specifications

Noise immunity	ESD (IEC 61800-5-1,IEC 61000-4-2) EFT (IEC 61800-5-1,IEC 61000-4-4) Surge Test (IEC 61800-5-1,IEC 61000-4-5) Conducted Susceptibility Test (IEC 61800-5-1,IEC 61000-4-6)
Operation/storage	Operation: -10°C ~ 50°C (temperature), 90% (humidity), pollution degree 2 Storage: -25°C ~ 70°C (temperature), 95% (humidity), non-condensing
Vibration/shock immunity	International standard: IEC 61800-5-1, IEC 60068-2-6/IEC 61800-5-1, IEC 60068-2-27

■ Installation

Connecting CMC-EIP01 to a Network


1. Turn off the power of AC motor drive.
2. Open the cover of AC motor drive.
3. Connect CAT-5e network cable to RJ-45 port on CMC-EIP01 (See Figure 2).



[Figure 2]


RJ-45 connector: Definition of Pins

PIN	Signal	Definition	PIN	Signal	Definition
1	Tx+	Positive pole for data transmission	5	--	N/C
2	Tx-	Negative pole for data transmission	6	Rx-	Negative pole for data receiving
3	Rx+	Positive pole for data receiving	7	--	N/C
4	--	N/C	8	--	N/C




■ **Connecting CMC-EIP01 to VFD-CP2000**


1. Switch off the power of AC motor drive.
2. Open the front cover of AC motor drive.
3. Place the insulation spacer into the positioning pin at Slot 1 (shown in Figure 3), and aim the two holes on the PCB at the positioning pin. Press the pin to clip the holes with the PCB (see Figure 4).
4. Screw up at torque 6 ~ 8 kg-cm (5.21 ~ 6.94 in-lbs) after the PCB is clipped with the holes (see Figure 5).



[Figure 3]



[Figure 4]



[Figure 5]


■ Communication parameter for VFD-CP2000 to connect to an Ethernet

Before VFD-CP2000 is linked to an Ethernet, set up the communication parameters shown in the table below. Then Ethernet master will be able to read/write the frequency characters and control characters from/into VFD-CP2000 after communication parameters are set.


CP2000 Parameters	Functions	Factory setting (Dec)	Explanation
00-20	Set up source of frequency command	0	Frequency command from keypad
00-21	Set up source of operation command	5	Operation command from communication card.
09-30	Communication decoding method	0	The decoding method for Delta AC Motor Drive (Delta AMD).
09-75	IP configuration	0	Static IP(0) / Dynamic IP
09-76	IP address-1	192	IP address <u>192</u> .168.1.5
09-77	IP address-2	168	IP address 192. <u>168</u> .1.5
09-78	IP address-3	1	IP address 192.168. <u>1</u> .5
09-79	IP address-4	5	IP address 192.168.1. <u>5</u>
09-80	Net mask-1	255	Net mask <u>255</u> .255.255.0
09-81	Net mask-2	255	Net mask 255. <u>255</u> .255.0
09-82	Net mask-3	255	Net mask 255.255. <u>255</u> .0
09-83	Net mask-4	0	Net mask 255.255.255. <u>0</u>
09-84	Default gateway-1	192	Default gateway <u>192</u> .168.1.1
09-85	Default gateway-2	168	Default gateway 192. <u>168</u> .1.1
09-86	Default gateway-3	1	Default gateway 192.168. <u>1</u> .1
09-87	Default gateway-4	1	Default gateway 192.168.1. <u>1</u>

■ Remove CMC-EIP01 from VFD-CP2000


1. Switch off the power supply of VFD-CP2000.
2. Remove the two screws (see Figure 6).
3. Twist opens the card clip and inserts the slot type screwdriver to the hollow to prize the PCB off the card clip (see Figure 7).
4. Twist opens the other card clip to remove the PCB (see Figure 8).



[Figure 6]



[Figure 7]



[Figure 8]

■ LED Indicators & Troubleshooting

There are 2 LED indicators on CMC-EIP01. The POWER LED displays the status of power supply, and the LINK LED displays the connection status of the communication.

LED Indicators

LED	Status		Indication	Action
POWER	Green	On	Power supply in normal status	No action required
		Off	No power supply	Check the power supply.
LINK	Green	On	Network connection in normal status	No action required
		Flashes	Network in operation	No action required
		Off	Network not connected	Check if the network cable is connected.


Troubleshooting

Abnormality	Cause	Action
POWER LED off	AC motor drive not powered	Check if AC motor drive is powered, and if the power supply is normal.
	CMC-EIP01 not connected to AC motor drive	Make sure CMC-EIP01 is connected to AC motor drive.

Abnormality	Cause	Action
LINK LED off	CMC-EIP01 not connected to network	Make sure the network cable is correctly connected to network.
	Poor contact to RJ-45 connector	Make sure RJ-45 connector is connected to Ethernet port.
No communication card found	CMC-EIP01 not connected to network	Make sure CMC-EIP01 is connected to network.
	PC and CMC-EIP01 in different networks and blocked by network firewall.	Search by IP or set up relevant settings by AC motor drive keypad.
Fail to open CMC-EIP01 setup page	CMC-EIP01 not connected to network	Make sure CMC-EIP01 is connected to the network.
	Incorrect communication setting in DCISoft	Make sure the communication setting in DCISoft is set to Ethernet.
	PC and CMC-EIP01 in different networks and blocked by network firewall.	Conduct the setup by AC motor drive keypad.
Able to open CMC-EIP01 setup page but fail to utilize webpage monitoring	Incorrect network setting in CMC-EIP01	Check if the network setting for CMC-EIP01 is correct. For the Intranet setting in your company, please consult your IT staff. For the Internet setting in your home, please refer to the network setting instruction provided by your ISP.
Fail to send e-mail	Incorrect network setting in CMC-EIP01	Check if the network setting for CMC-EIP01 is correct.
	Incorrect mail server setting	Please confirm the IP address for SMTP-Server.

EMC-COP01

■ RJ-45: Definition of Pins



8~1
Male



Female


Pin	Pin name	Definition
1	CAN_H	CAN_H bus line (dominant high)
2	CAN_L	CAN_L bus line (dominant low)
3	CAN_GND	Ground/0V/V-
6	CAN_GND	Ground/0V/V-

■ Specifications

Interface	RJ-45
Number of ports	1 Port
Transmission method	CAN
Transmission cable	CAN standard cable
Transmission speed	1M 500k 250k 125k 100k 50k
Communication protocol	CANopen protocol

■ CANopen Communication Cable


Model : TAP-CB03, TAP-CB04



Title	Part No.	L	
		mm	inch
1	TAP-CB03	500 ± 10	19 ± 0.4
2	TAP-CB04	1000 ± 10	39 ± 0.4

■ CANopen Breakout Box

Model : TAP-CN03



NOTE

Please refer to CANopen user manual for more details on CANopen operation.

CANopen user manual can also be downloaded on Delta website: <http://www.delta.com.tw/industrialautomation/>.

o

09 CP2000 Specifications

230V series

Frame size		A					B			C			D		E			
Model :VFD_ _ _ _CP23A- _ _		007	015	022	037	055	075	110	150	185	220	300	370	450	550	750	900	
Output Rating	Light Duty	Rated Output Capacity (kVA)	2	3	4	6	8.4	12	18	24	30	36	42	58	72	86	110	128
		Rated Output Current (A)	5	7.5	10	15	21	31	46	61	75	90	105	146	180	215	276	322
		Applicable Motor Output(kW)	0.8	1.5	2.2	3.7	5.5	7.5	11	15	19	22	30	37	45	55	75	90
		Applicable Motor Output(HP)	1	2	3	5	7.5	10	15	20	25	30	40	50	60	75	100	125
		Overload tolerance	120% of rated current for 1 minute during every 5 minutes															
		Max. output frequency(Hz)	600.00Hz												400.00Hz			
		Carrier Frequency(kHz)	2~15kHz (8KHz)									2~10kHz(6KHz)			2~9kHz(4KHz)			
	Normal Duty	Rated Output Capacity (kVA)	1.8	2	3.2	4.4	6.8	10	13	20	26	30	36	48	58	72	86	102
		Rated Output Current (A)	4.6	5	8	11	17	25	33	49	65	75	90	120	146	180	215	255
		Applicable Motor Output(kW)	0.4	0.8	1.5	2.2	3.7	5.5	7.5	11	15	19	22	30	37	45	55	75
		Applicable Motor Output(HP)	0.5	1	2	3	5	7.5	10	15	20	25	30	40	50	60	75	100
		Overload tolerance	120% of rated current for 1 minute during every 5 minutes, 160% of rated current for 3 seconds during every 25 seconds															
		Max. output frequency(Hz)	600.00Hz												400.00Hz			
		Carrier Frequency(kHz)	2~15kHz (8KHz)									2~10kHz (6KHz)			2~9 kHz(4kHz)			
Input rating	Input Current (A) Light Duty	6.4	9.6	15	22	25	35	50	65	83	100	116	146	180	215	276	322	
	Input Current (A) Normal Duty	3.9	6.4	12	16	20	28	36	52	72	83	99	124	143	171	206	245	
	Rated Voltage/Frequency	3-phase AC 200V~240V (-15% ~ +10%), 50/60Hz																
	Operating Voltage Range	170~265Vac																
	Frequency Tolerance	47~63Hz																
Cooling method	Natural Cooling	Fan Cooling																
Braking Chopper	Frame A,B,C: Built-in												Frame D and E: Optional					
DC choke	Frame A, B,C: Optional												Frame D and E: 3% built-in					
EMI Filter	Optional																	




460V series

Frame size		A						B			C				
Model: VFD____CP43A-__ ; VFD____CP4EA-__ ;		007	015	022	037	040	055	075	110	150	185	220	300	370	
Output Rating	Light Duty	Rated Output Capacity (kVA)	2.4	2.9	4	6	8.4	9.6	11.2	18	24	29	36	45	57
		Rated Output Current (A)	3	3.7	5	7.5	10.5	12	14	22.5	30	36	45	56	72
		Applicable Motor Output(kW)	0.75	1.5	2.2	3.7	4	5.5	7.5	11	15	18.5	22	30	37
		Applicable Motor Output(HP)	1	2	3	5	5	7.5	10	15	20	25	30	40	50
		Overload tolerance	120% of rated current for 1 minute during every 5 minutes												
		Max. output frequency(Hz)	600.00Hz												
		Carrier Frequency(kHz)	2~15kHz(8KHz)										2~10kHz(6KHz)		
	Normal Duty	Rated Output Capacity (kVA)	2.2	2.4	3.2	4.8	7.2	8.4	10	14	19	25	30	36	48
		Rated Output Current (A)	2.8	3	4	6	9	10.5	12	18	24	32	38	45	60
		Applicable Motor Output(kW)	0.4	0.75	1.5	2.2	3.7	4	5.5	7.5	11	15	18.5	22	30
		Applicable Motor Output(HP)	0.5	1	2	3	5	5	7.5	10	15	20	25	30	40
		Overload tolerance	120% of rated current for 1 minute during every 5 minutes, 160% of rated current for 3 seconds during every 25 seconds												
		Max. output frequency(Hz)	600.00Hz												
		Carrier Frequency(kHz)	2~15kHz (8KHz)										2~10kHz (6kHz)		
Input rating	Input Current (A) Light Duty	4.3	5.4	7.4	11	16	18	20	25	33	39	47	58	76	
	Input Current (A) Normal Duty	3.5	4.3	5.9	8.7	14	15.5	17	20	26	35	40	47	63	
	Rated Voltage/Frequency	3-Phase AC 380V~480V (-15%~+10%), 50/60Hz													
	Operating Voltage Range	323~528Vac													
	Frequency Tolerance	47~63Hz													
Cooling method	Natural Cooling				Fan Cooling										
Braking Chopper	Frame A,B,C: Built-in														
DC choke	Frame A, B,C: Optional														
EMI Filter	Frame A, B, C of VFD____CP4EA-__, EMI filter Built-in; Frame A, B, C of VFD____CP43A-__, EMI filter Optional														


460V series

Frame size		D				E		F		G		H				
Model: VFD_ _ _ _ CP43A- _ _ ; VFD_ _ _ _ CP43C- _ _		450	550	750	900	1100	1320	1600	1850	2200	2800	3150	3550	4000		
Output Rating	Light Duty	Rated Output Capacity (kVA)	73	88	115	143	175	196	247	273	367	422	491	544	613	
		Rated Output Current (A)	91	110	144	180	220	246	310	343	460	530	616	683	770	
		Applicable Motor Output(kW)	45	55	75	90	110	132	160	185	220	280	315	355	400	
		Applicable Motor Output(HP)	60	75	100	125	150	175	215	250	300	375	425	475	536	
		Overload tolerance	120% of rated current for 1 minute during every 5 minutes													
		Max. output frequency(Hz)	600.00Hz				400.00Hz									
		Carrier Frequency(kHz)	2~10kHz(6KHz)				2~9 kHz(4KHz)									
	Normal Duty	Rated Output Capacity (kVA)	58	73	88	120	143	175	207	247	295	367	438	491	544	
		Rated Output Current (A)	73	91	110	150	180	220	260	310	370	460	550	616	683	
		Applicable Motor Output(kW)	37	45	55	75	90	110	132	160	185	220	280	315	355	
		Applicable Motor Output(HP)	50	60	75	100	125	150	175	215	250	300	375	425	475	
		Overload tolerance	120% of rated current for 1 minute during every 5 minutes, 160% of rated current for 3 seconds during every 25 seconds													
		Max. output frequency(Hz)	600.00Hz				400.00Hz									
		Carrier Frequency(kHz)	2~10kHz(6KHz)				2~9 kHz(4KHz)									
Input rating	Input Current (A) Light Duty	91	110	144	180	220	246	310	343	460	530	616	683	770		
	Input Current (A) Normal Duty	74	101	114	157	167	207	240	300	380	400	494	555	625		
	Rated Voltage/Frequency	3-Phase AC 380V~480V (-15%~+10%), 50/60Hz														
	Operating Voltage Range	323~528Vac														
	Frequency Tolerance	47~63Hz														
Cooling method	Fan Cooling															
Braking Chopper	Frame D and above: Optional															
DC choke	Frame D and above: 3% built-in															
EMI Filter	Frame D and above: Optional															

General Specifications:

Control Characteristics	Control Method	1: V/F(V/F control), 2: SVC(Sensorless Vector Control),				
	Starting Torque	Reach up to 150% or above at 0.5Hz.				
	V/F Curve	4 point adjustable V/F curve and square curve				
	Speed Response Ability	5Hz				
	Torque Limit	Normal Duty: Max. 170% torque current				
	Torque Accuracy	±5%				
	Max. Output Frequency (Hz)	230V series: 600.00Hz (55kw and above: 400.00Hz); 460V series: 600.00Hz (90KW and above: 400.00Hz)				
	Frequency Output Accuracy	Digital command: ±0.01%, -10°C ~ +40°C, Analog command: ±0.1%, 25±10°C				
	Output Frequency Resolution	Digital command: 0.01Hz, Analog command: max. output frequency x 0.03/60 Hz (±1 bit)				
	Overload Tolerance	Light duty: 120% of rated current for 1 minute; Normal duty: 120% of rated current for 1 minute; 160% of rated current for 3 seconds				
	Frequency Setting Signal	0~+10V, 4~20mA, 0~20mA, pulse input				
	Accel. /Decel. Time	0.00~600.00/0.0~6000.0 seconds				
	Main control function	Fault restart	Parameter copy	Dwell	BACnet Communication	Momentary power loss ride thru
		Speed search	Over-torque detection	Torque limit	16-step speed (max)	Accel/Decel. time switch
S-curve accel/decel		3-wire sequence	Auto-Tuning (rotational, stationary)	Frequency upper/lower limit settings	Cooling fan on/off switch	
Slip compensation		Torque compensation	JOG frequency	MODOBUS communication (RS-485 RJ45, max. 115.2 kbps)	DC injection braking at start/stop	
Smart Stall		PID control (with sleep function)	Energy saving control			
Fan Control	230V series Models higher than VFD150CP23A-21 (included) are PWM control ; Models lower than VFD150CP23A-21 (not included) are on/off switch control. 460V series Models higher than VFD150CP43A-21/4EA-21 (included) are PWM control ; Models lower than VFD150CP43A-21/4EA-21(not included) are on/off switch control.					
Protection Characteristics	Motor Protection	Electronic thermal relay protection				
	Over-current Protection	Normal Duty: Over-current protection for 240% rated current Current clamp 『 Normal duty: 170~175% 』				
	Over-voltage Protection	230: drive will stop when DC-BUS voltage exceeds 410V 460: drive will stop when DC-BUS voltage exceeds 820V				
	Over-temperature Protection	Built-in temperature sensor				
	Stall Prevention	Stall prevention during acceleration, deceleration and running independently				
	Restart After Instantaneous Power Failure	Parameter setting up to 20 seconds				
	Grounding Leakage Current Protection	Leakage current is higher than 50% of rated current of the AC motor drive				
International Certifications	  					

Environment for Operation, Storage and Transportation:

DO NOT expose the AC motor drive in harsh environments, such as dust, direct sunlight, corrosive/inflammable gasses, humidity, liquid and vibration environment. The salt in the air must be less than 0.01mg/ cm ² every year.				
Environment	Installation location	IEC60364-1/IEC60664-1 Pollution degree 2, Indoor use only		
	Surrounding Temperature	Storage	-25 °C ~ +70 °C	
		Transportation	-25 °C ~ +70 °C	
	Non-condensation, non-frozen			
	Rated Humidity	Operation	Max. 90%	
		Storage/ Transportation	Max. 95%	
	No condense water			
	Air Pressure	Operation/ Storage	86 to 106 kPa	
		Transportation	70 to 106 kPa	
	Pollution Level	IEC721-3-3		
Operation		Class 3C2; Class 3S2		
Storage		Class 2C2; Class 2S2		
Transportation		Class 1C2; Class 1S2		
No concentrate				
Altitude	Operation	If AC motor drive is installed at altitude 0~1000m, follow normal operation restriction. If it is install at altitude 1000~3000m, decrease 2% of rated current or lower 0.5°C of temperature for every 100m increase in altitude. Maximum altitude for Corner Grounded is 2000m.		
Package Drop	Storage	ISTA procedure 1A(according to weight) IEC60068-2-31		
	Transportation			
Vibration	1.0mm, peak to peak value range from 2Hz to 13.2 Hz; 0.7G~1.0G range from 13.2Hz to 55Hz; 1.0G range from 55Hz to 512 Hz. Comply with IEC 60068-2-6			
Impact	IEC/EN 60068-2-27			
	<p>Under 220lbs (100kg): 15 g peak acceleration, 11 ms duration, half-sine, equipment tested in operating mode.</p> <p>Over 220lbs(100kg): 10 g peak acceleration, 11ms duration, half-sine, equipment tested in non-operating mode.</p> <p>Equipment may be tested in subassemblies.</p>			
Operation Position	Max. allowed offset angle ±10° (under normal installation position)			

Specification for Operation Temperature and Protection Level

Model	Frame	Top cover	Conduit Box	Protection Level	Operation Temperature
VFDxxxxCP23A-21 VFDxxxxCP43A-21	Frame A~C 230V: 0.75~30kW 460V: 0.75~37kW	Remove top cover	Standard conduit plate	IP20/UL Open Type	ND: -10~50°C LD: -10~40°C
		Standard with top cover		IP20/UL Type1/NEMA1	ND: -10~40°C LD: -10~40°C
VFDxxxxCP4EA-21, VFDxxxxCP43C-21	Frame D~H 230V: above 37kW 460V: above 45kW	N/A	With conduit box	IP20/UL Type1/NEMA1	ND: -10~40°C LD: -10~40°C
VFDxxxxCP23A-00 VFDxxxxCP43A-00 VFDxxxxCP43C-00,	Frame D~H 230V: above 37kW 460V: above 45kW	N/A	Without conduit box	IP00 IP20/UL Open Type	ND: -10~50°C LD: -10~40°C (ND =Normal Duty; LD = Light Duty)



10 Digital Keypad

KPC-CC01













KPC-CE01(Optional)








- Communication Interface
RJ-45 (socket) 、 RS-485 interface;
- Installation Method
Embedded type and can be put flat on the surface of the control box. The front cover is water proof.
- Charge the digital keypad for 6 minutes before you use it to program Delta's AC Motor Drive.
- What's new at KPC-CC01 keypad?
 - It supports calendar function of PLC (See Chapter 17 for more information about PLC.)
 - The available editing pages reach the maximum number of pages supported by TP Editor.
 - TP Editor v.140.1 is required
 - It supports VFDSOft to read parameters. Please go to <http://www.delta.com.tw/> to download VFDSOft v1.45.






Descriptions of Keypad Functions

Key	Descriptions			
	Start Operation Key <ol style="list-style-type: none"> 1. It is only valid when the source of operation command is from the keypad. 2. It can operate the AC motor drive by the function setting and the RUN LED will be ON. 3. It can be pressed again and again at stop process. 4. When enabling "HAND" mode, it is only valid when the source of operation command is from the keypad. 			
	Stop Command Key. This key has the highest processing priority in any situation. <ol style="list-style-type: none"> 1. When it receives STOP command, no matter the AC motor drive is in operation or stop status, the AC motor drive needs to execute "STOP" command. 2. The RESET key can be used to reset the drive after the fault occurs. For those faults that can't be reset by the RESET key, see the fault records after pressing MENU key for details. 			
	Operation Direction Key <ol style="list-style-type: none"> 1. This key is only control the operation direction NOT for activate the drive. FWD: forward, REV: reverse. 2. Refer to the LED descriptions for more details. 			
	ENTER Key Press ENTER and go to the next level. If it is the last level then press ENTER to execute the command.			
	ESC Key ESC key function is to leave current menu and return to the last menu. It is also functioned as a return key in the sub-menu.			
	Press menu to return to main menu. Menu content: KPC-CE01 does not support function 5 ~13. <table border="0" style="width: 100%;"> <tr> <td>1. Detail Parameter</td> <td>7. Quick/Simple Setup</td> <td>13. PC Link</td> </tr> </table>	1. Detail Parameter	7. Quick/Simple Setup	13. PC Link
1. Detail Parameter	7. Quick/Simple Setup	13. PC Link		


	2. Copy Parameter 3. Keypad Locked 4. PLC Function 5. Copy PLC 6. Fault Record 8. Display Setup 9. Time Setup 10. Language Setup 11. Startup Menu 12. Main Page
	Direction: Left/Right/Up/Down 1. In the numeric value setting mode, it is used to move the cursor and change the numeric value. 2. In the menu/text selection mode, it is used for item selection.
	Function Key 1. It has the factory setting function and the function can be set by the user. The present factory setting: F1 is JOG function. 2. Other functions must be defined by TPEditor first. TPEditor software V1.03 is available for download at: http://www.delta.com.tw/product/em/download/download_main.asp?act=3&pid=3&cid=3&tpid=3 3. Installation Instruction for TPEditor is on page 10-15 of this chapter.
	HAND ON Key 1. This key is executed by the parameter settings of the source of Hand frequency and hand operation. The factory settings of both source of Hand frequency and hand operation are the digital keypad. 2. Press HAND ON key at stop status, the setting will switch to hand frequency source and hand operation source. Press HAND ON key at operation status, it stops the AC motor drive first (display AHSP warning), and switch to hand frequency source and hand operation source. 3. Successful mode switching for KPC-CE01, “H/A” LED will be on; for KPC-CC01, it will display HAND mode/ AUTO mode on the screen.
	1. This key is executed by the parameter settings of the source of AUTO frequency and AUTO operation. The factory setting is the external terminal (source of operation is 4-20mA). 2. Press Auto key at stop status, the setting will switch to hand frequency source and hand operation source. Press Auto key at operation status, it stops the AC motor drive first (display AHSP warning), and switch to hand frequency source and hand operation source. 3. Successful mode switching for KPC-CE01, “H/A” LED will be off; for KPC-CC01, it will display HAND mode/ AUTO mode on the screen

Descriptions of LED Functions

LED	Descriptions
	Steady ON: operation indicator of the AC motor drive, including DC brake, zero speed, standby, restart after fault and speed search. Blinking: drive is decelerating to stop or in the status of base block. Steady OFF: drive doesn't execute the operation command
	Steady ON: stop indicator of the AC motor drive. Blinking: drive is in the standby status. Steady OFF: drive doesn't execute “STOP” command.
	Operation Direction LED (green: forward running, red: reverse running) Steady ON: drive is in forward running status. Blinking: drive is changing the operation direction. Steady OFF: drive is in reverse running status.
	(Only KPC-CE01 support this function) Setting can be done during operation. HAND LED: When HAND LED is on (HAND mode); when HAND LED is off (AUTO mode).
	(Only KPC-CE01 support this function) Setting can be done during operation. AUTO LED: When AUTO LED is on (AUTO mode); when AUTO LED is off (HAND mode).

CANopen ~"RUN"	RUN LED:	
	LED status	Condition/State
	OFF	CANopen at initial No LED
	Blinking	CANopen at pre-operation 
	Single flash	CANopen at stopped 
ON	CANopen at operation status No LED	
CANopen ~"ERR"	ERR LED:	
	LED status	Condition/ State
	OFF	No Error
	Single flash	One message fail 
	Double flash	Guarding fail or heartbeat fail 
Triple flash	SYNC fail 	
ON	Bus off	


Digital Keypad: KPC-CC01 Function




NOTE

1. Startup page can only display pictures, no flash.
2. When Power ON, it will display startup page then the main page. The main page displays Delta's default setting F/H/A/U, the display order can be set by Pr.00.03 (Startup display). When the selected item is U page, use left key and right key to switch between the items, the display order of U page is set by Pr.00.04 (User display).
3. Charge the digital keypad for 6 minutes before you use it to program Delta's AC Motor Drive.

4. Display Icon




- : present setting
- ▼ : roll down the page for more options



- ▶ : show complete sentence
- Press for complete information





Display item








- MENU
- 1.Detail Parameter
 - 2.Copy Parameter
 - 3.Keypad Locked
 - 4.PLC Function
 - 5. Copy PLC
 - 6. Fault Record
 - 7. Quick/Simple Setup
 - 8. Display Setup
 - 9. Time Setup
 - 10. Language Setup
 - 11. Start-up
 - 12. Main page
 - 13. PC Link

Item 1~4 are the common items for KPC-CC01 &KPC-CE01




1. Detail Parameter

 <p>Press to select.</p>	<p>00 System Pr Content</p>  <p>00-08 Password Set</p>  <p>01-00 The maximum output freq.</p> 
--	--



2. Copy Parameter

	<p>Copy parameters (Pr)</p> <ol style="list-style-type: none"> 4 sets of parameters duplication. When the setting is complete, the date will be written to the copy parameters (Pr) page.  <p>Press </p>  <p>Press  to save or load</p> <p>After selecting save and pressing "ENTER", the parameter setting will be saved in the keypad.</p>
---	---


3. Keypad locked

 <p>Press  to lock</p>	<p>Keypad Locked</p> <p>This function is used to lock the keypad. The main page would not display “keypad locked” when the keypad is locked, however it will display the message” please press ESC and then ENTER to unlock the keypad” when any key is pressed.</p>  <p>Press any key.</p>
---	--

4. PLC Function

 <p>PLC function</p> <ol style="list-style-type: none"> Disable PLC run PLC stop 	<p>When activate and stop PLC function, the PLC status will be displayed on main page of Delta default setting.</p>  <p>The PLC function of KPC-CE01 can only displays:</p> <ol style="list-style-type: none"> PLC0 PLC1 PLC2
--	---

5. Copy PLC




Copy PLC

- ▼ 1.
- 2.
- 3.


Copy PLC


- Duplicate 4 sets of parameters.
- When the setting is complete, the date will be written to the Copy PLC page.



Copy PLC


- ▼ 1.2010/03/14
- 2.
- 3.


Press  to setting menu.




File 1


- ▼ 1. Save to the drive
- 2. Save to the digital display

Press  to select where to save the file


Press 

Press  execute file saving process.

If you select “1.save to the drive” and press ENTER, the file will be saved to the drive.

 **NOTE**

If password protection for WPLSoft editor was set, it is required to enter the password before the file can successfully be saved onto the digital display.




File 1

Password 0000


Input Times 0

6. Fault record



Fault record

- ▼ 1:GFF
- 2:ocA
- 3:oH


Press  to select.

KPC-CE01 does not support this function.

Fault Record


It can accumulate 6 sets of recent fault records.


The first fault code displays in the record is the latest fault. Select the fault code for details on time, date, frequency, current, voltage and DC BUS Volt..



Fault record


- ▼ 1:GFF
- 2:ocA
- 3:oH

Press  to view the current and voltage of the fault



2: ocA

- ▲▼ Time: 19:47:00
- Frequency: 0.00
- Current: 0.00


 **NOTE**

Fault actions of AC motor drive are record and save to KPC-CC01. When KPC-CC01 is removed and apply to another AC motor drive, the previous fault records will not be deleted. The new fault records of the present AC motor drive will accumulate to KPC-CC01.

7. Quick/Simple Setting

Quick setting

▼ 1: V/F mode
3: SVC mode
6: My mode

Press  to select.

Quick Setting:

1. VF Mode
2. VFPG Mode
3. SVC Mode
4. FOC PG Mode
5. TQCPG Mode
6. My Mode

Quick Setting: (CP2000 does NOT have PG card)

1)V/F Mode

V/F mode P00-07

▲ 01. Password Input
▼ 02. Password Setting
03. Control Mode

→

01: Password Input (Decode)

00-07

0

Password Input

0~ 65535

Items

1. Parameter Protection Password Input (P00-07)
2. Parameter Protection Password Setting (P00-08)
3. Control Mode (P00-10)
4. Control of Speed Mode (P00-11)
5. Load Selection (P00-16)
6. Carrier Frequency (P00-17)
7. Source of the Master Frequency Command (AUTO) (P00-20)
8. Source of the Operation Command (AUTO) (P00-21)
9. Stop Method (P00-22)
10. Digital Keypad STOP function (P00-32)
11. Max. Operation Frequency (P01-00)
12. Base Frequency of Motor 1 (P01-01)
13. Max. Output Voltage Setting of Motor 1 (P01-02)
14. Mid-point Frequency 1 of Motor 1 (P01-03)
15. Mid-point Voltage 1 of Motor 1 (P01-04)
16. Mid-point Frequency 2 of Motor 1 (P01-05)
17. Mid-point Voltage 2 of Motor 1 (P01-06)
18. Min. Output Frequency of Motor 1 (P01-07)
19. Min. Output Voltage of Motor 1 (P01-08)
20. Output Frequency Upper Limit (P01-10)
21. Output Frequency Lower Limit (P01-11)
22. Accel. Time 1 (P01-12)
23. Decel Time 1 (P01-13)
24. Over-voltage Stall Prevention (P06-01)
25. Derating Protection (P06-55)
26. Software Brake Level (P07-00)
27. Speed Search during Start-up (P07-12)
28. Emergency Stop (EF) & Force to Stop Selection (P07-20)
29. Filter Time of Torque Command (P07-24)
30. Filter Time of Slip Compensation (P07-25)
31. Torque Compensation Gain (P07-26)
32. Slip Compensation Gain (P07-27)

3)SVC Mode

V/F mode P00-07

▲ 01. Password Input
▼ 02. Password Setting
03. Control Mode

→

01: Password Input (Decode)

00-07

0

Password Input


0~ 65535

Items

1. Parameter Protection Password Input (P00-07)
2. Parameter Protection Password Setting (P00-08)
3. Control Mode (P00-10)
4. Control of Speed Mode (P00-11)
5. Load Selection (P00-16)
6. Carrier Frequency (P00-17)
7. Source of the Master Frequency Command (AUTO) (P00-20)

8. Source of the Operation Command (AUTO) (P00-21)
9. Stop Method (P00-22)
10. Digital Keypad STOP function (P00-32)
11. Max. Operation Frequency (P01-00)
12. Base Frequency of Motor 1 (P01-01)
13. Max. Output Voltage Setting of Motor 1 (P01-02)
14. Min. Output Frequency of Motor 1 (P01-07)
15. Min. Output Voltage of Motor 1 (P01-08)
16. Output Frequency Upper Limit (P01-10)
17. Output Frequency Lower Limit (P01-11)
18. Accel. Time 1 (P01-12)
19. Decel Time 1 (P01-13)
20. Full-load Current of Induction Motor 1 (P05-01)
21. Rated Power of Induction Motor 1 (P05-02)
22. Rated Speed of Induction Motor 1 (P05-03)
23. Pole Number of Induction Motor 1 (P05-04)
24. No-load Current of Induction Motor 1 (P05-05)
25. Over-voltage Stall Prevention (P06-01)
26. Over-current Stall Prevention during Acceleration (P06-03)
27. Derating Protection (P06-55)
28. Software Brake Level (P07-00)
29. Emergency Stop (EF) & Force to Stop Selection (P07-20)
30. Filter Time of Torque Command (P07-24)
31. Filter Time of Slip Compensation (P07-25)
32. Slip Compensation Gain (P07-27)


6) My Mode



My mode:

It can save 01~32 sets of parameters (Pr).


1



Press F4 and save to my mode.


Click F4 in parameter setting page, the parameter will save to My Mode. To delete or correct the parameter, enter this parameter and click the "DEL" on the bottom right corner.

2







The parameter (Pr) will be displayed in My mode if it is properly saved.

To correct or to delete this Pr. clicks DEL.










Press F4 to delete this Pr. Setting in My Mode.


8. Display setup

 <p>Press  to enter the setting menu.</p>	<p>1. Contrast Adjustment</p>  <p>Adjust setting value</p> <p>2. Back-lighted Time</p>  <p>Adjust setting value</p>
---	---


9. Time setting

	<p>Enter time setup page, "9" will continue to blink</p> <p>  move to left / right</p> <p>  increase / decrease the value</p> <p>Press  to confirm.</p> <p> NOTE When the digital keypad is removed, the time setting will be in standby status for 7 days. After this period, the time needs to be reset.</p>
---	--




10. Language setup

	<p>Language selection.</p>
---	----------------------------





11. Startup Page Setting

	<ol style="list-style-type: none"> Default picture 1 DELTA LOGO Default picture 2 DELTA Text User defined: optional accessory is require (TPEditor & USB/RS-485 Communication Interface-IFD6530) Install an editing accessory would allow users to design their own start-up page. If editor accessory is not installed, "user defined" option will display a blank page. <p><u>USB/RS-485 Communication Interface-IFD6530</u> Please refer to Chapter 07 Optional Accessories for more detail.</p> <p><u>TPEditor</u> TPEditor Installation Instruction is on page 10-16 and TPEditor V1.03 is available for download at: http://www.delta.com.tw/product/em/download/download_main.asp?act=3&pid=3&cid=3&tpid=3</p>
---	---

12. Main page



 <p>Press  to select.</p>	<p>1. Default page Default picture and editable picture are available upon selection.</p>  <p>F 600.00Hz >>> H >>> A >>> U (circulate)</p> <p>2. User defined: optional accessory is require (TPEditor & USB/RS-485 Communication Interface-IFD6530) Install an editing accessory would allow users to design their own start-up page. If editor accessory is not installed, "user defined" option will display a blank page.</p> <p><u>USB/RS-485 Communication Interface-IFD6530</u> Please refer to Chapter 07 Optional Accessories for more detail.</p> <p><u>TPEditor</u> TPEditor Installation Instruction is on page 10-16 and TPEditor V1.03 is available for download at: http://www.delta.com.tw/product/em/download/download_main.asp?act=3&pid=3&cid=3&tpid=3</p>
---	--

13. PC Link

 <p>Press ENTER</p> 	<p>The function of PC Link is to establish a connection with computer to download the page for user defined editing. After enter to PC Link page, check if the connection of KPC-CC01 and computer is successfully establish, then press enter to go to next page and wait for communication response.</p> <p>1. If the connection failed, the screen will show "Time Out".</p>  <p>2. If the connection succeeds, the screen page will show "Downloading". When the download is done, it returns to MENU page.</p>  <p>3. In order to set the start-up page and main page in the format user defined, user must check the user define option for start-up page and main page. If the user define page for editing has not yet downloaded to KPC-CC01, the start-up page and main page will display as blank.</p>
---	---

Other display

When fault occur, the menu will display:



1. Press ENTER and start RESET. If still no response, please contact local distributor or return to the factory. To view the fault DC BUS voltage, output current and output voltage, press "MENU"→"Fault Record".
2. Press ENTER again, if the screen returns to main page, the fault is clear.
3. When fault or warning message appears, backlight LED will blinks until the fault or the warning is cleared.

Optional accessory for digital keypad: RJ45 Extension Lead

Part No.	Description
CBC-K3FT	RJ45 Extension Lead 3 feet
CBC-K5FT	RJ45 Extension Lead 5 feet
CBC-K7FT	RJ45 Extension Lead 7 feet
CBC-K10FT	RJ45 Extension Lead 10 feet
CBC-K16FT	RJ45 Extension Lead 16 feet

Note:

- Keypad version 1.00 supports up to 4 main pages. If you download over 4 main pages, it will only support the first 4 downloaded main pages.
- By pressing keypads, you can only switch pages from pages. It doesn't support entering words or images.
- Downloading baud rate supports 9600 bps, 19200 bps and 38400 bps.
- The VFD communication address to read and write are at 0x22xx

Definition of Communication address:

Address	Read/Write	Definition		Description
2200h	R	b15~b0	Output current (A)	
2201h	R	b15~b0	Counter Value (c)	
2202h	R	b15~b0	Actual Frequency (H)	
2203h	R	b15~b0	DC-Bus Voltage (U)	
2204h	R	b15~b0	Output Voltage(A)	
2205h	R	b15~b0	Power Factor Angle (n)	
2206h	R	b15~b0	Output Power(P)	
2207h	R	b15~b0	Actual Motor Speed(r)	
2208h	R	b15~b0	Output Torque (t)	
2209h	R	b15~b0	PG Position (G)	
220Ah	R	b15~b0	Feedback PV value (b)	
220Bh	R	b15~b0	AVI in percentage (1.)	
220Ch	R	b15~b0	ACI in percentage (2.)	
220Dh	R	b15~b0	AUI in percentage (3.)	
220Eh	R	b15~b0	Heat Sink temperature (t.)	
220Fh	R	b15~b0	IBGT temperature (T)	
2210h	R	b15~b0	DI ON/OFF status (i)	
2211h	R	b15~b0	DO ON/OFF status (o)	
2212h	R	b15~b0	Multi-Speed (S)	
2213h	R	b15~b0	DI CPU pin status (i.)	
2214h	R	b15~b0	DO CPU pin status (o.)	
2215h	R	b15~b0	Running number of Encoder (Z)	
2216h	R	b15~b0	Pulse Input Frequency (4)	
2217h	R	b15~b0	Pulse Input Position (4.)	


TPEditor Installation Instruction

1) TPEditor: Setup & Basic Functions


1. Run TPEditor version 1.30



2. Go to File (F) → Click on New. The Window below will pop up. At the device type, click on the drop down menu and choose DELTA VFD-C Inverter. At the TP type, click on the drop down menu and choose VFD-C Keypad. As for File Name, enter TPE0. Now click on OK.



3. You are now at the designing page. Go to Edit (E) → Click on Add a New Page (A) or go to the TP page on the upper right side, right click once on TP page and choose Add to increase one more page for editing. The current firmware of Keypad is version 1.00 and can support up to 4 pages.






4. Download setting. Go to Tool → Communication settings (C) to set up the PC Com Port and Baud Rate. The supporting speeds of Baud rate are 9600bps, 19200bps and 38400bps. The default setting of TP address is 1, please do not modify.




2) Edit Startup Page

1. Click once on the Boot Page on the right hand side of your computer screen or click on View (V) → click on Boot Page (B). Then a blank Boot Page window will pop up. Use the circled items to design your Startup page.






33. Static Text  . Open a blank page, click once on this button  , and then double click on that blank page. The following windows will pop up.





On the right hand side of the Static Text Setting, you can adjust the frame setting, the text direction, the alignment and the font setting. Once you finish all the adjustments that you need.


You can continue to input your text in the blank space of Static Text Setting window. When you finish inputting your text, click on OK to continue your next step or click cancel to abort the current step.

34. Static Bitmap  → Open a blank page, then click once on this button  and then double click on that blank page. The following window will pop up.




Please note that Static Bitmap setting support only images in BMP format. Now choose an image that you need and click open, then that image will appear in the Static Bitmap window.


35. Geometric Bitmap  → As shown in the picture on the left side, there are 11 kinds of geometric bitmap to choose. Open a new blank page then click once on a geometric bitmap icon that you need. Then drag that icon and enlarge it to the size that you need on that blank page. For example, if you drag this icon  to a blank page, you will see the following window.



36. Download---Take the image below as an example. The sentence “Boot page” is a static text; the 11 images below are geometric bitmaps. The image on the right hand side is a Static Bitmap. To upload a start up page, double click to activate “Boot page. Make sure that you have followed the instruction on page 3 to choose the right com port. Then go to “Communication (M)” →Click on “Write Boot Page TP (B).” When you see the pop up message below




Go to the C2000 Keypad, press Menu then keep on pressing the Upward key until you see “PC Link,” then press ENTER once, when you see “Press Enter to PC Link” on the keypad, press the ENTER again. Then click the YES button to begin the upload.



3) Edit Main Page

1. Click on a page under the TP Page to edit or go to View → click on Boot Page to begin to edit main page. The objects available for you to use are in the red circles below.




From left to right: Static Text, ASCII Display, Static Bitmap, Scale, Bar Graph, Button, Clock Display, Units, Numeric Input, 11 geometric bitmaps and different width of lines. The application of Static Text, Static Bitmap, and geometric bitmap is the same as the editing startup page.



2. **Numeric/ASCII Display A):** Go to Objects (O)→Click once on the Numeric/ASCII Display(A)





→Drag to enlarge to reach the size that you need to add objects in the screen where you want to create an object →Double click on the object to set up Related Devices, Frame Setting , Fonts and Alignment.




Related Device: Choose the VFD Communication Port that you need, if you want to read output frequency (H), set the VFD Communication Port to \$2202. For other values, please refer to ACMD ModBus Comm Address List.

3. **Scale Setting** : On the Tool Bar, click on this  for Scale Setting. You can also edit Scale Setting in the Property Window on the right hand side of your computer screen.




- a. Scale Position: Click on the drop down list to choose which position that you need to place a scale.
- b. Scale Side: Click on the drop down list to choose if you want to number your scale from smaller number to bigger number or from big to small. Click OK to accept this setting or click Cancel to abort.
- c. Font Setting: Click on the drop down list to choose the Font setting that you need then click OK to accept the setting or click Cancel to abort.
- d. Value Length: Click on the drop down to choose 16bits or 32 bits. Then click OK to accept the setting or click Cancel to abort.


- e. Main Scale & Sub Scale: In order to divide the whole scale into equal parts, key in the numbers of your choices for main scale and sub scale.
- f. Maximum value & Minimum Value are the numbers on the two ends of a scale. They can be negative numbers but the input numbers are limited by value.
- g. Follow the Scale setting mentioned above; you will have a scale as shown below.





4. Bar Graph setting  :




- a. Related Device: Choose the VFD Communication Port that you need.
- b. Direction Setting: Click on the drop down menu to choose one of the following directions: From Bottom to Top, From Top to Bottom, From Left to Right or From Right to Left.
- c. Maximum Value & Minimum Value: They define the range covered by the maximum value and minimum value. If a value is smaller than or equal to the minimum value, then the bar graph will be blank. If a value is bigger or equal to the maximum value, then the bar graph will be full. If a value is between minimum and maximum value, then the bar graph will be filled proportionally.

5. Button  : Currently this function only allows the Keypad to switch pages; other functions are not yet available. Text input function and Image inserted functions are not yet supported.



Double click on  to open set up window.




- a. <Button Type> allows you set up buttons' functions. But Page Jump is the only supported function currently.
- b. Page Jump setting: After you choose the Page Jump function in the drop down list, you will see this Page Jump Setting Menu
- c. <Function Key> allows you to assign functions to the following keys on the KPC-CC01 keypad: F1, F2, F3, F4, Up, Down, Left and Right. Please note that the Up and Down keys are locked by TPEditor. These two keys cannot be programmed. If you want to program Up and Down keys, go to Tool→Function Key Settings (F) →Re-Define Up/Down Key(R).





d. There are no supported functions other than the setting mentioned above.

6. Clock Display Setting  : Click once on this button  .
Open a new file and click once in that window, you will see the following



In the clock display setting, you can choose to display Time, Day or Date on the Keypad. To adjust time, go to #9 on the Keypad's menu. You can also adjust Frame Setting, Font Setting and Alignment.


7. Unit Measurement  : Click once on this Button:
Open a new file and double click on that window, you will see the following




Choose from the drop down list the Metrology and the Unity Name that you need.
As for Metrology, you have the following choices Length, Square Measure, Volume/Solid Measure, Weight, Speed, Time and Temperature. The unit name changes automatically when you change metrology type.

8. Numeric Input Setting  :


This menu allows you to provide parameters or communication ports and to input numbers.

Click once on this button  .


Open a new file and double click on that window, you will see the following:



- a. Related Device: There are two blank spaces to fill in, one is <Writing> and another one is <Read>. Input the numbers that you want to display and the corresponding numbers of a parameter and that of a communication port. For example, input 012C to Read and Write Parameter P01-44.
- b. OutLine Setting: The Frame setting, Font setting, Vertical Alignment and Horizontal Alignment are the same as mentioned before. Click on the drop down menu and choose the setting that you need.
- c. Function key: The setting here allows you to program keys on the keypad. Press the key on the menu then the corresponding key on the keypad will start to blink, then press Enter to confirm the setting.
- d. Value Type & Value Length: These two factors influence the range of the Minimum and Maximum Value of the Limit Setting. Please note that the corresponding supporting values for C2000 have to be 16bits. The 32bits values are not supported.
- e. Value Setting: This part is set automatically by the keypad itself.
- f. Limit Setting: Input the range the security setting here.
- g. For example, if you set Function Key as F1, Minimum Value as 0 and Maximum Value as 4, then press F1 on Keypad Then you can press Up and Down key on the keypad to increase or decrease the value. Press Enter Key on the keypad to confirm your setting. You can also go to parameter table 01-44 to verify if your input correctly the value.




9. Download TP Page : Press Up or Down key on the keypad until you reach #13 PC Link. Then press Enter on the keypad and you will see the word "Waiting" on keypad's screen. Now choose a page that you have created then go to Communication (M) → Write to TP (W) to start downloading the page to the keypad



When you see the word Completed on the keypad's screen, that means the download is done. Then you can press ESC on the keypad to go back to the menu of the keypad.

11 Summaries of Parameter Settings

00 Drive Parameters

 **NOTE** IM: Induction Motor; PM: Permanent Magnet Motor

Parameter	Function	Setting	Factory Setting
00-00	ID Code of the AC Motor Drive	4: 230V, 1HP (0.75kW) 5: 460 V, 1HP (0.75kW) 6: 230V, 2HP (1.5kW) 7: 460 V, 2HP (1.5kW) 8: 230V, 3HP (2.2kW) 9: 460 V, 3HP (2.2kW) 10: 230V, 5HP (3.7kW) 11: 460 V, 5HP (3.7kW) 12: 230V, 7.5HP (5.5kW) 13: 460 V, 7.5HP (5.5kW) 14: 230V, 10HP (7.5kW) 15: 460V, 10HP (7.5kW) 16: 230V, 15HP (11kW) 17: 460V, 15HP (11kW) 18: 230V, 20HP (15kW) 19: 460V, 20HP (15kW) 20: 230V, 25HP (18.5kW) 21: 460V, 25HP (18.5kW) 22: 230V, 30HP (22kW) 23: 460V, 30HP (22kW) 24: 230V, 40HP (30kW) 25: 460V, 40HP (30kW) 26: 230V, 50HP (37kW) 27: 460V, 50HP (37kW) 28: 230V, 60HP (45kW) 29: 460V, 60HP (45kW) 30: 230V, 75HP (55kW) 31: 460V, 75HP (55kW) 32: 230V, 100HP (75kW) 33: 460V, 100HP (75kW) 34: 230V, 125HP(90kW) 35: 460V, 125HP (90kW) 37: 460V, 150HP (110kW) 39: 460V, 175HP(132kW) 41: 460V, 215HP(160kW) 43: 460V, 250HP(185kW) 45: 460V, 300HP(220kW) 47: 460V, 375HP(280kW) 49: 460V, 425HP(315kW) 51: 460V, 475HP(355kW) 53: 460V, 536HP(400kW) 93: 460V, 5.5HP (4.0kW)	Read Only
00-01	Display AC Motor Drive Rated Current	Display by models	Read Only
00-02	Parameter Reset	0: No function 1: Read only 6: Reset PLC (including CANopen Master Index) 7: Reset CANopen Index (Slave) 9: All parameters are reset to factory settings(base frequency is 50Hz) 10: All parameters are reset to factory settings (base frequency is 60Hz)	0

	Parameter	Function	Setting	Factory Setting
↗	00-03	Start-up Display Selection	0: F (frequency command) 1: H (output frequency) 2: U (multi-function display, see Pr.00-04) 3: A (output current)	0
↗	00-04	Content of Multi-function Display (User Defined)	0: Display output current (A) 1: Display counter value (c) 2: Display actual output frequency (H.) 3: Display DC-BUS voltage (v) 4: Display output voltage (E) 5: Display output power angle (n) 6: Display output power in kW (P) 8: Display estimate output torque % (t) 10: Display PID feedback in % (b) 11: Display AVI1 in % (1.) 12: Display ACI in % (2.) 13: Display AVI2 in % (3.) 14: Display the temperature of IGBT in °C (i.) 15: Display the temperature of heat sink in °C (c.) 16: The status of digital input (ON/OFF) (i) 17: The status of digital output (ON/OFF) (o) 18: Multi-step speed (S) 19: The corresponding CPU pin status of digital input (d.) 20: The corresponding CPU pin status of digital output (0.) 25: Overload counting (0.00~100.00%) (h.) 26: Ground Fault GFF (Unit :%)(G.) 27: DC Bus voltage ripple (Unit: Vdc) (r.) 28: Display PLC data D1043 (C) 30: Display output of user defined (U) 31: H page x Pr.00-05 Display user Gain(K)	3
	00-05	Coefficient Gain in Actual Output Frequency	0~160.00	0
	00-06	Software version	Read Only	###
↗	00-07	Parameter Protection Password Input	0~65535 0~4 : Recording # of times of password attemps	0
↗	00-08	Parameter Protection Password Setting	0~65535 0 : No password protection / password is entered correctly (Pr00-07) 1 : Parameter is locked	0
↗	00-09	Display advanced parameters	Bit 0: Group 0 Bit 1: Group 1 Bit 2: Group 2 Bit 3: Group 3 Bit 4: Group 4 Bit 5: Group 5 Bit 6: Group 6 Bit 7: Group 7 Bit 8: Group 8 Bit 9: Group 9	0

	Parameter	Function	Setting	Factory Setting
	00-11	Velocity Control Mode	0 : VF (V/F control) 2 : SVC (Sensor-Less Vector Control)	0
↗	00-16	Loading mode selection	0 : Light Duty 1 : Normal Duty	0
	00-17	Carrier Frequency (KHz)	Light Duty 1-20HP 2~15KHz 25-60HP 2~10KHz 75-125HP 2~9KHz Normal Duty 1-15HP 2~15KHz 20-50HP 2~10KHz 60-100HP 2~9KHz	8 6 4 2 2 2
	00-18	Reserved		
	00-19	PLC command mask(SOOC, SOOF, SOTC, SOPC)	0~65535	0
↗	00-20	Source of the MASTER Frequency Command (AUTO)	0: Digital keypad 1: RS-485 serial communication 2: External analog input (Pr.03-00) 3: External UP/DOWN terminal 6: CANopen communication card 8: Communication card (no CANopen card)	0
↗	00-21	Source of the Operation Command (AUTO)	0: Digital keypad 1: External analog input (Pr.03-00) 2: RS-485 serial communication 3: External UP/DOWN terminal 5: Communication card (not included CANopen card)	0
↗	00-22	Stop method	0: Ramp to stop 1: Coast to stop	0
↗	00-23	Motor Operating Direction Control	0: Enable forward/reverse 1: Reverse disable 2: Forward disable	0
↗	00-24	Memory of Communication Frequency Command	Read Only	Read Only
	00-25	User Defined Property	Bit 0~3: user defined on decimal places 0000b: no decimal place 0001b: one decimal place 0010b: two decimal place 0011b: three decimal place Bit 4~15: user define on unit 000xh: Hz 001xh: rpm 002xh: % 003xh:kg	0

	Parameter	Function	Setting	Factory Setting
	00-26	Max. User Defined Value	0: Disable 0000b: 0~65535 (No decimal place in Pr.00-25 setting) 0001b: 0.0~6553.5 (One decimal place in Pr.00-25 setting) 0010b: 0.0~655.35(Two decimal place in Pr.00-25 setting) 0011b: 0.0~65.536 (Three decimal place in Pr.00-25 setting)	0
	00-27	User Defined Value	Read Only	Read Only
	00-28	Reserved	65535	0
	00-29	Reserved	65535	0
↗	00-30	Source of the Master Frequency Command (HAND)	0: Digital keypad 1: RS-485 serial communication 2: External analog input (Pr.03-00) 3: External UP/DOWN terminal 6: CANopen communication card 8: Communication card (no CANopen card)	0
↗	00-31	Source of the Operation Command (HAND)	0: Digital keypad 1: External terminals. Keypad STOP disabled. 2: RS-485 serial communication. Keypad STOP disabled. 3: CANopen communication card 5: Communication card (not include CANopen card)	
	00-32	Digital Keypad STOP Function	0: STOP key disable 1: STOP key enable	0
	00-33 ~ 00-47	Reserved		
	00-48	Display Filter Time (Current)	0.001 ~ 65.535	0.100
	00-49	Display Filter Time (Keypad)	0.001 ~ 65.535	0.100
	00-50	Software Version (date)	0~65535	Read Only

01 Basic Parameter

Parameter	Explanation	Settings	Factory Setting
01-00	Max. Operating Frequency (Hz)	50.00~600.00Hz	60.00/ 50.00
01-01	Motor1: Max Output Frequency(Hz)	0.00~600.00Hz	60.00/ 50.00
01-02	Motor1: Max Output Voltage (V)	230V models: 0.0V~255.0V 460V models: 0.0V~510.0V	220.0 400.0
01-03	Mid-point Frequency 1 of Motor 1	0.00~600.00Hz	3.0
✓ 01-04	Mid-point Voltage 1 of Motor 1	230V: 0.0V~240.0V 460V: 0.0V~480.0V	110 220
01-05	Mid-point Frequency 2 of Motor 1	0.00~600.00Hz	0.50
✓ 01-06	Mid-point Voltage 2 of Motor 1	230V: 0.0V~240.0V 460V: 0.0V~480.0V	4.0 8.0
01-07	Min. Output Frequency of Motor 1	0.00~600.00Hz	0.00
✓ 01-08	Min. Output Voltage of Motor 1	230V: 0.0V~240.0V 460V: 0.0V~480.0V	0.0 0.0
01-09	Start-Up Frequency	0.00~600.00Hz	0.50
✓ 01-10	Output Frequency Upper Limit	0.00~600.00Hz	600.00
✓ 01-11	Output Frequency Lower Limit	0.00~600.00Hz	0
✓ 01-12	Accel. Time 1	Pr.01-45=0: 0.00~600.00 second Pr.01-45=1: 0.00~6000.0 second	10.00 10.0
✓ 01-13	Decel. Time 1	Pr.01-45=0: 0.00~600.00 second Pr.01-45=1: 0.00~6000.0 second	10.00 10.0
✓ 01-14	Accel. Time 2	Pr.01-45=0: 0.00~600.00 second Pr.01-45=1: 0.00~6000.0 second	10.00 10.0
✓ 01-15	Decel. Time 2	Pr.01-45=0: 0.00~600.00 second Pr.01-45=1: 0.00~6000.0 second	10.00 10.0
✓ 01-16	Accel. Time 3	Pr.01-45=0: 0.00~600.00 second Pr.01-45=1: 0.00~6000.0 second	10.00 10.0
✓ 01-17	Decel. Time 3	Pr.01-45=0: 0.00~600.00 second Pr.01-45=1: 0.00~6000.0 second	10.00 10.0
✓ 01-18	Accel. Time 4	Pr.01-45=0: 0.00~600.00 second Pr.01-45=1: 0.00~6000.0 second	10.00 10.0
✓ 01-19	Decel. Time 4	Pr.01-45=0: 0.00~600.00 second Pr.01-45=1: 0.00~6000.0 second	10.00 10.0
✓ 01-20	JOG Acceleration Time	Pr.01-45=0: 0.00~600.00 second Pr.01-45=1: 0.00~6000.0 second	10.00 10.0
✓ 01-21	JOG Deceleration Time	Pr.01-45=0: 0.00~600.00 second Pr.01-45=1: 0.00~6000.0 second	10.00 10.0
✓ 01-22	JOG Frequency	0.00~600.00Hz	6.00

Parameter	Explanation	Settings	Factory Setting
01-23	Frequency of 1st Acceleration / Deceleration & Frequency of 4th Acceleration / Deceleration.	0.00~600.00Hz	0.00
01-24	S-curve for Acceleration Departure Time 1	Pr.01-45=0: 0.00~25.00 second Pr.01-45=1: 0.0~250.0 second	0.20 0.2
01-25	S-curve for Acceleration Arrival Time 2	Pr.01-45=0: 0.00~25.00 second Pr.01-45=1: 0.0~250.0 second	0.20 0.2
01-26	S-curve for Deceleration Departure Time 1	Pr.01-45=0: 0.00~25.00 second Pr.01-45=1: 0.0~250.0 second	0.20 0.2
01-27	S-curve for Deceleration Arrival Time 2	Pr.01-45=0: 0.00~25.00 second Pr.01-45=1: 0.0~250.0 second	0.20 0.2
01-28	Upper limit of Frequency 1 setting not allowed	0.00~600.00Hz	0.00
01-29	Lower limit of Frequency 1 setting not allowed	0.00~600.00Hz	0.00
01-30	Upper limit of Frequency 2 setting not allowed	0.00~600.00Hz	0.00
01-31	Lower limit of Frequency 2 setting not allowed	0.00~600.00Hz	0.00
01-32	Upper limit of Frequency 3 setting not allowed	0.00~600.00Hz	0.00
01-33	Lower limit of Frequency 3 setting not allowed	0.00~600.00Hz	0.00
01-34	Zero-speed Mode	0: Output waiting 1: Zero-speed operation 2: Output at Minimum Frequency (the 4 th output frequency)	0
01-35	Motor 2: Max Output Frequency (Hz)	0.00~600.00Hz	60.00/ 50.00
01-36	Motor 2: Max Output Voltage (V)	230V models: 0.0V~255.0V 460V models: 0.0V~510.0V	200.0 400.0
01-37	Mid-point Frequency 1 of Motor 2	0.00~600.00Hz	3
01-38	Mid-point Voltage 1 of Motor 2	230V models: 0.0V~240.0V 460V models: 0.0V~480.0V	110/ 220
01-39	Mid-point Frequency 2 of Motor 2	0.00~600.00Hz	0.50
01-40	Mid-point Voltage 2 of Motor 2	230V models: 0.0V~240.0V 460V models: 0.0V~480.0V	4.0 8.0
01-41	Min. Output Frequency of Motor 2	0.00~600.00Hz	0.00
01-42	Min. Output Voltage of Motor 2	230V models: 0.0V~240.0V 460V models: 0.0V~480.0V	0.0 0.0
01-43	V/f Curve Selection	0: normal V/F curve 1: Curve to the power of 1.5 2: Curve to the power of 2	0

	Parameter	Explanation	Settings	Factory Setting
↗	01-44	Optimal Acceleration/Deceleration Setting	0: Linear accel. /decel. 1: Auto accel., Linear decel. 2: Linear accel., Auto decel. 3: Auto accel. / decel. 4: Linear, stall prevention by auto accel./decel. (limit by Pr.01-12 to 01-21)	0
	01-45	Time Unit for Accel. /Decel. and S Curve	0: Unit: 0.01 sec 1: Unit: 0.1sec	0
	01-46	CANopen Quick Stop Time	Pr. 01-45=0: 0.00~600.00 sec Pr. 01-45=1: 0.0~6000.0 sec	1.00
	01-47 ~ 01-50	Reserved		

02 Digital Input/Output Parameters

Parameter	Explanation	Settings	Factory Setting
02-00	2-wire/3-wire Operation Control	0: 2-wire mode, power on for operation control 1: 2-wire mode 2, power on for operation control 2: 3-wire, power on for operation control	0
02-01	Multi-function Input Command 1 (MI1)	0: No function	1
02-02	Multi-function Input Command 2 (MI2)	1: Multi-step speed command 1/multi-step position command 1	2
02-03	Multi-function Input Command 3 (MI3)	2: Multi-step speed command 2/multi-step position command 2	3
02-04	Multi-function Input Command 4 (MI4)	3: Multi-step speed command 3/multi-step position command 3	4
02-05	Multi-function Input Command 5 (MI5)	4: Multi-step speed command 4/multi-step position command 4	0
02-06	Multi-function Input Command 6 (MI6)	5: Reset	0
02-07	Multi-function Input Command 7 (MI7)	6: JOG command (By KPC-CC01 or external control)	0
02-08	Multi-function Input Command 8 (MI8)	7: Acceleration/deceleration speed inhibit	0
02-26	Input terminal of I/O extension card (MI9)	8: The 1 st , 2 nd acceleration/deceleration time selection	0
02-27	Input terminal of I/O extension card (MI10)	9: The 3 rd , 4 th acceleration/deceleration time selection	0
02-28	Input terminal of I/O extension card (MI12)	10: EF Input (Pr.07-20)	0
02-29	Input terminal of I/O extension card (MI12)	11: B.B input from external (Base Block)	0
02-30	Input terminal of I/O extension card (MI13)	12: Output stop	0
02-31	Input terminal of I/O extension card (MI14)	13: Cancel the setting of optimal accel. /decel. time 14: Switch between motor 1 and motor 2 15: Operation speed command from AVI1 16: Operation speed command from ACI 17: Operation speed command from AVI2 18: Emergency stop (Pr.07-20) 19: Digital up command 20: Digital down command 21: PID function disabled	0
		22: Clear counter 23: Input the counter value (MI6) 24: FWD JOG command 25: REV JOG command 27: ASR1/ASR2 selection 28: Emergency stop (EF1) 29: Signal confirmation for Y-connection 30: Signal confirmation for Δ-connection 38: Disable EEPROM write function 40: Force coast to stop 41: HAND switch 42: AUTO switch 44~47 : Reserved 49: Drive enable	

Parameter	Explanation	Settings	Factory Setting
		51: Selection for PLC mode bit0	
		52: Selection for PLC mode bit1	
		53: Trigger CANopen quick stop	
		54: UVW Magnetic Contactor On/Off	
		55: Brake Released Signal	
		56: Max. Reverse Disabled	
		57: Max Forward Disabled	
		58: Enable fire mode (with RUN Command)	
		59: Enable fire mode (without RUN Command)	
		60: All motors disabled	
		61: Motor#1 disabled	
		62: Motor#2 disabled	
		63: Motor#3 disabled	
		64: Motor#4 disabled	
		65: Motor #5 disabled	
		66: Motor#6 disabled	
		67: Motor#7 disabled	
		68: Motor#8 disabled	
		69~70 : Disabled	
✓ 02-09	UP/DOWN key mode	0: up/down by the accel. /decel. time 1: up/down constant speed (Pr.02-10)	0
✓ 02-10	Constant speed. The Accel. /Decel. Speed of the UP/DOWN Key	0.01~1.00Hz/ms	0.01
✓ 02-11	Multi-function Input Response Time	0.000~30.000 seconds	0.005
✓ 02-12	Multi-function Input Mode Selection	0~65535 (0:N.O. ; 1 : N.C.)	0
✓ 02-13	RLY1: Multi Output Terminal	0 : No function	11
✓ 02-14	RLY2: Multi Output Terminal	1: Operation Indication	1
✓ 02-15	RLY3: Multi Output Terminal	2: Operation speed attained	0
✓ 02-16~ 02-17	Reserved		
✓ 02-36	Expansion Card Output Terminal (MO3)	4: Desired frequency attained 2 (Pr.02-24)	0
✓ 02-37	Expansion Card Output Terminal (MO4)	5: Zero speed (Frequency command)	0
✓ 02-38	Expansion Card Output Terminal (MO5)	6: Zero speed, include STOP(Frequency command)	0
✓ 02-39	Output terminal of the I/O extension card (MO6)	7: Over torque 1	0
✓ 02-40	Output terminal of the I/O extension card (MO7)	8: Over torque 2	0
✓ 02-41	Output terminal of the I/O extension card (MO8)	9: Drive is ready	0

Parameter	Explanation	Settings	Factory Setting
✓ 02-42	Output terminal of the I/O extension card (MO9)	10: Low voltage warning (LV) (Pr.06-00)	0
✓ 02-43	Output terminal of the I/O extension card (MO10)	11: Malfunction indication	0
✓ 02-44	Output terminal of the I/O extension card (MO11)	12: Mechanical brake release(Pr.02-32)	0
✓ 02-45	Output terminal of the I/O extension card (MO12)	13: Overheat warning (Pr.06-15)	0
✓ 02-46	Output terminal of the I/O extension card (MO13)	14: Software brake signal indication(Pr.07-00)	0
		15: PID feedback error	
		16: Slip error (oSL)	
		17: Terminal count value attained, does not return to 0 (Pr.02-20)	
		18: Preliminary count value attained, returns to 0 (Pr.02-19)	
		19: Base mask	
		20: Warning output	
		21: Over voltage warning	
		22: Over-current stall prevention warning	
		23: Over-voltage stall prevention warning	
		24: Operation mode indication	
		25: Forward command	
		26: Reverse command	
		27: Output when current \geq Pr.02-33 (\geq 02-33)	
		28: Output when current \leq Pr.02-33 (\leq 02-33)	
		29: Output when frequency \geq Pr.02-34 (\geq 02-34)	
		30: Output when frequency \leq Pr.02-34 (\leq 02-34)	
		31: Y-connection for the motor coil	
		32: Δ -connection for the motor coil	
		33: Zero speed (actual output frequency)	
		34: Zero speed include stop(actual output frequency)	
		35: Error output selection 1(Pr.06-23)	
		36: Error output selection 2(Pr.06-24)	
		37: Error output selection 3(Pr.06-25)	
		38: Error output selection 4(Pr.06-26)	
		40: Speed attained (including Stop)	
		44: Low current output	
		45: UVW Magnetic Contactor enabled	
		47: Brake output closed	
		50: Output for CANopen control	
		51: Output for RS485	
		52: Output for communication card	
		53: Fire mode indication	
		54: Bypass fire mode indication	
		55: Motor #1 Output	
		56: Motor #2 Output	
		57: Motor #3 Output	
		58: Motor#4 Output	
		59: Motor#5 Output	
		60: Motor #6 Output	

Parameter	Explanation	Settings	Factory Setting	
		61: Motor#7 Output		
		62: Motor#8 Output		
✓	02-18	Multi-function output direction	0~65535 (0 : N.O. ; 1 : N.C.)	0
✓	02-19	Terminal counting value attained	0~65500	0
✓	02-20	Preliminary counting value attained (not return to 0)	0~65500	0
✓	02-21	Digital Output Gain (DFM)	1~166	1
✓	02-22	Desired Frequency Attained 1	0.00~600.00Hz	60.00/ 50.00
✓	02-23	The Width of the Desired Frequency Attained 1	0.00~600.00Hz	2.00
✓	02-24	Desired Frequency Attained 2	0.00~600.00Hz	60.00/ 50.00
✓	02-25	The Width of the Desired Frequency Attained 2	0.00~600.00Hz	2.00
	02-32	Brake Delay Time	0.000~65.000 秒	0.000
✓	02-33	Output Current Level Setting for Multi-function External Terminals	0~100%	0
✓	02-34	Output frequency setting for multi-function output terminal	0.00~600.00Hz	0.00
✓	02-35	External Operation Control Selection after Reset and Activate	0: Disabled 1: Drive runs if run command exists after reset	0
✓	02-47	Zero-speed Level of Motor	0~65535 rpm	0
✓	02-48	Max. Frequency of Resolution Switch	0.01~600.00Hz	60.00
✓	02-49	Switch the delay time of Max. output frequency	0.000~65.000 seconds	0.000
✓	02-50	Status of Multi-function Input Terminal	Monitor the status of multi-function input terminals	Read Only
✓	02-51	Status of Multi-function Output Terminal	Monitor the status of multi-function output terminals	Read Only
	02-52	Display External Output terminal occupied by PLC	Monitor the status of PLC input terminals	Read Only
	02-53	Display Analog Input Terminal occupied by PLC	Monitor the status of PLC output terminals	Read Only
	02-54	Display the Frequency Command Memory of External Terminal	Read Only	Read Only

03 Analog Input/Output Parameter

	Parameter	Explanation	Settings	Factory Setting
✓	03-00	Analog Input 1 (AVI1)	0: No function 1: Frequency command (torque limit under torque control mode) 4: PID target value 5: PID feedback signal 6: PTC thermistor input value 11: PT100 thermistor input value 12~17: Reserved	1
✓	03-01	Analog Input 2(ACI)		
✓	03-02	Analog Input 3 (AVI2)		
✓	03-03	AVI1 Analog Input Bias	-100.0~100.0%	0
✓	03-04	ACI Analog Input Bias	-100.0~100.0%	0
✓	03-05	AVI2 Analog Positive Voltage Input Bias	-100.0~100.0%	0
✓	03-06	Reserved		
✓	03-07	AVI1 positive/negative bias mode	0: No bias 1: Lower than bias=bias 2: Greater than bias=bias 3: The absolute value of the bias voltage while serving as the center 4: Serve bias as the center	0
✓	03-08	ACI positive/negative bias mode		
✓	03-09	AVI2 positive/negative bias mode		
	03-10	Reserved		
✓	03-11	Analog Input Gain 1 (AVI1)	-500.0~500.0% -500.0~500.0% -500.0~500.0%	100.0 100.0 100.0
✓	03-12	Analog Input Gain 2 (ACI)		
✓	03-13	Analog Positive Input Gain 3 (AVI2)		
✓	03-14	Reserved		
✓	03-15	Analog Input Filter Time (AVI1)	0.00~20.00 seconds	0.01
✓	03-16	Analog Input Filter Time (ACI)	0.00~20.00 seconds	0.01
✓	03-17	Analog Input Filter Time (AVI2)	0.00~20.00 seconds	0.01
✓	03-18	Addition Function of the Analog Input	0: Disable addition function (AVI1, ACI, AVI2) 1: Enable addition function	0
✓	03-19	Loss of the ACI Signal	0: Disable 1: Continue operation at the last frequency 2: Decelerate to 0Hz 3: Stop immediately and display ACE	0
✓	03-20	Multi-function Output 1 (AFM1)	0: Output frequency (Hz)	0
✓	03-23	Multi-function Output 2 (AFM2)	1: Frequency command (Hz)	0
			2: Motor speed (Hz)	
			3: Output current (rms)	
			4: Output voltage	
			5: DC Bus voltage	

Parameter	Explanation	Settings	Factory Setting
		6: Power factor	
		7: Power	
		9 : AVI1 %	
		10 : ACI %	
		11 : AVI2 %	
		20: CANopen analog output	
		21: RS485 analog output	
		22: Communication card analog output	
		23: Constant voltage output	
✎ 03-21	Gain for Analog Output 1 (AFM1)	0~500.0%	100
✎ 03-22	Analog Output 1 Value in REV Direction (AFM1)	0: Absolute output voltage 1: Reverse output 0V; Positive output 0-10V 2: Reverse output 5-0V; Positive output 5-10V	0
✎ 03-24	Gain for Analog Output 2 (AFM2)	0~500.0%	100
✎ 03-25	Analog Output 2 Value in REV Direction (AFM2)	0: Absolute output voltage 1: Output 0V in REV direction; output 0-10V in FWD direction 2: Output 5-0V in REV direction; output 5-10V in FWD direction	0
✎ 03-26	Display Low pass Filter (AFM 1)	0.001~65.535 seconds	0
✎ 03-27	Display Low pass Filter (AFM 2)	0.001~65.535 seconds	0
✎ 03-28	AVI1 Selection	0: 0-10V 1: 0-20mA 2: 4-20mA	0
✎ 03-29	ACI Selection	0: 4-20mA 1: 0-10V 2: 0-20mA	0
✎ 03-30	Status of PLC Output Terminal	Monitor the status of PLC output terminals	Read Only
03-31	AFM2 0-20mA Output Selection	0: 0-20mA 1: 4-20mA	0
03-32	AFM1 DC output setting level	0.00~100.00%	0
03-33	AFM2 DC Output Setting Level	0.00~100.00%	0
03-34~03-49	Reserved	Reserved	
03-50	AI calculated selection	0~7	0
03-51	AVI Point1 - voltage	0~10.00 / 0~20.00	0
03-52	AVI Point 1- percentage	0~100%	0
03-53	AVI Point 2- voltage	0~10.00 / 0~20.00	5.00
03-54	AVI Point2-percent	0~100%	50
03-55	AVI Point 3 - voltage	0~10.00 / 0~20.00	10.00
03-56	AVI Point 3- percent	0~100%	100

Parameter	Explanation	Settings	Factory Setting
03-57	ACI Point 1 – voltage	0~10.00 / 0~20.00	4.00
03-58	ACI Point 1- percent	0~100%	0
03-59	ACI Point 2 – voltage	0~10.00 / 0~20.00	12.00
03-60	ACI Point2 - percent	0~100%	50
03-61	ACI Point 3 – voltage	0~10.00 / 0~20.00	20.00
03-62	ACI Point3 - percent	0~100%	100
03-63	AUI Point1 - voltage	0~10.00V	0
03-64	AUI Point 2- percent	0~100%	0
03-65	AUI Point 2- voltage	0~10.00V	5.00
03-66	AUI Point2 -percent	0~100%	50
03-67	AUI Point 3- voltage	0~10.00V	10.00
03-68	AUI Point 3 - percent	0~100%	100

04 Multi-step Speed Parameters

	Parameter	Explanation	Settings	Factory Setting
↗	04-00	1st Step Speed Frequency	0.00~600.00Hz	0
↗	04-01	2nd Step Speed Frequency	0.00~600.00Hz	0
↗	04-02	3rd Step Speed Frequency	0.00~600.00Hz	0
↗	04-03	4th Step Speed Frequency	0.00~600.00Hz	0
↗	04-04	5th Step Speed Frequency	0.00~600.00Hz	0
↗	04-05	6th Step Speed Frequency	0.00~600.00Hz	0
↗	04-06	7th Step Speed Frequency	0.00~600.00Hz	0
↗	04-07	8th Step Speed Frequency	0.00~600.00Hz	0
↗	04-08	9th Step Speed Frequency	0.00~600.00Hz	0
↗	04-09	10th Step Speed Frequency	0.00~600.00Hz	0
↗	04-10	11th Step Speed Frequency	0.00~600.00Hz	0
↗	04-11	12th Step Speed Frequency	0.00~600.00Hz	0
↗	04-12	13th Step Speed Frequency	0.00~600.00Hz	0
↗	04-13	14th Step Speed Frequency	0.00~600.00Hz	0
↗	04-14	15th Step Speed Frequency	0.00~600.00Hz	0

05 Motor Parameters

Parameter	Explanation	Settings	Factory Setting
05-00	Motor Auto Tuning	0: No function 1: Measure induction motor in dynamic status (motor spinning) (Rs, Rr, Lm, Lx, no-load current) 2: Measure induction motor in static status (motor not spinning)	0
05-01	Full-Load current of Induction Motor 1 (Amps)	10~120% of the drive's rated current	0
05-02	Rated Power of Induction Motor 1 (kW)	0~655.35kW	0
05-03	Rated Rotational Speed of Induction Motor 1 (rpm)	0~65535 1710(60Hz 4 poles) ; 1410(50Hz 4 poles)	1710
05-04	Pole Number of Induction Motor 1	2~20	4
05-05	No Load Current of Induction Motor 1 (Amps)	0~ Pr.05-01 of factory setting	0
05-06	Stator Resistance (Rs) of Induction Motor 1	0~65535mΩ	0
05-07	Rotor Resistance (Rr) of Mo1	0~65535mΩ	0
05-08	Magnetizing Inductance (Lm) og Induction Motor 1	0~65535mH	0
05-09	Stator Inductance (Lx) of Induction Motor 1	0~65535mH	0
05-10 ~ 05-12	Reserved		
05-13	Rated Current of Induction Motor 2 (Amps)	0~65535	0
05-14	Rated Power of Induction Motor 2 (kW)	0~655.35kW	0
05-15	Rated Rotational Speed of Induction Motor 2 (rpm)	0~65535 1710(60Hz 4poles) ; 1410(50Hz 4 poles)	1710
05-16	Pole Number of Induction Motor 2	2~20	4
05-17	No-load Current of Induction Motor 2 (A)	0~Parameter05-01 factory setting	0
05-18	Stator Resistance (Rs) of Induction Motor 2	0~65.535Ω	0
05-19	Rotor Resistance (Rr) of Motor 2	0~65.535Ω	0
05-20	Magnetizing Inductance (Lm) og Induction Motor 2	0~65535mH	0
05-21	Stator Inductance (Lx) of Induction Motor 2	0~65535mH	0
05-22	Induction Motor 1/ Motor 2 Selection	1: motor 1 2: motor 2	1
05-23	Frequency for Y-connection/△-connection Switch of Induction Motor	0.00~600.00Hz	60.00

Parameter	Explanation	Settings	Factory Setting
05-24	Y-connection/ Δ -connection Switch of Induction Motor	0 : Disable 1 : Enable	0
05-25	Delay Time for Y-connection/ Δ -connection Switch of Induction Motor	0.000~60.000 seconds	0.200
05-26 ~ 05-30	Reserved		
05-31	Accumulated Motor Operation Time (minutes)	00~1439	0
05-32	Accumulative Motor Operation Time (day)	00~65535	0
05-33	Induction Motor and Permanent Magnet Motor Selection	0: IM 1: PM	0
05-34	Full Load current of Permanent Magnet Motor(A)	0.0~6553.5Amps	0
05-35	Rated Power of Permanent Magnet Motor (kW)	0.00~655.35kW	0
05-36	Rated Rotational Speed of Permanent Magnet Motor (rpm)	0~65535 rpm	2000
05-37	Pole number of Permanent Magnet Motor	0~65535	10
05-38	Inertia of Permanent Magnet Motor	0~6553.5 kg.cm ²	0
05-39	Stator Resistance of PM Motor	0.000~65.535 Ω	0.000
05-40	Permanent Magnet Motor Ld	0.00~655.35mH	0
05-41	Permanent Magnet Motor Lq	0.00~655.35mH	0
05-42	Offset angle of PM Motor pole	0.0~360.0	0
05-43	Ke parameter of PM Motor	0~65535 (Unit: V/1000rpm)	0

06 Protection Parameters

	Parameter	Explanation	Settings	Factory Setting
↗	06-00	Low Voltage Level	230V : 160.0~220.0Vdc 460V : 320.0~440.0Vdc	180 360
↗	06-01	Over-voltage Stall Prevention	230V : 350.0~450.0Vdc 460V : 700.0~900.0Vdc	380.0 760.0
↗	06-02	Reserved		
↗	06-03	Over-current Stall Prevention during Acceleration	Normal duty: 0~130%(100%: drive's rated current); Light duty: 0~130%(100%: drive's rated current)	Normal duty:120; Light duty:120
↗	06-04	Over-current Stall Prevention during Operation	Normal Load: 0~130%(100%: drive's rated current); Light duty: 0~130%(100%: drive's rated current)	Normal duty:120; Light duty:120
↗	06-05	Accel. /Decel. Time Selection of Stall Prevention at Constant Speed	0: by current accel/decel time 1: by the 1st accel/decel time 2: by the 2nd accel/decel time 3: by the 3rd accel/decel time 4: by the 4th accel/decel time 5: by auto accel/decel	0
↗	06-06	Over-torque Detection Selection (OT1)	0: No function 1: Over-torque detection during constant speed operation, continue to operate after detection 2: Over-torque detection during constant speed operation, stop operation after detection 3: Over-torque detection during operation, continue to operate after detection 4: Over-torque detection during operation, stop operation after detection	0
↗	06-07	Over-torque Detection Level (OT1)	10~200% (100%: drive's rated current)	120
↗	06-08	Over-torque Detection Time (OT1)	0.0~60.0 seconds	0.1
↗	06-09	Over-torque Detection Selection (OT2)	0: No function 1: Over-torque detection during constant speed operation, continue to operate after detection 2: Over-torque detection during constant speed operation, stop operation after detection 3: Over-torque detection during operation, continue to operation after detection 4: Over-torque detection during operation, stop operation after detection	0
↗	06-10	Over-torque Detection Level (OT2)	10~200% (100%: drive's rated current)	120
↗	06-11	Over-torque Detection Time (OT2)	0.0~60.0 seconds	0.1
↗	06-12	Maximum Torque Limit	0~200% (100%: drive's rated current)	150%
↗	06-13	Electronic Thermal Relay Selection (Motor 1)	0: Motor with constant torque output 1: Motor with variable torque output 2: Electronic Thermal Relay disabled	2
↗	06-14	Electronic Thermal Characteristic for Motor 1	30.0~600.0 seconds	60.0

	Parameter	Explanation	Settings	Factory Setting
✓	06-15	Heat Sink Over-heat (OH) Warning	0.0~110.0℃	85.0
✓	06-16	Stall Prevention Limit Level	0~100% (Parameter06-03 , Parameter06-04)	50
	06-17	Current Error Record	0: No fault record	0
	06-18	Second Most Recent Error Record	1: Over-current during acceleration (ocA)	0
	06-19	Third Most Recent Error Record	2: Over-current during deceleration (ocd)	0
	06-20	Fourth Most Recent Error Record	3: Over-current during constant speed(ocn)	0
	06-21	Fifth Most Recent Error Record	4: Ground fault (GFF)	0
	06-22	Sixth Most Recent Error Record	5: IGBT short-circuit (occ)	0
			6: Over-current at stop (ocS)	
			7: Over-voltage during acceleration (ovA)	
			8: Over-voltage during deceleration (ovd)	
			9: Over-voltage during constant speed (ovn)	
			10: Over-voltage at stop (ovS)	
			11: Low-voltage during acceleration (LvA)	
			12: Low-voltage during deceleration (Lvd)	
			13: Low-voltage during constant speed (Lvn)	
			14: Stop mid-low voltage (LvS)	
			15: Phase loss protection (PHL)	
			16: IGBT over-heat (oH1)	
			17: Capacitance over-heat (oH2) (over 40hp)	
			18: tH1o (TH1 open: IGBT over-heat protection error)	
			19: tH2o (TH2 open: capacitance over-heat protection error)	
			20: Reserved	
			21: Drive over-load (oL) (When current is 150% of the rated current, the drive will be overloaded.)	
			22: Electronics thermal relay 1 (EoL1)	
			23: Electronics thermal relay 2 (EoL2)	
			24: Motor overheat (oH3) (PTC)	
			25: Reserved	
			26: Over-torque 1 (ot1)	
			27: Over-torque 2 (ot2)	
			28: Under current 1 (uc1)	
			29: Under current 2 (uc2)	
			30: Memory write-in error (cF1)	
			31: Memory read-out error (cF2)	
			32: Reserved	
			33: U-phase current detection error (cd1)	
			34: V-phase current detection error (cd2)	
			35: W-phase current detection error (cd3)	
			36: Clamp current detection error (Hd0)	
			37: Over-current detection error (Hd1)	
			38: Over-voltage detection error (Hd2)	
			39: Ground current detection error (Hd3)	
			40: Auto tuning error (AuE)	
			41: PID feedback loss (AFE)	

	Parameter	Explanation	Settings	Factory Setting
			42~47 Reserved	
			48: ACI reference input loss (ACE)	
			49: External fault input (EF)	
			50: Emergency stop (EF1)	
			51: External Base Block (BB)	
			52: Password Error (Pcode)	
			53 : Reserved	
			54: Communication error (cE1)	
			55: Communication error (cE2)	
			56: Communication error (cE3)	
			57: Communication error (cE4)	
			58: Communication Time-out (cE10)	
			59: PU Time-out (cP10)	
			60: Brake transistor error (bF)	
			61: Y-connection/ Δ -connection switch error (ydc)	
			62: Decel. Energy Backup Error (dEb)	
			63: Slip error (oSL)	
			64~65 : Reserved	
			73: External safety gate S1	
			74: FIRE mode output	
			79: U phase over current (Uocc)	
			80: V phase over current (Vocc)	
			81: W phase over current (Wocc)	
			82: U phase output phase loss (OPHL)	
			83: V phase output phase loss (OPHL)	
			84: W phase output phase loss (OPHL)	
			101: CANopen software disconnect1 (CGdE)	
			102: CAN open software disconnect2 (CHbE)	
			103: CANopen synchronous error (CSYE)	
			104: CANopen hardware disconnect (CbFE)	
			105: CANopen index setting error (CIde)	
			106: CANopen slave station number setting error (CAde)	
			107: CANopen index setting exceed limit (CFrE)	
✓	06-23	Fault Output Option 1	0~65535(refer to bit table for fault code)	0
✓	06-24	Fault Output Option 2	0~65535(refer to bit table for fault code)	0
✓	06-25	Fault Output Option 3	0~65535(refer to bit table for fault code)	0
✓	06-26	Fault Output Option 4	0~65535(refer to bit table for fault code)	0
✓	06-27	Electronic Thermal Relay Selection 2 (Motor 2)	0: Motor with constant torque output 1: Motor with variable torque output 2: Electronic Thermal Relay disabled	2
✓	06-28	Electronic Thermal Operating Time of Motor 2 (Seconds)	30.0~600.0(Seconds)	60.0
✓	06-29	PTC Detection Selection	0: Warn and keep operation 1: Warn and ramp to stop 2: Warn and coast to stop 3: No warning	0
✓	06-30	PTC Level	0.0~100.0%	50.0

	Parameter	Explanation	Settings	Factory Setting
✓	06-31	Frequency Command when Malfunction	0.00~655.35 Hz	Read Only
	06-32	Output Frequency when Malfunction	0.00~655.35 Hz	Read Only
	06-33	Output Voltage when Malfunction	0.0~6553.5 V	Read Only
	06-34	DC Voltage at Malfunction	0.0~6553.5 V	Read Only
	06-35	Output Current at Malfunction	0.00~655.35 Amp	Read Only
	06-36	IGBT Temperature at Malfunction	0.0~6553.5 °C	Read Only
	06-37	Capacitance Temperature at Malfunction	0.0~6553.5 °C	Read Only
	06-38	Motor Speed in rpm at Malfunction	0~65535	Read Only
	06-39	Reserved	0~65535	Read Only
	06-40	Status of Multi-function Input Terminal when Malfunction	0~65535	Read Only
	06-41	Status of Multi-function Output Terminal when Malfunction	0~65535	Read Only
	06-42	Drive Status when Malfunction	0~65535	Read Only
	06-43	Reserved		
	06-44	Reserved		
	06-45	Action for detected Output Phase Loss (OPhL)	0: Warn and keep operation 1: Warn and ramp to stop 2: Warn and coast to stop 3: No warning	3
	06-46	Time of detected Output Phase Loss	0~65.535 seconds	0.5
	06-47	Detected Current Bandwidth	0~655.35%	1.0
	06-48	DC Brake Time of Output Phase Loss	0~65.535 seconds	0.1
	06-49	Reserved		
	06-50	Time of detected Input Phase Loss	0.00~600.00 seconds	0.20
	06-51	Reserved		
	06-52	Ripple of the detected Input Phase Loss' Ripple	230V models: 0.0 ~ 160 Vdc 460V models : 0.0 ~ 320 Vdc	30/60
	06-53	Action for detected Input Phase Loss (OrP)	0: warn and ramp to stop 1: warn and coast to stop	0
	06-54	Reserved		

Parameter	Explanation	Settings	Factory Setting
06-55	Derating Protection	0: Constant rated current and limit carrier wave by loaded current and temperature 1: Constant carrier frequency and limit loaded current by setting carrier wave 2: Constant rated current(same as setting 0), but current limit is closed	0
06-56	PT100 Detection Level 1	0~10000 v	5000
06-57	PT100 Detection Level 2	0~10000 v	7000
06-58	PT100 Level 1 Frequency Protect	0~600.00 Hz	0
06-59	Reserved		
06-60	Software Detection GFF Current Level (% rated current of the drive)	0~6553.5%	60.0
06-61	Software detection of GFF Low pass Filter gain	0~655.35 sec	0.10
06-62	Disable Level of dEb	230V models: 0~220.0 Vdc 460V models: 0~440.0 Vdc	180.0/ 360.0
06-63	Fault Record 1 (Min)	0~65535 minutes	Read Only
06-64	Fault Record 2 (Min)	0~65535 minutes	Read Only
06-65	Fault Record 3 (Min)	0~65535 minute	Read Only
06-66	Fault Record 4 (Min)	0~65535 minutes	Read Only
06-67	Fault Record 5 (Min)	0~65535 minutes	Read Only
06-68	Fault Record 6 (Min)	0~65535 minutes	Read Only
06-69	Number of Days of Malfunction (days)	Read Only	Read Only
06-70	Duration of Malfunction (minutes)	Read Only	Read Only
06-71	Low Current Setting Level	0~100.0%	0
06-72	Low Current Detection Time	0~360.00 seconds	0

	Parameter	Explanation	Settings	Factory Setting
	06-73	Options when low current occurs	0 : No function 1 : Warn and coast to stop 2 : Warn and ramp to stop by 2nd deceleration time 3 : Warn and operation continues	0
	06-80	Fire mode	0: No function 1: Forward operation 2: Reverse Operation	0
	06-81	Operating Frequency when running Fire Mode(Hz)	0.00 to 60000Hz	6000
	06-82	Bypass Fire Mode enabled	0: Disable Bypass 1: Enable Bypass	0
	06-83	Delayed Time when Bypass Fire Mode	0.0 to 6550.0 sec	0
	06-84	Auto reset counter of Fire Mode	0~10	0
	06-85	Length of time to reset auto-counter (seconds)	0.0 to 6000.0 sec	600

07 Special Parameters

Parameter	Explanation	Settings	Factory Setting
07-00	Setup Software Brake Level	230V series : 350.0~450.0Vdc 460V series : 700.0~900.0Vdc	380.0 760.0
07-01	DC Brake Current Level	0~100%	0
07-02	DC Brake Time at Start-up	0.0~60.0 seconds	0.0
07-03	DC Brake Time at Stop	0.0~60.0 seconds	0.0
07-04	Startup Frequency for DC Brake	0.00~600.00Hz	0.00
07-05	Reserved		
07-06	Restart after Momentary Power Down	0: Stop operation 1: Speed search starting from last speed before the moment of power down. 2: Speed search starting from minimum output frequency	0
07-07	Maximum Power Loss Duration	0.1~20.0 seconds	2.0
07-08	Base Block Time	0.1~5.0 seconds	0.5
07-09	Current Limit for Speed Search	20~200%	100
07-10	Base Block Speed Search (oc, ov, bb)	0: Stop operation 1: Speed search starting from last speed before the moment of base block. 2: Speed search starting from minimum output frequency	0
07-11	# of Auto Reset after Errors Occurred	0~10	0
07-12	Speed Search while Start-up	0: Disable 1: Speed search starting from maximum output frequency 2: Speed search starting from start-up motor frequency 3: Speed search starting from minimum output frequency	0
07-13	Deceleration Time at Momentary Power Down (dEb function: Deceleration Energy Backup)	0: Disable 1: 1st decel. time 2: 2nd decel. time 3: 3rd decel. time 4: 4th decel. time 5: system decel. time 6: Auto decel. time	0
07-14	DEB Return Time	0.0~25.0 sec(0~250)	0
07-15	Dwell Time at Accel.	0.00~600.00sec(0~60000)	0
07-16	Dwell Frequency at Accel.	0.00~600.00Hz(0~60000)	0
07-17	Dwell Time at Decel.	0.00~600.00sec(0~60000)	0
07-18	Dwell Frequency at Decel.	0.00~600.00Hz(0~60000)	0
07-19	Fan Cooling Control	0: Fan always ON 1: 1 minute after the AC motor drive stops, fan will be OFF 2: When the AC motor drive runs, the fan is ON. When the AC motor drive stops, the fan is OFF 3: Fan turns ON when the preliminary heat sink's temperature reached around 60°C (140°F). 4: Fan always OFF	0

Parameter	Explanation	Settings	Factory Setting
07-20	Emergency Stop (EF) & Force to Stop Selection	0: Coast stop 1: By deceleration Time 1 2: By deceleration Time 2 3: By deceleration Time 3 4: By deceleration Time 4 5: System Deceleration 6: Automatic Deceleration	0
07-21	Auto Energy-sAVING Operation	0: Disable 1: Enable	0
07-22	Energy-sAVING Gain	10~1000%	100
07-23	Auto Voltage Regulation(AVR) Function	0: Enable AVR 1: Disable AVR 2: Disable AVR during deceleration	0
07-24	Filter Time of Torque Command (V/F and SVC control mode)	0.001~10.000seconds	0.020
07-25	Filter Time of Slip Compensation (V/F and SVC control mode)	0.001~10.000 seconds	0.100
07-26	Torque Compensation Gain (V/F and SVC control mode)	0~10	0
07-27	Slip Compensation Gain (V/F and SVC control mode)	0.00~10.00	0.00
07-28	Reserved		
07-29	Slip Deviation Level	0.0~100.0%	0
07-30	Detection Time of Slip Deviation	0.0~10.0 seconds	1.0
07-31	Over Slip Treatment	0: Warn and keep operation 1: Warn and ramp to stop 2: Warn and coast to stop 3: No warning	0
07-32	Motor Hunting Gain	0~10000	1000
07-33	Recovery Time to Pr.07-11 (# of auto reset after error occurred)	00~60000 seconds	60.0
07-34	Kp: Automatic Acceleration\Deceleration	0~65535	40
07-35	Ki: Automatic Acceleration\Deceleration	0~65535	0.001
07-36	Power Generating Slip Compensation Gain	0.00~1.00	1.00
07-37~07-49	Reserved		
07-50	PWM Fan Speed 0~100%	0~100	60

08 High-function PID Parameters

Parameter	Explanation	Settings	Factory Setting
08-00	Input Terminal for PID feedback	0: No function 1: Negative PID feedback: input from external terminal AV11 (Pr.03-00) 4: Positive PID feedback from external terminal AV11 (Pr.03-00)	0
08-01	Proportional Gain (P)	0.0~500.0%	1.0
08-02	Integral Time (I)	0.00~100.00 seconds	1.00
08-03	Derivative Time (D)	0.00~1.00seconds	0.00
08-04	Upper Limit of Integral Control	0.0~100.0%	100.0
08-05	PID Output Frequency Limit	0.0~110.0%	100.0
08-06	Reserved		
08-07	PID Delay Time	0.0~35.0 seconds	0.0
08-08	Feedback Signal Detection Time	0.0~3600.0 seconds	0.0
08-09	Options on Feedback Error	0: Warn and keep operation 1: Warn and ramp to stop 2: Warn and coast to stop 3: Warn and operate at last frequency	0
08-10	Sleep Frequency	0.00~600.00Hz or 0~200.00%	0.00
08-11	Wake-up Frequency	0.00~600.00Hz or 0~200.00%	0.00
08-12	Sleep Time	0.0~6000.0 seconds	0.0
08-13	PID Deviation Level	1.0~50.0%	10.0
08-14	PID Deviation Time	0.1~300.0 seconds	5.0
08-15	Filter Time for PID Feedback	0.1~300.0 seconds	5.0
08-16	PID Compensation Selection	0: Parameter setting 1: Analog input	0
08-17	PID Compensation	-100.0~+100.0%	0
08-18	Setting of Sleep mode function	0: Follow PID output command 1: Follow PID feedback signal	
08-19	Integral Limit during Wakeup	0~200.0%	
08-20	PID Mode Selection	0: Serial connection 1: Parallel connection	0
08-21	Enable PID to Change Operating Direction	0: Operating direction cannot be changed 1: Operating direction can be changed	0

09 Communication Parameters

	Parameter	Explanation	Settings	Factory Setting
✓	09-00	COM1 Communication Address	1~254	1
✓	09-01	COM1 Transmission Speed	4.8~115.2Kbps	9.6
✓	09-02	COM1 Transmission Fault Treatment	0: Warn and continue operation 1: Warn and ramp to stop 2: Warn and coast to stop 3: No warning and continue operation	3
✓	09-03	COM1 Time-out Detection	0.0~100.0 seconds	0.0
✓	09-04	COM1 Communication Protocol	0: 7N1 (ASCII) 1: 7N2 (ASCII) 2: 7E1 (ASCII) 3: 7O1 (ASCII) 4: 7E2 (ASCII) 5: 7O2 (ASCII) 6: 8N1 (ASCII) 7: 8N2 (ASCII) 8: 8E1 (ASCII) 9: 8O1 (ASCII) 10: 8E2 (ASCII) 11: 8O2 (ASCII) 12: 8N1 (RTU) 13: 8N2 (RTU) 14: 8E1 (RTU) 15: 8O1 (RTU) 16: 8E2 (RTU) 17: 8O2 (RTU)	1
✓	09-05 ~ 09-08	Reserved		
✓	09-09	Response Delay Time	0.0~200.0ms	2.0
✓	09-10	Main Communication Frequency (Hz)	0.00~600.00Hz	60.00
✓	09-11	Block Transfer 1	0~65535	0
✓	09-12	Block Transfer 2	0~65535	0
✓	09-13	Block Transfer 3	0~65535	0
✓	09-14	Block Transfer 4	0~65535	0
✓	09-15	Block Transfer 5	0~65535	0
✓	09-16	Block Transfer 6	0~65535	0
✓	09-17	Block Transfer 7	0~65535	0
✓	09-18	Block Transfer 8	0~65535	0
✓	09-19	Block Transfer 9	0~65535	0
✓	09-20	Block Transfer 10	0~65535	0
✓	09-21	Block Transfer 11	0~65535	0
✓	09-22	Block Transfer 12	0~65535	0

Parameter	Explanation	Settings	Factory Setting
09-23	Block Transfer 13	0~65535	0
09-24	Block Transfer 14	0~65535	0
09-25	Block Transfer 15	0~65535	0
09-26	Block Transfer 16	0~65535	0
09-27 ~ 09-29	Reserved		
09-30	Communication Decoding Method	0: Old Delta definition(20XX) 1: New Delta definition(60XX)	0
09-31	COM1 Protocol	0: RS485 1: BACnet	0
09-34	PLC frequency setup	0: Before PID control 1: After PID control	0
09-35	PLC Address	1~254	2
09-36	CANopen Slave Address	0: Disable 1~127	0
09-37	CANopen Speed	0 : 1M 1 : 500k 2: 250k 3: 125k 4: 100k (Delta Only) 5: 50k	0
09-38	CANopen Frequency Gain	1.00 ~ 2.00	1.00
09-39	CANopen Warning Record	bit 0 : CANopen Guarding Time out bit 1 : CANopen Heartbeat Time out bit 2 : CANopen SYNC Time out bit 3 : CANopen SDO Time out bit 4 : CANopen SDO buffer overflow bit 5 : Can Bus Off bit 6 : Error protocol of CANopen	0
09-40	CANopen Decoding Method	0: Communication definition of CP2000 series 1: CANopen DS402 Standard	1
09-41	CANopen Communication Status	0 : (Node Reset State) 1 : (Com Reset State) 2 : (Boot up State) 3 : (Pre Operation State) 4 : (Operation State) 5 : (Stop State)	0
09-42	CANopen Control Status	0 : (Not Ready For Use State) 1 : (Inhibit Start State) 2 : (Ready To Switch On State) 3 : (Switched On State) 4 : (Enable Operation State) 7 : (Quick Stop Active State) 13 : (Err Reaction Active State)	0

Parameter	Explanation	Settings	Factory Setting
		14 : (Error State)	
09-43	Reset CAN Initial Idx	bit0: reset address 20XX to 0. bit1: reset address 264X to 0 bit2: reset address 26AX to 0 bit3: reset address 60XX to 0	65535
09-45	CANopen Master function	0: Use 420XX 1: Use 60XX	0
09-46	CANopen Master Address	1~127	100
09-47 ~ 09-49	Reserved		
09-50	BACnet Dnet	0~127	10
09-51	BACnet Baud Rate	96~384	384
09-52	BACnet Device ID L	0~9999	1
09-53	BACnet Device ID H	0~419	0
09-54	Reserved		
09-55	BACnet Max Address	0~127	127
09-56	BACnet Password	0~65535	0
09-60	Identification of Communication Card	0: No communication card 1: DeviceNet Slave 2: Profibus-DP Slave 3: CANopen Slave 4: Modbus-TCP Slave 5: EtherNet/IP Slave 6~8: Reserved	0
09-61	Firmware Version of Communication Card	Read Only	##
09-62	Product Code	Read Only	##
09-63	Error Code	Read Only	##
09-64 ~ 09-69	Reserved		
09-70	Address of Communication Card	DeviceNet: 0-63 Profibus-DP: 1-125	1
09-71	Communication Card Speed	Standard DeviceNet: 0: 100Kbps 1: 125Kbps 2: 250Kbps 3: 1Mbps (Delta only) Non standard DeviceNet: (Delta only) 0: 10Kbps 1: 20Kbps 2: 50Kbps 3: 100Kbps 4: 125Kbps 5: 250Kbps 6: 500Kbps 7: 800Kbps 8: 1Mbps	2

Parameter	Explanation	Settings	Factory Setting
09-72	Other settings of communication card speed	0: Disable In this mode, baud rate can only be 0,1,2,3 in standard DeviceNet speed 1: Enable In this mode, the baud rate of DeviceNet can be same as CANopen (0-8). °	0
09-75	IP Configuration of the Communication Card	0: Static IP 1: Dynamic IP (DHCP)	0
09-76	IP Address 1 of the Communication Card	0~255	0
09-77	IP Address 2 of the Communication Card	0~255	0
09-78	IP Address 3 of the Communication Card	0~255	0
09-79	IP Address 4 of the Communication Card	0~255	0
09-80	Address Mask 1 of the Communication Card	0~255	0
09-81	Address Mask 2 of the Communication Card	0~255	0
09-82	Address Mask 3 of the Communication Card	0~255	0
09-83	Address Mask 4 of the Communication Card	0~255	0
09-84	Gateway Address 1 of the Communication Card	0~255	0
09-85	Gateway Address 2 of the Communication Card	0~255	0
09-86	Gateway Address 3 of the Communication Card	0~255	0
09-87	Gateway Address 4 of the Communication Card	0~255	0
09-88	Password for Communication Card (Low word)	0~99	0
09-89	Password for Communication Card (High word)	0~99	0
09-90	Reset Communication Card	0: No function 1: Reset to return to the factory setting	0
09-91	Additional Setting for Communication Card	Bit 0: Enable IP Filter : Bit 1: Enable internet parameters (1bit) Once the setup of internet parameter is done, the Bit 1 will be enabled. But after the parameters of the communication card are updated, this Bit 1 will be disabled. Bit 2: Enable login password (1bit) When login password is correctly entered, the Bit 2 will be enabled. But after the parameters of the communication card are updated, this Bit 2 will be disabled.	0
09-92	Status of Communication Card	Bit 0: Enable password. When the communication card is locked by a password, this Bit 0 will be enabled. When the password is clear, this Bit 0 will be disabled.	0

12 PUMP Parameter

Parameter	Explanation	Settings	Factory Setting
↘ 12-00	Circulative Control	0: No operation 1: Fixed Time Circulation (by time) 2: Fixed quantity circulation (by PID) 3: Fixed quantity control 4: Fixed Time Circulation+ Fixed quantity circulation 5: Fixed Time Circulation+ Fixed quantity control	0
↘ 12-01	Number of motors to be connected	From only 1 and up to 8 motors	1
↘ 12-02	Operating time of each motor (minutes)	0 to 65500 min	0
↘ 12-03	Delay Time due to the Acceleration (or the Increment) at Motor Switching	0.0 to 3600.0 sec	10
↘ 12-04	Delay Time due to the Deceleration (or the Decrement) at Motor Switching (seconds)	0.0 to 3600.0 sec	10
↘ 12-05	Delay time while fixed quantity circulation at Motor Switching (seconds)	0.0 to 3600.0 sec	100
12-06	Frequency when switching motors at fixed quantity circulation (Hz)	0.00 to 600.00 Hz	6000
↘ 12-07	Action to do when Fixed Quantity Circulation breaks down.	0: Turn off all output 1: Motors powered by mains electricity continues to operate.	0
↘ 12-08	Frequency when stopping auxiliary motor (Hz)	0.00 to 600.00 Hz	0

Chapter 12 Description of Parameter Settings

00 Drive Parameters

✎ The parameter can be set during operation.

00 - 00 ID Code of the AC Motor Drive

Factory Setting: ##

Settings Read Only

00 - 01 Display AC Motor Drive Rated Current

Factory Setting: ##

Settings Read Only

📖 Pr. 00-00 displays the identity code of the AC motor drive. Using the following table to check if Pr.00-01 setting is the rated current of the AC motor drive. Pr.00-01 corresponds to the identity code Pr.00-01.

📖 The factory setting is the rated current for normal duty. Please set Pr.00-10 to 0 to display the rated current for the light duty.

230V series											
Frame	A					B			C		
kW	0.75	1.5	2.2	3.7	5.5	7.5	11	15	18.5	22	30
HP	1.0	2.0	3.0	5.0	7.5	10	15	20	25	30	40
ID Code of the AC Motor Drive	4	6	8	10	12	14	16	18	20	22	24
Rated Current of Light Duty (A)	5	7.5	10	15	21	31	46	61	75	90	105
Rated Current of Normal Duty (A)	3	5	8	11	17	25	33	49	65	75	90

Frame	D		E		
kW	37	45	55	75	90
HP	50	60	75	100	125
ID Code of the AC Motor Drive	26	28	30	32	34
Rated Current of Light Duty (A)	146	180	215	276	322
Rated Current of Normal Duty (A)	120	146	180	215	255

460V series													
Frame	A							B			C		
kW	0.75	1.5	2.2	3.7	4.0	5.5	7.5	11	15	18.5	22	30	37
HP	1	2	3	5	5.5	7.5	10	15	20	25	30	40	50
ID Code of the AC Motor Drive	5	7	9	11	93	13	15	17	19	21	23	25	27
Rated Current of Light Duty (A)	3	3.7	5	7.5	10.5	12	14	22.5	30	36	45	56	72
Rated Current of Normal Duty (A)	1.7	3.0	4.0	6.0	9.0-	10.5	12	18	24	32	38	45	60





Frame	D				E		F		G		H		
kW	45	55	75	90	110	132	160	185	220	280	315	355	400
HP	60	75	100	125	150	175	215	250	300	375	425	475	536
ID Code of the AC Motor Drive	29	31	33	35	37	39	41	43	45	47	49	51	53
Rated Current of Light Duty (A)	91	110	144	180	220	246	310	343	460	530	616	683	770

Rated Current of Normal Duty (A)	73	91	110	150	180	220	260	310	370	460	550	616	683
----------------------------------	----	----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----

00 - 02 Parameter Reset

Factory Setting: 0


- Settings
- 0: No Function
 - 1: Write protection for parameters
 - 6: Reset PLC (including CANopen Master Index)
 - 7: Reset CANopen Index (Slave)
 - 8: keypad lock
 - 9: All parameters are reset to factory settings(base frequency is 50Hz)

-  When it is set to 1, all parameters are read only except Pr.00-02~00-08 and it can be used with password setting for password protection. It needs to set Pr.00-02 to 0 before changing other parameter settings.
-  When it is set to 6: clear internal PLC program (includes the related settings of PLC internal CANopen master)
-  When it is set to 7: reset the related settings of CANopen slave.
-  When it is set to 9 or 10: all parameters are reset to factory settings. If the password is set in Pr.00-08, it needs to input the password set in Pr.00-07 to reset to factory settings.

00 - 03 Start-up Display Selection

Factory setting: 0

- Settings
- 0: Display the frequency command (F)
 - 1: Display the actual output frequency (H)
 - 2: Display User define (U)
 - 3: Output current (A)

-  This parameter determines the start-up display page after power is applied to the drive. User defined choice display according to the setting in Pr.00-04.

00 - 04 Content of Multi-function Display (user defined)

Factory setting: 3

- Settings
- 0: Display output current (A)
 - 1: Display counter value (c)
 - 2: Display actual output frequency (H.)
 - 3: Display DC-BUS voltage (v)
 - 4: Display output voltage (E)
 - 5: Display output power angle (n)
 - 6: Display output power in kW (P)
 - 8: Display estimate output torque % (t = 00: positive torque; -00 negative torque) (t)
 - 9: Display PG feedback (G) (refer to Note 1)
 - 10: Display PID feedback in % (b)

- 11: Display AVI1 in % (1.), 0~10V/4-20mA/0-20mA corresponds to 0~100%
(Refer to Note 2)
- 12: Display ACI in % (2.), 4~20mA/0~10V/0-20mA corresponds to 0~100%
(Refer to Note 2)
- 13: Display AVI2 in % (3.), -10V~10V corresponds to -100~100%(Refer to Note 2)
- 14: Display the temperature of IGBT in °C (i.)
- 15: Display the temperature of capacitance in °C (c.)
- 16: The status of digital input (ON/OFF) refer to Pr.02-20 (i) (Refer to Note3)
- 17: Display digital output status ON/OFF (Pr.02-15) (o) (refer to NOTE 4)
- 18: Display the multi-step speed that is executing (S)
- 19: The corresponding CPU pin status of digital input (d) (refer to NOTE 3)
- 20: The corresponding CPU pin status of digital output (0.) (refer to NOTE 4)
- 25: Overload counting (0.00~100.00%) (h.)
- 26: GFF Ground Fault (Unit :%)(G)
- 27:DC Bus voltage ripple (Unit: Vdc)(r.)
- 28: Display PLC register D1043 data (C) display in hexadecimal
- 30 : Display output of user defined (U)
- 31 : H page x 00-05 Display user Gain(K)

Note 1

It can display negative values when setting analog input bias (Pr.03-03~03-10).

Example: assume that AVI1 input voltage is 0V, Pr.03-03 is 10.0% and Pr.03-07 is 4 (Serve bias as the center).

Note 2

Example: If REV, MI1 and MI6 are ON, the following table shows the status of the terminals.

0 means OFF, 1 means ON

Terminal	MI15	MI14	MI13	MI12	MI11	MI10	MI8	MI7	MI6	MI5	MI4	MI3	MI2	MI1	REV	FWD
Status	0	0	0	0	0	0	0	0	1	0	0	0	0	1	1	0

MI10~MI15 are the terminals for extension cards (Pr.02-26~02-31).

If REV, MI1 and MI6 are ON, the value is 0000 0000 1000 0110 in binary and 0086h in HEX. When Pr.00-04 is set to “16” or “19”, it will display “0086h” with LED U is ON on the keypad KPC-CE01. The setting 16 is the status of digital input by Pr.02-11 setting and the setting 19 is the corresponding CPU pin status of digital input. User can set to 16 to monitor digital input status and then set to 19 to check if the wire is normal.

Note 3

Assume that RY1: Pr.02-13 is set to 9 (Drive ready). After applying the power to the AC motor drive, if there is no other abnormal status, the contact will be OFF. The display status will be shown as follows.

0 means OFF, 1 means ON


Terminal	Reserved				Reserved				Reserved				MO2	MO1	Reserved	RY2	RY1
Status	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1

Meanwhile, if Pr.00-04 is set to 17 or 20, it will display in hexadecimal “0001h” with LED U is ON on the keypad. The setting 17 is the status of digital output by Pr.02-18 setting and the setting 20 is the corresponding CPU pin status of digital output. User can set 17 to monitor the digital output status and then set to 20 to check if the wire is normal.

00 - 05 Coefficient Gain in Actual Output Frequency

Factory Setting: 0.00

Settings 0~160.00

 This parameter is to set coefficient gain in actual output frequency. Set Pr.00-04= 31 to display the calculation result on the screen (calculation = output frequency * Pr.00-05).

00 - 06 Software version

Factory Setting: #.#


Settings Read Only


↗ 00 - 07 Input Parameter Protection Password


Factory Setting: 0


Settings 0~65535


Display 0~4 (# of times of password attempts)

 This parameter allows user to enter their password (which is pre-set in Pr.00-08) to unlock the parameter protection and to make changes to the parameter.

 After you set up this parameter, make sure that you note its value for any future use.

 The purpose of having Pr.00-07 and Pr.00-08 is to prevent the personal misoperation.

 If you forget the password, clear the setting by input 9999 and press ENTER key, then input 9999 again and press Enter within 10 seconds. After decoding, all the settings will return to factory setting.

 When setting up a password all parameters read are 0, except parameter 00-08.

➤ **00 - 08** Set up a Parameter Protection Password

Factory Setting: 0

Settings 0~65535

Display 0: No password protection / password is entered correctly (Pr00-07)
 1: Password has been set

📖 This parameter is for you to set up a password to protect your parameter settings from unauthorized modifications. For the very first set up, enter directly a password of your choice. Once you finish entering that password, the setting of the parameter 8 will be 1. Then the password protection is activated. If you want to modify any parameter, go to parameter 00-07, enter the password that you set up here. If the right password is entered, then the parameter 00-08 will be 0 and you can modify any parameter.

📖 Once you decode the parameter protection number at Parameter 00-07 and the set the parameter to 0, then the password protection will be canceled. The will not be password protection when you re-start CP2000.



📖 Password setting is permanently effective. If you need to modify any parameter, decode the parameter protection at Parameter 00-07.

📖 How to re-start the parameter protection after the password is decode?

Method01: Go to parameter 00-08, enter once a new password.

Method02: Reboot CP2000 to restore the setting

Method03: Input any value into Pr.00-07 (Do not enter the password).



00 - 09 Display Advanced Parameters

Factory Setting: 0

Settings Bit 0: Group 0
 Bit 1: Group 1
 Bit 2: Group 2
 Bit 3: Group 3
 Bit 4: Group 4
 Bit 5: Group 5
 Bit 6: Group 6
 Bit 7: Group 7
 Bit 8: Group 8
 Bit 9: Group 9
 (Bin Setting and Display for LCD Keypad)

00 - 11 Velocity Control Mode

Factory Setting: 0


Settings 0 : V/F (V/F control)
 2 : SVC (Sensorless Vector Control)

This parameter determines the control method of the AC motor drive: °


0: V/F control: user can design proportion of V/f as required and can control multiple motors simultaneously.

2: Sensorless vector control: get the optimal control by the auto-tuning of motor parameters.

When setting Pr.00-11 to 0, the V/F control diagram is shown as follows.



When setting Pr.00-11 to 2, the sensorless vector control diagram is shown as follows.



00 - 16 Loading mode selection

Factory Setting: 0

- Settings 0: Light duty
1: Normal duty

- Light duty 230V series & 460V series: When the output current is 110% of the rated output current, the endurance time is 60 seconds. When the output current is 130% of the rated output current, the endurance time is 3 seconds. Refer to Pr.00-17 for the setting of carrier frequency. Refer to chapter specifications or Pr.00-01 for the rated current.
- Normal duty 230 V series & 460V series: When the output current is 120% of the rated output current, the endurance time is 60 seconds. When the output current is 160% of the rated output current, the endurance time is 3 seconds. . Refer to Pr.00-17 for the setting of carrier frequency. Refer to chapter specifications or Pr.00-01 for the rated current.

00 - 17 Carrier Frequency

Factory Setting: As shown in table below

Settings 2~15kHz

This parameter determinates the PWM carrier frequency of the AC motor drive.

230V series			
Models	1-20HP [0.75-15kW]	25-60HP [18.5-45kW]	75-125HP [55-90kW]
Settings	2~15kHz	2~10kHz	2~9kHz
Light Duty Factory Setting	8kHz	6kHz	4kHz
Normal Duty Factory Setting	8 kHz	6 kHz	4 kHz
460V series			
Models	1-25HP [0.75-18.5kW]	30-100HP [22-75kW]	125-536HP [90-400kW]
Settings	2~15kHz	2~10kHz	2~9kHz
Light Duty Factory Setting	8kHz	6kHz	4kHz
Normal Duty Factory Setting	8 kHz	6 kHz	4 kHz

Carrier Frequency	Acoustic Noise	Electromagnetic Noise or Leakage Current	Heat Dissipation	Current Wave
1kHz	Significant ↑ ↓ Minimal	Minimal ↑ ↓ Significant	Minimal ↑ ↓ Significant	
8kHz				
15kHz				

由 From the table, we see that the PWM carrier frequency has a significant influence on the electromagnetic noise, AC motor drive heat dissipation, and motor acoustic noise. Therefore, if the surrounding noise is greater than the motor noise, lower the carrier frequency is good to reduce the temperature rise. Although it is quiet operation in the higher carrier frequency, the entire wiring and interference resistance should be considerate.

When the carrier frequency is higher than the factory setting, it needs to protect by decreasing the carrier frequency. See Pr.06-55 for the related setting and details.

00 - 18 Reserved

00 - 19 PLC Command Mask

Factory Setting: Read Only


Settings


- Bit 0: Control command controls by PLC
- Bit 1: Frequency command controls by PLC
- Bit 2: Reserved
- Bit 3: Reserved


00 - 20 Source of the MASTER Frequency Command (AUTO)

Factory Setting: 0

- Settings
- 0: Digital keypad
 - 1: RS-485 serial communication
 - 2: External analog input (Pr.03-00)
 - 3: External UP/DOWN terminal
 - 6: CANopen communication card
 - 8: Communication card (no CANopen card)

 It is used to set the source of the master frequency in AUTO mode.


 Pr.00-20 and 00-21 are for the settings of frequency source and operation source in AUTO mode. Pr.00-30 and 00-31 are for the settings of frequency source and operation source in HAND mode. The AUTO/HAND mode can be switched by the keypad KPC-CC01 or multi-function input terminal (MI).


 The factory setting of frequency source or operation source is for AUTO mode. It will return to AUTO mode whenever power on again after power off. If there is multi-function input terminal used to switch AUTO/HAND mode. The highest priority is the multi-function input terminal. When the external terminal is OFF, the drive won't receive any operation signal and can't execute JOG.

00 - 21 Source of the Operation Command (AUTO)

Factory Setting: 0

- Settings
- 0: Digital keypad
 - 1: External terminals. Keypad STOP disabled.
 - 2: RS-485 serial communication. Keypad STOP disabled.
 - 3: CANopen card
 - 5: Communication card (not includes CANopen card)


 It is used to set the source of the operation frequency in AUTO mode.


 When the operation command is controlled by the keypad KPC-CC01, keys RUN, STOP and JOG (F1) are valid.

00 - 22 Stop Mode

Factory Setting: 0

- Settings
- 0: Ramp to stop
 - 1: Coast to stop

 The parameter determines how the motor is stopped when the AC motor drive receives a valid stop command.



Ramp to Stop and Coast to Stop

1. **Ramp to stop:** the AC motor drive decelerates from the setting of deceleration time to 0 or minimum output frequency (Pr. 01-09) and then stop (by Pr.01-07).
2. **Coast to stop:** the AC motor drive stops the output instantly upon a STOP command and the motor free runs until it comes to a complete standstill.
 - It is recommended to use “ramp to stop” for safety of personnel or to prevent material from being wasted in applications where the motor has to stop after the drive is stopped. The deceleration time has to be set accordingly.
 - If the motor free running is allowed or the load inertia is large, it is recommended to select “coast to stop”. For example, blowers, punching machines and pumps

⚡ 00 - 23 Motor Operating Direction Control

Factory Setting: 0

- Settings
- 0: Enable forward/ reverse
 - 1: Disable reverse
 - 2: Disable forward

This parameter enables the AC motor drives to run in the forward/reverse Direction. It may be used to prevent a motor from running in a direction that would consequently injure the user or damage the equipment.

00 - 24 Memory of Communication Frequency Command

Factory Setting: Read Only


- Settings Read Only


If keypad is the source of frequency command, when Lv or Fault occurs the present frequency command will be saved in this parameter.

00 - 25 User Defined Property

Factory Setting: 0

Settings	B Bit 0~3: user define on decimal place 0000b: no decimal place 0001b: one decimal place 0010b: two decimal place 0011b: three decimal place Bit 4~15: user define on unit 000xh: Hz 001xh: rpm 002xh: % 003xh: kg
----------	---


 Bit 0~3: F & H page unit and Pr.00-26 decimal display is supported up to 3 decimal places.

 Bit 4~15: F & H page unit and Pr.00-26 unit display is supported up to 4 types of unit display.

00 - 26 Max. User Defined Value


Factory Setting: 0

Settings	0: Disable 0000B: 0~65535 (No decimal place in Pr.00-25 setting) 0001B: 0.0~6553.5 (One decimal place in Pr.00-25 setting) 0010B: 0.0~655.35(Two decimal place in Pr.00-25 setting) 0011B: 0.0~65.536 (Three decimal place in Pr.00-25 setting)
----------	---

 User define is enabled when Pr.00-26 is not 0. The setting of Pr.00-26 corresponds to Pr.01.00 (Max. output frequency of the drive).

Example: User define: 100.0%, Pr.01.00 = 60.00Hz

Pr.00.25 setting is 0021h; Pr.0026 setting is 100.0%

 **NOTE** In order to display as the setting in Pr.0025, please set up Pr.00.25 first and ensure Pr.00.26 is not set to 0.

00 - 27 User Defined Value

Factory Setting: Read Only

Settings	Read Only
----------	-----------


 Pr.00-27 will show user defined value when Pr.00-26 is not set to 0.

00 - 28 Reserved**00 - 29** Reserved

↗ 00 - 30 Source of the Master Frequency Command (HAND)

Factory Setting: 0


- Settings
- 0: Digital keypad
 - 1: RS-485 serial communication
 - 2: External analog input (Pr.03-00)
 - 3: External UP/DOWN terminal
 - 6: CANopen communication card
 - 8: Communication card (no CANopen card)


 It is used to set the source of the master frequency in HAND mode.

↗ 00 - 31 Source of the Operation Command (HAND)


Factory Setting: 0

- Settings
- 0: Digital keypad
 - 1: External terminals. Keypad STOP disabled.
 - 2: RS-485 serial communication. Keypad STOP disabled.
 - 3: CANopen communication card
 - 5: Communication card (not including CANopen card)

 It is used to set the source of the operation frequency in HAND mode.

 参 Pr.00-20 and 00-21 are for the settings of frequency source and operation source in AUTO mode.

Pr.00-30 and 00-31 are for the settings of frequency source and operation source in HAND mode. The AUTO/HAND mode can be switched by the keypad KPC-CC01 or multi-function input terminal (MI).

 The factory setting of frequency source or operation source is for AUTO mode. It will return to AUTO mode whenever power on again after power off. If there is multi-function input terminal used to switch AUTO/HAND mode. The highest priority is the multi-function input terminal. When the external terminal is OFF, the drive won't receive any operation signal and can't execute JOG.

↗ 00 - 32 Enable Digital Keypad STOP Function

Factory Setting: 0

- Settings
- 0: STOP key disable
 - 1: STOP key enable

00 - 33
~00 - 47 Reserved

00 -48 Display Filter Time (Current)

Factory Setting: 0.100


- Settings 0.001~65.535

 Set this parameter to minimize the **current fluctuation** displayed by digital keypad.

00 - 49 Display Filter Time on the Keypad

Factory Setting: 0.100


Settings 0.001~65.535

 Set this parameter to minimize the **display value fluctuation** displayed by digital keypad.

00 - 50 Software Version (date)

Factory Setting: Read Only

Settings 0~65535

 This parameter displays the drive's software version by date.

01 Basic Parameter

✎ The parameter can be set during operation.

01 - 00 Maximum Output Frequency

Factory Setting: 60.00/50.00

Settings 50.00~600.00Hz

📖 This parameter determines the AC motor drive's Maximum Output Frequency. All the AC motor drive frequency command sources (analog inputs 0 to +10V, 4 to 20mA, 0 to 20mA and $\pm 10V$) are scaled to correspond to the output frequency range.

01 - 01 Motor1: Max Output Frequency(Hz) (Base Frequency/Motor Rated Frequency)

Factory Setting: 60.00/50.00

Settings 0.00~600.00Hz

01 - 02 Motor1: Max Output Voltage (V)**01 - 03** Mid-point Frequency 1 of Motor 1

Factory Setting:

220.00/400.00

Factory Setting: 3.0

Settings 230V series 0.0~240.0V

460V series 0.0~480.0V

Settings 0.00~600.00Hz

✎ **01 - 04** Mid-point Voltage 1 of Motor 1

Factory Setting: 11.0/22.0

Settings 230V series 0.0~255.0V

460V series 0.0~510.0V

01 - 05 Mid-point Frequency 2 of Motor 1

Factory Setting: 0.50

Settings 0.00~600.00Hz

✎ **01 - 06** Mid-point Voltage 2 of Motor 1

Factory Setting: 4.0/8.0

Settings 230V series 0.0~240.0V

460V series 0.0~480.0V

01 - 07 Min. Output Frequency of Motor 1

Factory Setting: 0.00

Settings 0.00~600.00Hz


01 - 08 Min. Output Voltage of Motor 1


Factory Setting: 0.0/0.0


Settings 230V series 0.0~240.0V
460V series 0.0~480.0V**01 - 09** Start-Up Frequency

Factory Setting: 0.50

Settings 0.0~600.00Hz

 When start frequency is higher than the min. out put frequency, drives' output will be from start frequency to the setting frequency. Please refer to the following diagram for details.

 **Fcmd**=frequency command,
Fstart=start frequency (Pr.01-09),
fstart=actual start frequency of drive,
Fmin=4th output frequency setting (Pr.01-07/Pr.01-41),
Flow=output frequency lower limit (Pr.01-11)



01 - 10 Output Frequency Upper Limit

Factory Setting: 600.00


Settings 0.00~600.00Hz

01 - 11 Output Frequency Lower Limit

Factory Setting: 0.00

Settings 0.00~600.00Hz

- The upper/lower output frequency setting is used to limit the actual output frequency. If the frequency setting is higher than the upper limit, it will run with the upper limit frequency. If output frequency is lower than the output frequency lower limit and frequency setting is higher than min. frequency, it will run with lower limit frequency. The upper limit frequency should be set to be higher than the lower limit frequency.
- Pr.01-10 setting must be \geq Pr.01-11 setting. Pr.01-00 setting is regarded as 100.0%.
- This setting will limit the max. Output frequency of drive. If frequency setting is higher than Pr.01-10, the output frequency will be limited by Pr.01-10 setting.
- When the drive starts the function of slip compensation (Pr.07-27) or PID feedback control, drive output frequency may exceed frequency command but still be limited by this setting.
- Related parameters: Pr.01-00 Max. Operation Frequency and Pr.01-11 Output Frequency Lower Limit



V/f curve

- 📖 This setting will limit the min. output frequency of drive. When drive frequency command or feedback control frequency is lower than this setting, drive output frequency will limit by the lower limit of frequency.
- 📖 When the drive starts, it will operate from min. output frequency (Pr.01-05) and accelerate to the setting frequency. It won't limit by this parameter setting.
- 📖 The setting of output frequency upper/lower limit is used to prevent the personal misoperation, the overheat due to too low operation frequency and the damage due to too high speed.
- 📖 If the output frequency upper limit setting is 50Hz and frequency setting is 60Hz, max. output frequency will be 50Hz.
- 📖 If the output frequency lower limit setting is 10Hz and min. operation frequency setting (Pr.01-05) is 1.5Hz, it will operate by 10Hz when the frequency command is greater than Pr.01-05 and less than 10Hz. If the frequency command is less than Pr.01-05, the drive will be in ready status and no output.
- 📖 If the frequency output upper limit is 60Hz and frequency setting is also 60Hz, it won't exceed 60Hz even after slip compensation. If the output frequency needs to exceed 60Hz, it can increase output frequency upper limit or max. operation frequency.










- ↘ 01 - 12 Accel. Time 1
- ↘ 01 - 13 Decel. Time 1
- ↘ 01 - 14 Aceel. Time 2
- ↘ 01 - 15 Decel. Time 2
- ↘ 01 - 16 Accel. Time 3
- ↘ 01 - 17 Decel. Time 3
- ↘ 01 - 18 Accel. Time 4
- ↘ 01 - 19 Decel. Time 4
- ↘ 01 - 20 JOG Acceleration Time


01 - 21 JOG Deceleration Time

Factory Setting: 10.00/10.0

Settings Parameters 01-45=0 : 0.00~600.00 seconds

Parameters 01-45=1 : 0.0~6000.0 seconds





-  The Acceleration Time is to determine the length of time required for the AC motor drive to ramp from 0.0 Hz to Maximum Output Frequency (Pr.01-00). The Deceleration Time is to determine the length of time required for an AC motor drive to decrease from Maximum Output Frequency (Pr.01-00) to 0.00Hz.
-  The Acceleration/Deceleration Time is invalid when using Pr.01-44 Optimal Acceleration/Deceleration Setting.
-  The Acceleration/Deceleration Time 1, 2, 3, 4 are selected according to the Multi-function Input Terminals settings. The factory settings are Accel./Decel. Time 1.
-  When enabling torque limits and stalls prevention function, actual accel./decel. time will be longer than the above action time.
-  Please note that it may trigger the protection function (Pr.06-03 Over-current Stall Prevention during Acceleration or Pr.06-01 Over-voltage Stall Prevention) when the setting of accel./decel. time is too short.
-  Please note that it may cause motor damage or drive protection enabled due to over current during acceleration when the setting of acceleration time is too short.
-  Please note that it may cause motor damage or drive protection enabled due to over current during deceleration or over-voltage when the setting of deceleration time is too short.
-  It can use suitable brake resistor (see Chapter 06 Accessories) to decelerate in a short time and prevent over-voltage.
-  When enabling Pr.01-24~Pr.01-27, the actual accel./decel. time will be longer than the setting.



01 - 22 JOG Frequency (JOG)

Factory Setting: 6.00


Settings 0.00~600.00Hz


-  Both external terminal JOG and key “F1” on the keypad KPC-CC01 can be used. When the jog command is ON, the AC motor drive will accelerate from 0Hz to jog frequency (Pr.01-22). When the jog command is OFF, the AC motor drive will decelerate from Jog Frequency to zero. The Jog Accel./Decel. time (Pr.01-20, Pr.01-21) is the time that accelerates from 0.0Hz to Pr.01-22 JOG Frequency.
-  The JOG command can't be executed when the AC motor drive is running. In the same way, when the JOG command is executing, other operation commands are invalid except forward/reverse commands and STOP key on the digital keypad.
-  The optional keypad KPC-CE01 doesn't support JOG function.
- 

01 - 23 Frequency of 1st Acceleration / Deceleration & Frequency of 4th Acceleration / Deceleration.

Factory Setting: 0.00

Settings 0.00~600.00Hz

-  The transition from acceleration/deceleration time 1 to acceleration/deceleration time 4, may also be enabled by the external terminals. The external terminal has priority over Pr. 01-23.



1st/4th Acceleration/Deceleration Switching

01 - 24 S-curve for Acceleration Departure Time 1

01 - 25 S-curve for Acceleration Arrival Time 2

01 - 26 S-curve for Deceleration Departure Time 1


01 - 27 S-curve for Deceleration Arrival Time 2

Factory Setting: 0.20/0.2

Settings Parameter 01-45=0 : 0.00~25.00 seconds

Parameter 01-45=1 : 0.00~250.0 seconds

- 📖 It is used to give the smoothest transition between speed changes. The accel./decel. curve can adjust the S-curve of the accel./decel. When it is enabled, the drive will have different accel./decel. curve by the accel./decel. time.
- 📖 The S-curve function is disabled when accel./decel. time is set to 0.
- 📖 When Pr.01-12, 01-14, 01-16, 01-18 \geq Pr.01-24 and Pr.01-25,
the Actual Accel. Time = Pr.01-12, 01-14, 01-16, 01-18 + (Pr.01-24 + Pr.01-25)/2
- 📖 When Pr.01-13, 01-15, 01-17, 01-19 \geq Pr.01-26 and Pr.01-27,
the Actual Decel. Time = Pr.01-13, 01-15, 01-17, 01-19 + (Pr.01-26 + Pr.01-27)/2




- 01 - 28 Upper limit of Frequency 1 setting not allowed
- 01 - 29 Lower limit of Frequency 1 setting not allowed
- 01 - 30 Upper limit of Frequency 2 setting not allowed
- 01 - 31 Lower limit of Frequency 2 setting not allowed
- 01 - 32 Upper limit of Frequency 3 setting not allowed
- 01 - 33 Lower limit of Frequency 3 setting not allowed

Factory Setting: 0.00

Settings 0.00~600.00Hz

- 📖 These parameters are used to set the skip frequency of the AC drive. But the frequency output is continuous. There is no limit for the setting of these six parameters and can be used as required.
- 📖 These parameters are used to set the skip frequency of the AC drive. But the frequency output is continuous. The limit of these six parameters is 01-28 \geq 01-29 \geq 01-30 \geq 01-31 \geq 01-32 \geq 01-33. This function will be invalid when setting to 0.0.
- 📖 The skip frequencies are useful when a motor has vibration at a specific frequency bandwidth. By skipping this frequency, the vibration will be avoided. It offers 3 zones for use.
- 📖
- 📖 The setting of frequency command (F) can be set within the range of skip frequencies. At this moment, the output frequency (H) will be limited by these settings.
- 📖 When accelerating/decelerating, the output frequency will still pass the range of skip frequencies.




01 - 34 Zero-speed Mode

Factory Setting: 0

- Settings
- 0: Output waiting
 - 1: Zero-speed operation
 - 2: Output at Minimum Frequency (the 4th output)

- 📖 When the frequency is less than F_{min} (Pr.01-07 or Pr.01-41), it will operate by this parameter.
- 📖 When it is set to 0, the AC motor drive will be in waiting mode without voltage output from terminals U/V/W.
- 📖 When it is set to 1, it will execute DC brake by V_{min} (Pr.01-08 and Pr.01-42) in V/F and SVC modes.
- 📖 When it is set to 2, the AC motor drive will run by F_{min} (Pr.01-07, Pr.01-41) and V_{min} (Pr.01-08, Pr.01-42) in V/F and SVC modes.
- 📖 In V/F and SVC modes



01 - 35 Motor 2: Max Output Frequency (Hz) (Base Frequency/Motor Rated Frequency)


Factory Setting: 60.00/50.00


- Settings 0.00~600.00Hz

01 - 36 Motor 2: Max Output Voltage (V) (Base Voltage/Motor Rated Voltage)

Factory Setting: 200.0/400.0

Settings 230V series 0.0~255.0V
460V series 0.0~510.0V


 The setting of this parameter follows that rated output voltage on the nameplate. If the motor uses 220V, then the setting will be 220.0V. If the motor uses 200V, then the setting will be 200.0V.

 There are several kinds of motor available in the market and the power systems differ from country to country. The most feasible and simplest way to solve this issue is to install a variable frequency drive such as CP2000. Then problems such as different voltage and frequency will be easily solved to bring a motor into full play.

01 - 37 Motor 2: Middle Output Frequency 1

Factory Setting: 3.00

Settings 0.00~600.00Hz

 **01 - 38** Motor 2: Middle Output Voltage 1

Factory Setting: 11.0/22.0

Settings 230V series 0.0~240.0V
460V series 0.0~480.0V

01 - 39 Motor 2: Middle Output Frequency 2

Factory Setting: 0.50

Settings 0.00~600.00Hz

 **01 - 40** Motor 2: Middle Output Voltage 2

Factory Setting: 4.0/8.0

Settings 230V series 0.0~240.0V
460V series 0.0~480.0V

01 - 41 Motor 2: Minimum Output Frequency


Factory Setting: 0.00

Settings 0.00~600.00Hz


 **01 - 42** Motor 2: Minimum Output Voltage

Factory Setting: 0.0/0.0

Settings 230V series 0.0~255.0V
460V series 0.0~510.0V



 The setting of V/F curve usually follows the load characteristics of a motor. If the workload exceed a motor's capacity, pay attentions to its heat dissipation, dynamic balance and bearing lubrication.

- 📖 If the setting of the voltage at low frequency is too high, it might cause a motor to be broken down, be overheated, have stall prevention and/or have over current protection. So please be very careful when setting up parameter to avoid any damages on the motor and the drive.
- 📖 Parameters 01-35 ~ 01-42 are to set up V/F curve of Motor 2. When multi-function input terminals 02-02~ 02-08 and 02-26 ~ 02-31 (expansion card) are set to 14 and enabled, then the drive will operate by following V/F curve of Motor 2.
- 📖 The V/F curve of Motor 1 is shown as below. The V/F Curve of Motor 2 will be the like.




Common setting of V/F curve

(1) General purpose




(2) Fan & Hydraulic Machinery

Motor spec. 60Hz




Motor spec. 50Hz




(3) High Starting Torque

Motor spec. 60Hz



Motor spec. 50Hz



01 – 43 V/F Curve Selection

Factory Setting: 0

Settings 0: V/F curve determined by group 01


1: 1.5 power curve

2: Square curve

- When setting to 0, refer to Pr.01-01~01-08 for motor 1 V/f curve. For motor 2, refer to Pr.01-35~01-42.
- When setting to 1 or 2, the 2nd and the 3rd voltage frequency setting are invalid.
- If a motor load is a variable torque load (the torque is in direct proportion to the speed, such as the load of a fan or a pump), it will decrease input voltage to reduce flux loss and iron loss of the motor at low speed with low load torque to raise the entire efficiency.
- When setting the higher power V/F curve, low frequency torque will be even lower so it is not suitable for fast acceleration/deceleration. It is recommended NOT to apply this parameter for any fast acceleration/deceleration.

01-02

Voltage %




01-01

Frequency%


01 – 44 Optimal Acceleration/Deceleration Setting


Factory Setting: 0


Settings	0: Linear accel. /decel.
	1: Auto accel., Linear decel.
	2: Linear accel., Auto decel.
	3: Auto accel. / decel.
	4: Linear, stall prevention by auto accel./decel. (limit by


 This parameter helps to decrease efficiently the mechanical vibration when a motor starts/stops a load. It auto-detects the torque size of a load, then it will accelerate to reach the frequency of your setting within the shortest time and the smoothest start-up current. It can also auto-detect the re-generated voltage of a load, and then it will decelerate to stop the motor within the shortest time and in a smoothest way.

 Setting 0 Linear accel./decel.: it will accelerate/decelerate according to the setting of Pr.01-12~01-19.

 Setting to Auto accel./decel.: it can reduce the mechanical vibration and prevent the complicated auto-tuning processes. It won't stall during acceleration so a brake resistor is not required. In addition, it can improve the operation efficiency and save energy.

 Setting 3 Auto accel./decel. (auto calculation of the accel./decel. time by actual load): this setting helps to decrease efficiently the mechanical vibration when the drive starts/stops a load. It auto-detects the torque size of a load, then it will accelerate to reach the frequency of your setting within the shortest time and the smoothest start-up current. It can also auto-detect the re-generated voltage of a load, and then it will decelerate to stop the drive within the shortest time and in a smoothest way.

 Setting 4 Stall prevention by auto accel./decel. (limited by 01-12 to 01-21): if the acceleration/deceleration is in a reasonable range, it will accelerate/decelerate in accordance with the setting of Pr.01-12~01-19. If the accel./decel. time is too short, the actual accel./decel. time will be greater than the setting of accel./decel. time.



① When Pr.01-44 is set to 0.

② When Pr.01-44 is set to 3.

01 – 45 Time Unit for Acceleration/Deceleration and S Curve


Factory Setting: 0

Settings 0: Unit 0.01 second
 1: Unit 0.1 second

01 – 46 CANopen Quick Stop Time

Factory Setting: 1.00

Settings Parameter 01-45=0: 0.00~600.00 seconds
 Parameter 01-45=1: 0.0~6000.0 seconds

 It is to set up the length of time required when a drive decelerates from its max. operation frequency (Pr.01-00) to 0.00Hz in CANopen control mode. .

01 – 47
~01 – 50 Reserved

02 Digital Input/Output Parameter

✈ The parameter can be set during operation.

02 - 00 2-wire/3-wire Operation Control

Factory Setting: 0

Settings 0: 2 wire mode 1
 1: 2 wire mode 2
 2: 3 wire mode

📖 This parameter is to set the operation control method. There are three different control modes.

02-00	Control Circuits of the External Terminal	
When the setting is 0 Two-wire mode 1 FWD/STOP REV/STOP		FWD: ("OPEN": STOP) ("CLOSE": FWD) REV: ("OPEN": STOP) ("CLOSE": REV) DCM VFD-CP
When setting is 1 Two-wire mode 2 RUN/STOP FWD/REV REV/FWD		FWD: ("OPEN": STOP) ("CLOSE": RUN) REV: ("OPEN": FWD) ("CLOSE": REV) DCM VFD-CP
3: Three-wire operation control		FWD "CLOSE": RUN MI1 "OPEN": STOP REV/FWD "OPEN": FWD "CLOSE": REV DCM VFD-CP

02 - 01 Multi-function Input Command 1 (MI1) (MI1) When Pr02-00 is set at "3: Three-wire operation control, the terminal M1 becomes the STOP contact

Factory Setting: 1

02 - 02 Multi-function Input Command 2 (MI2)

Factory Setting: 2

02 - 03 Multi-function Input Command 3 (MI3)

Factory Setting: 3

02 - 04 Multi-function Input Command 4 (MI4)

Factory Setting: 4

02 - 05 Multi-function Input Command 5 (MI5)

02 - 06 Multi-function Input Command 6 (MI6)

02 - 07 Multi-function Input Command 7 (MI7)

02 - 08 Multi-function Input Command 8 (MI8)

02 - 26 Input terminal of I/O extension card (MI10)

02 - 27	Input terminal of I/O extension card (MI11)
02 - 28	Input terminal of I/O extension card (MI12)
02 - 29	Input terminal of I/O extension card (MI13)
02 - 30	Input terminal of I/O extension card (MI14)
02 - 31	Input terminal of I/O extension card (MI15)

Factory Setting: 0

Settings

0: No function

1: multi-step speed command 1

2: multi-step speed command 2

3: multi-step speed command 3

4: multi-step speed command 4

5: Reset

6: JOG command (By KPC-CC01 or external control)

7: acceleration/deceleration speed not allow

8: the 1st, 2nd acceleration/deceleration time selection9: the 3rd, 4th acceleration/deceleration time selection

10: EF Input (Pr.07-20)

11 : B.B input from external (Base Block)

12: Output stop

14: switch between motor 1 and motor 2

15: operation speed command from AVI1

16: operation speed command from ACI

17: operation speed command from AVI2

18: Emergency stop (Pr.07-20)

19: Digital up command

20: Digital down command

21: PID function disabled

22: Clear counter

23: Input the counter value (MI6)

24: FWD JOG command

25: REV JOG command

28: Emergency stop (EF1)

29: Signal confirmation for Y-connection

30: Signal confirmation for Δ -connection

38 : Disable write EEPROM function

40: Enforced coast to stop

41 : HAND switch

42 : AUTO switch

44~47: Reserved

49: Drive enabled

51: Selection for PLC mode bit 0

52: Selection for PLC mode bit 1

53: Triggered CANOpen quick stop

54: UVW Magnetic Contactor On/OFF

55: Confirmation signal of the released brake

56: Max. Reverse Disabled

57: Max. Forward Disabled

58: Enable fire mode (with RUN Command)

59: Enable fire mode (without RUN Command)

60: Disable all the motors

- 61: Disable Motor#1
- 62: Disable Motor#2
- 63: Disable Motor#3
- 64: Disable Motor#4 disabled
- 65: Disable Motor #5 disabled
- 66: Disable Motor#6 disabled
- 67: Disable Motor#7 disabled
- 68: Disable Motor#8 disabled







-
-  This parameter selects the functions for each multi-function terminal.
 -  Parameter 02-26 to 02-31 will be physical input terminals after expansion cards are installed. If there is no expansion cards installed, these parameters remain virtual terminals. For example, after installing the multiple function expansion card “EMC-D42A”, Parameter 02-26 to 02-29 are defined as corresponding parameters for terminals MI10 to MI13. But Parameters 02-30 to 02-31 are still virtual terminals.
 -  When terminals are defined as virtual, you need a digital keypad such as KPC-CC01 or a communication mode to modify status of bit 8~15 (0 means ON, 1 means OFF) at Parameter 02-12.
 -  If the setting of the Parameter 02-00 is "2: 3 wire mode," then the terminal MI 1 becomes a STOP contact .So the function which was set at this terminal is automatically disabled.

Table of Functions

**(for Normally Open (N.O.) Contacts , ON means contact is CLOSED;
OFF means contact is OPEN)**

Settings	Functions	Descriptions
0	No Function	
1	Multi-step speed command 1 /Multi-step position command 1	15-step speeds or 15-step positions could be conducted through the digital status of the 4 terminals. It will be 16 in total if the master speed is included. (Refer to Parameter set 4)
2	Multi-step speed command 2 /Multi-step position command 2	
3	Multi-step speed command 3 /Multi-step position command 3	
4	Multi-step speed command 4 /Multi-step position command 4	
5	Reset	After the error of the drive is eliminated, use this terminal to reset the drive.

Settings	Functions	Descriptions
6	JOG Command	<p>Before executing this function, wait for the drive stop completely. While the drive is running, the operating direction can be modified and STOP key on the keypad is still valid. Once the external terminal receives OFF command, the motor will stop by the JOG deceleration time. Refer to Pr.01-20~01-22 for details.</p> 
7	Acceleration / Deceleration Speed Inhibit	<p>When this function is enabled, the acceleration and deceleration are stopped right away. After this function is disabled, the AC motor drive re-starts to accel./decel. from the inhibiting point.</p> 
8	The 1 st , 2 nd acceleration or deceleration time selection	<p>The acceleration/deceleration time of the drive can be selected from this function or the digital status of the terminals; there are 4 acceleration/deceleration speeds in total for selection.</p>
9	The 3 rd , 4 th acceleration or deceleration time selection	
10	EF Input (EF: External Fault)	<p>External fault input terminal. It decelerates by Pr.07-20 setting (If there is any External Fault, it will be saved in an error log)</p>
11	External B.B. Input (Base Block)	<p>07-08 ◦ When this contact is ON, output of the drive will be cut off immediately, and the motor will be free run and display B.B. signal. Refer to Pr.07-08 for details.</p>

Settings	Functions	Descriptions
12	Output stop	<p>If this contact is ON, output of the drive will be cut off immediately, and the motor will then be free run. Once it is turned to OFF, the drive will accelerate to the setting frequency</p> <p>Mix-GND ON OFF ON</p> <p>Operation command ON</p>
13	Cancel the setting of the optimal accel./decel. time	Before using this function, Pr.01-44 should be set to mode 01, 02, 03 or 04 first. When this function is enabled, OFF is for auto mode and ON is for linear accel./decel.
14	Switch between drive settings 1 and 2	When the contact is ON: use parameters of motor 2. When it is OFF: use parameters of motor 1.
15	Operation speed command form AVI1	When the contact is ON, the source of the frequency has to be from AVI1. (If the operation speed commands are set to AVI1, ACI and AVI2 at the same time. The priority is AVI1 > ACI > AVI2)
16	ACI Operation speed command form ACI	When the contact is ON, the source of the frequency has to be from ACI. (If the operation speed commands are set to AVI1, ACI and AVI2 at the same time. The priority is AVI1 > ACI > AVI2)
17	Operation speed command form AVI2 I	When this function is enabled, the source of the frequency has to be from AVI2. (If the operation speed commands are set to AVI1, ACI and AVI2 at the same time. The priority is AVI1 > ACI > AVI2)
18	Emergency Stop (07-20)	When the contact is ON, the drive will ramp to stop by setting of Pr.07-20.
19	Digital Up command	When the contact is ON, the frequency of the drive will be increased or decreased by one unit (Parameter 02-00). If this function is constantly ON, the frequency will be increased or decreased by setting of Pr.02-09 or Pr.02-10.
20	Digital Down Command	
21	PID function disabled	When the contact is ON, the PID function is disabled
22	Clear counter	When the contact is ON, it will clear current counter value and display "0". Only when this function is disabled, it will keep counting upward.
23	Input the counter value (multi-function input command 6)	The counter value will increase 1 once the contact is ON. It needs to be used with Pr.02-19.

Settings	Functions	Descriptions												
24	FWD JOG command	When the contact is ON, the drive will execute forward Jog command. When execute JOG command under torque mode, the drive will automatically switch to speed mode; after JOG command is done, the drive will return to torque mode.												
25	REV JOG command	When the contact is ON the drive will execute reverse Jog command. When execute JOG command under torque mode, the drive will automatically switch to speed mode; after JOG command is done, the drive will return to torque mode.												
28	Emergency stop (EF1)	<p>When the contact is ON, the drive will execute emergency stop and display EF1 on the keypad. The motor stays in the free run until the error is cleared. (terminal's status is back to normal). Only after pressing RESET" (EF: External Fault), the motor can continue to run.</p> <p>Mix-GND: ON, OFF, ON Reset: ON, OFF Operation command: ON</p>												
29	Signal confirmation for Y-connection	When the control mode is V/F and the contact is ON, the drive will operate by following the 1st V/F.												
30	Signal confirmation for Δ connection	When the control mode is V/F and contact is ON, the drive will operate by following the 2nd V/F.												
38	Disable EEPROM write function	When this contact is ON, write to EEPROM is disabled.												
40	Enforced coast to stop	When this contact is ON during an operation, the drive will free run to stop.												
41	HAND switch	<ul style="list-style-type: none"> <input checked="" type="checkbox"/> When multi-function input terminal is switched OFF, it executes a STOP command. That means when switching to OFF during the operation, the drive will also stop. <input checked="" type="checkbox"/> When switching by the keypad KPC-CC01 during an operation, the drive will be switched to the status after stop. <input checked="" type="checkbox"/> When a command is entered via a keypad such as KPC-CC01, the drive will stop for few seconds then switch to the status in accordance with that command. <input checked="" type="checkbox"/> Digital keypad displays the drive's status such as HAND/OFF/AUTO <table border="1" style="margin-left: 40px;"> <thead> <tr> <th></th> <th>Bit 1</th> <th>Bit 0</th> </tr> </thead> <tbody> <tr> <td>OFF</td> <td>0</td> <td>0</td> </tr> <tr> <td>AUTO</td> <td>0</td> <td>1</td> </tr> <tr> <td>HAND</td> <td>1</td> <td>0</td> </tr> </tbody> </table>		Bit 1	Bit 0	OFF	0	0	AUTO	0	1	HAND	1	0
	Bit 1		Bit 0											
OFF	0	0												
AUTO	0	1												
HAND	1	0												
42	AUTO switch													

		OFF	1	1																
Settings	Functions	Descriptions																		
44 ~ 47	Reserved																			
49	Drive enabled	When drive = Enabled, RUN command is valid. When drive = Disabled, RUN command is invalid. When drive is in an Operation, motor coast to stop.																		
51	Selection for PLC mode bit0	<table border="1"> <thead> <tr> <th>PLC status</th> <th>Bit 1</th> <th>Bit 0</th> </tr> </thead> <tbody> <tr> <td>Disable PLC function (PLC 0)</td> <td>0</td> <td>0</td> </tr> <tr> <td>Trigger PLC to operation (PLC 1)</td> <td>0</td> <td>1</td> </tr> <tr> <td>Trigger PLC to stop (PLC 2)</td> <td>1</td> <td>0</td> </tr> <tr> <td>No function</td> <td>1</td> <td>1</td> </tr> </tbody> </table>				PLC status	Bit 1	Bit 0	Disable PLC function (PLC 0)	0	0	Trigger PLC to operation (PLC 1)	0	1	Trigger PLC to stop (PLC 2)	1	0	No function	1	1
PLC status	Bit 1					Bit 0														
Disable PLC function (PLC 0)	0					0														
Trigger PLC to operation (PLC 1)	0					1														
Trigger PLC to stop (PLC 2)	1	0																		
No function	1	1																		
52	Selection for PLC mode bit1																			
53	Triggered CANopen quick stop	When this function is triggered under CANopen control, the drive will change its status to quick stop.																		
	UVW magnetic contactor ON/OFF	To receive confirmation signals while there is UVW magnetic contactor during output.																		
55	Confirmation signal of released brake	When a motor has a mechanical brake, this function is to confirm a brake has been released.																		
56	Max. Reverse Disabled	To set maximum value while Reverse and Forward operations have a limit switch to do reciprocating actions.																		
57	Max. Forward Disabled																			
58	Enable fire mode with RUN Command	Enable this function under fire mode to force the drive to run (while there is RUN COMMAND).																		
59	Enable fire mode without RUN Command	Enable this function under fire mode to force the drive to run (while there isn't RUN COMMAND).																		
60	Disable all the motors																			
61	Disable Motor#1	If any of Auxiliary Motor#1 to Motor#8 is out of order or under maintenance, enable this terminal to bypass that motor.																		
62	Disable Motor#2																			
63	Disable Motor#3																			
64	Disable Motor#4																			
65	Disable Motor#5																			
66	Disable Motor#6																			
67	Disable Motor#7																			
68	Disable Motor#8																			

02 - 09 UP/DOWN Key Mode

Factory Setting: 0

Settings 0 : UP/DOWN by the accel./decal. Time
1 : UP/DOWN constant speed (by parameter 02-10)


02 - 10 The Acceleration/Deceleration Speed of the UP/DOWN Key with Constant Speed

Factory Setting: 0.01


Settings 0.01~1.00Hz/ms

These settings are used when multi-function input terminals are set to 19 or 20. Refer to Pr.02-09 and 02-10 for the frequency up/down command.

When Pr.02-09 is set to 0: press the external terminal UP/DOWN key as shown in the following diagram to increase/decrease the frequency command (F). In this mode, it also can be controlled by UP/DOWN key on the digital keypad.



Pr.02-09 set to 1: it will increase/decrease frequency command (F) by the setting of acceleration/deceleration (Pr.01-12~01-19) and only be valid during operation.



02 - 11 Digital Input Response Time

Factory Setting: 0.005

Settings 0.000~30.000 seconds

This parameter is to set the response time of digital input terminals FWD, REV and MI1~MI8.

It is for digital input terminal signal delay and confirmation. The delay time is confirmation time to prevent some uncertain interference that would cause error in the input of the digital terminals. Under this condition, confirmation for this parameter would improve effectively, but the response time will be somewhat delayed.

02 - 12 Multi-function Input Mode Selection

Factory Setting: 0

Settings 0~65535 (0:N.O. ; 1:N.C.)

📖 The setting of this parameter is in hexadecimal.

📖 This parameter is to set the input signal level and it won't be affected by the SINK/SOURCE status.

📖 Bit0 is for FWD terminal, bit1 is for REV terminal and bit2 to bit15 is for MI1 to MI14.

📖 User can change terminal status by communicating.

For example, MI1 is set to 1 (multi-step speed command 1), MI2 is set to 2 (multi-step speed command 2). Then the forward + 2nd step speed command=1001(binary)= 9 (Decimal). Only need to set Pr.02-12=9 by communication and it can forward with 2nd step speed. It doesn't need to wire any multi-function terminal.

Bit15	bit14	bit13	bit12	bit11	bit10	bit9	bit8	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
MI14	MI13	MI12	MI11	MI10	MI9	MI8	MI7	MI6	MI5	MI4	MI3	MI2	MI1	REV	FWD

02 - 13 Relay1: Multi Output Terminal

Factory Setting: 11

02 - 14 Relay2: Multi Output Terminal

Factory Setting: 1

02 - 15 Relay3: Multi Output Terminal

Factory Setting: 0

02 - 16 Reserved

02 - 17 Reserved

02 - 36 Expansion Card Output Terminal (MO3)

02 - 37 Expansion Card Output Terminal (MO4)

02 - 38 Expansion Card Output Terminal (MO5)

02 - 39 Output terminal of the I/O extension card (MO6)

02 - 40 Output terminal of the I/O extension card (MO7)

02 - 41 Output terminal of the I/O extension card (MO8)

02 - 42 Output terminal of the I/O extension card (MO9)

02 - 43 Output terminal of the I/O extension card (MO10)

02 - 44 Output terminal of the I/O extension card (MO11)

02 - 45 Output terminal of the I/O extension card (MO12)


02 - 46 Output terminal of the I/O extension card (MO13)


Factory Setting: 0


Settings:


- 0: No function
- 1: Operation Indication
- 2: Operation speed attained
- 3: Desired Frequency Attained 1 (Parameter 02-22)
- 4: Desired Frequency Attained 2 (Parameter 02-24)
- 5: Zero speed (Frequency command)
- 6: Zero speed, include STOP(Frequency command)
- 7: Over torque 1
- 8: Over torque 2
- 9: Drive is ready
- 10: Low voltage warning (LV) (Pr.06-00)
- 11: Malfunction indication
- 12: Mechanical brake release(Pr.02-32)
- 13: Overheat warning (Pr.06-15)
- 14: Software brake signal indication(Pr.07-00)
- 15: PID feedback error
- 16: Slip error (oSL)
- 17: Terminal count value attained, does not return to 0
(Pr.02-20)
- 18: Preliminary count value attained, returns to 0
(Pr.02-19)
- 19: Base block
- 20: Warning output
- 21: Over voltage warning
- 22: Over-current stall prevention warning
- 23: Over-voltage stall prevention warning
- 24: Operation mode indication
- 25: Forward command
- 26: Reverse command
- 27: Output when current \geq Pr.02-33 (\geq 02-33)
- 28: Output when current \leq Pr.02-33 (\leq 02-33)
- 29: Output when frequency \geq Pr.02-34 (\geq 02-34)
- 30: Output when frequency \leq Pr.02-34 (\leq 02-34)
- 31: Y-connection for the motor coil
- 32: Δ -connection for the motor coil
- 33: Zero speed (actual output frequency)
- 34: Zero speed include stop(actual output frequency)
- 35: Error output selection 1(Pr.06-23)


- 36: Error output selection 2(Pr.06-24)
- 37: Error output selection 3(Pr.06-25)
- 38: Error output selection 4(Pr.06-26)
- 40: Speed attained (including Stop)
- 44: Low current output
- 45: UVW Magnetic Contactor enabled
- 47: Brake output closed
- 50: Output for CANopen control
- 51: Output for RS485
- 52: Output for communication card
- 53: Fire mode indication
- 54: Bypass fire mode indication
- 55: Motor #1 Output
- 56: Motor #2 Output
- 57: Motor #3 Output
- 58: Motor#4 Output
- 59: Motor#5 Output
- 60: Motor #6 Output
- 61: Motor#7 Output
- 62: Motor#8 Output

 This parameter selects the functions for each multi-function terminal.

 The terminals of Pr.02-36~Pr.02-41 will only be displayed after using with optional card EMC-D42A and EMC-R6AA

 The optional card EMC-D42A offers 2 output terminals and can be used with Pr.02-36~02-37.

 The optional card EMC-R6AA offers 6 output terminals and can be used with Pr.02-36~02-41


 Summary of function settings (Take the normally open contact for example, ON: contact is closed, OFF: contact is open)

Settings	Functions	Descriptions
0	No Function	This terminal has no function.
1	Operation Indication	Active when the drive is not at STOP.
2	Master Frequency Attained	Active when the AC motor drive reaches the output frequency setting.
3	Desired Frequency Attained 1 (Pr.02-22)	Active when the desired frequency (Pr.02-22) is attained.
4	Desired Frequency Attained 2 (Pr.02-24)	Active when the desired frequency (Pr.02-24) is attained.
5	Zero Speed (frequency command)	Active when frequency command =0. (the drive should be at RUN mode)
6	Zero Speed with Stop (frequency command)	Active when frequency command =0 or stop.
7	Over Torque 1	Active when detecting over-torque. Refer to Pr.06-07 (over-torque detection level-OT1) and Pr.06-08 (over-torque detection time-OT1). Refer to Pr.06-06~06-08.
8	Over Torque 2	Active when detecting over-torque. Refer to Pr.06-10 (over-torque detection level-OT2) and Pr.06-11 (over-torque detection time-OT2). Refer to Pr.06-09~06-11.


Settings	Functions	Descriptions
9	Drive Ready	Active when the drive is ON and no abnormality detected.
10	Low voltage warn (Lv)	Active when the DC Bus voltage is too low. (refer to Pr.06-00 low voltage level)
11	Malfunction Indication	Active when fault occurs (except Lv stop).
12	Mechanical Brake Release (Pr.02-32)	When drive runs after Pr.02-32, it will be ON. This function should be used with DC brake and it is recommended to use contact "b"(N.C).
13	Overheat	Active when IGBT or heat sink overheats to prevent OH turn off the drive. (refer to Pr.06-15)
14	Software Brake Signal Indication	Active when the soft brake function is ON. (refer to Pr.07-00)
15	PID Feedback Error	Active when the feedback signal is abnormal.
16	Slip Error (oSL)	Active when the slip error is detected.
17	Terminal Count Value Attained (Pr.02-20; not return to 0)	Active when the counter reaches Terminal Counter Value (Pr.02-19). This contact won't active when Pr.02-20>Pr.02-19.
18	Preliminary Counter Value Attained (Pr.02-19; returns to 0)	Active when the counter reaches Preliminary Counter Value (Pr.02-19).
19	External Base Block input (B.B.)	Active when the output of the AC motor drive is shut off during base block.
20	Warning Output	Active when the warning is detected.
21	Over-voltage Warning	Active when the over-voltage is detected.
22	Over-current Stall Prevention Warning	Active when the over-current stall prevention is detected.
23	Over-voltage Stall prevention Warning	Active when the over-voltage stall prevention is detected.
24	Operation Mode Indication	Active when the operation command is controlled by external terminal. (Pr.00-20≠0)
25	Forward Command	Active when the operation direction is forward.
26	Reverse Command	Active when the operation direction is reverse.
27	Output when Current >= Pr.02-33	Active when current is >= Pr.02-33.
28	Output when Current <= Pr.02-33	Active when current is <= Pr.02-33.
29	Output when frequency >= Pr.02-34	Active when frequency is >= Pr.02-34.
30	Output when Frequency <= Pr.02-34	Active when frequency is <= Pr.02-34.
31	Y-connection for the Motor Coil	Active when PR.05-24 is less than Pr.05-23 and time is more than Pr.05-25.
32	△-connection for the Motor Coil	Active when PR.05-24 is higher than Pr.05-23 and time is more than Pr.05-25.
33	Zero Speed (actual output frequency)	Active when the actual output frequency is 0. (the drive should be at RUN mode)
34	Zero Speed with Stop (actual output frequency)	Active when the actual output frequency is 0 or Stop.
35	Error Output Selection 1 (Pr.06-23)	Active when Pr.06-23 is ON.
36	Error Output Selection 2 (Pr.06-24)	Active when Pr.06-24 is ON.
37	Error Output Selection 3 (Pr.06-25)	Active when Pr.06-25 is ON.
38	Error Output Selection 4 (Pr.06-26)	Active when Pr.06-26 is ON.

Settings	Functions	Descriptions
40	Speed Attained (including zero speed)	Active when the output frequency reaches frequency setting or stop
44	Low Current Output	This function needs to be used with Pr.06-71 ~ Pr.06-73
45	UVW Magnetic Contactor enabled	
47	Brake Released at Stop	<p>When drive stops, the corresponding multi-function terminal will be ON if the frequency is less than Pr.02-34. After it is ON, it will be OFF when brake delay time exceeds Pr.02-32.</p>
50	Output for CANopen control	For CANopen communication output
51	Output for RS-485	For RS-485 output
52	Out put for communication card	For CMC-MOD01, CMC-EIP01, CMC-PN01, CMC-DN01 communication control to do output

Example of crane function



It is recommended to be used with Dwell function as shown in the following:



02 - 18 Multi-output Direction

Factory Setting: 0

Settings 0~65535 (0:N.O. ; 1:N.C.)

The setting of this parameter is in hexadecimal.

This parameter is set via bit setting. If a bit is 1, the corresponding output acts in the opposite way. For example: If Pr02-13=1, Relay 1 is open when the drive runs and is closed when the drive is stopped

Bit15	bit14	bit13	bit12	bit11	bit10	bit9	bit8	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
MO20	MO19	MO18	MO17	MO16	MO15	MO14	MO13	MO12	MO11	MO10	MO2	MO1	保留	RY2	RY1

02 - 19 Terminal count value attained (returns to 0)

Factory Setting: 0

Settings 0~65500

The counter trigger can be set by the multi-function terminal MI6 (set Pr.02-06 to 23). Upon completion of counting, the specified output terminal will be activated (Pr.02-13~02-14, Pr.02-36, 02-37 is set to 18). Pr.02-19 can't be set to 0.

When the display shows c5555, the drive has counted 5,555 times. If display shows c5555●, it means that real counter value is between 55,550 to 55,559.


02 - 20 Preliminary count value attained (not return to 0)

Factory Setting: 0

Settings 0~65500

When the counter value counts from 1 and reaches this value, the corresponding multi-function output terminal will be activated, provided one of Pr. 02-13, 02-14, 02-36, 02-37 set to 17 (Preliminary Count Value Setting). This parameter can be used for the end of the counting to make the drive runs from the low speed to stop.

See the sequence diagram below:



02 - 21 Digital Output Gain (DFM)

Factory Setting: 1

Settings 1~166

It is used to set the signal for the digital output terminals (DFM-DCM) and digital frequency output (pulse X work period=50%). Output pulse per second = output frequency X Pr.02-21.

02 - 22 Desired Frequency Attained 1

Factory Setting: 60.00/50.00

Settings 0.00~600.00Hz

02 - 24 Desired Frequency Attained 2

Factory Setting: 60.00/50.00

Settings 0.00~600.00Hz

02 - 23 The Width of the Desired Frequency Attained 1

Factory Setting: 2.00


Settings 0.00~600.00Hz

02 - 25 The Width of the Desired Frequency Attained 2

Factory Setting: 2.00

Settings 0.00~600.00Hz

Once output frequency reaches desired frequency and the corresponding multi-function output terminal is set to 3 or 4 (Pr.02-13, 02-14, 02-36, and 02-37), this multi-function output terminal will be ON.




02 - 32 Brake Delay Time


Factory Setting: 0.000

Settings 0.000~65.000 seconds

When the AC motor drive runs after Pr.02-32 delay time, the corresponding multi-function output terminal (12: mechanical brake release) will be ON. It is recommended to use this function with DC brake.



If this parameter is applied without DC brake, it will be invalid. Refer to the following operation timing.



02 - 33 Output Current Level Setting for Multi-function Output Terminals

Factory Setting: 0

Settings 0~100%

- 📖 When output current is larger or equal to Pr.02-33, it will activate multi-function output terminal (Pr.02-13, 02-14, 02-16, and 02-17 is set to 27).
- 📖 When output current is smaller than Pr.02-33, it will activate multi-function output terminal (Pr.02-13, 02-14, 02-16, 02-17 is set to 28).

02 - 34 Output Boundary for Multi-function Output Terminals

Factory Setting: 0.00

Settings 0.00~±60.00Hz

- 📖 When output frequency is higher than Pr.02-34, it will activate the multi-function terminal (Pr.02-13, 02-14, 02-16, 02-17 is set to 29).
- 📖 When output frequency is lower than Pr.02-34, it will activate the multi-function terminal (Pr.02-13, 02-14, 02-16, 02-17 is set to 30)

02 - 35 External Operation Control Selection after Reset and Activate

Factory Setting: 0

Settings 0: Disable

1: Drive runs if the run command still exists after reset or re-boots.

- 📖 Setting 1:
 - Status 1: After the drive is powered on and the external terminal for RUN keeps ON, the drive will run.
 - Status 2: After clearing fault once a fault is detected and the external terminal for RUN keeps ON, the drive can run after pressing RESET key.

02 - 48 Max. Frequency of Resolution Switch

Factory Setting: 60.00


Settings 0.01~600.00Hz

02 - 49 Switch the delay time of Max. output frequency

Factory Setting: 0.000


Settings 0.000~65.000 秒


It is used to improve the unstable speed or unstable position due to the insufficient of analog resolution. It needs to be used with external terminal (set to 43). After setting this parameter, it needs to adjust the analog output resolution of controller simultaneously by this setting.




02 - 50 Display the Status of Multi-function Input Terminal

Factory Setting: 唯讀



 For Example:

If Pr.02-50 displays 0034h (Hex), i.e. the value is 52, and 110100 (binary). It means MI1, MI3 and MI4 are active.



0=ON
1=OFF

Settings

$$= \text{bit}5 \times 2^5 + \text{bit}4 \times 2^4 + \text{bit}2 \times 2^2$$

$$= 1 \times 2^5 + 1 \times 2^4 + 1 \times 2^2$$


$$= 32 + 16 + 4 = 52$$


NOTE

$2^5 = 32$	$2^4 = 16$	$2^3 = 8$	$2^2 = 4$
$2^1 = 2$	$2^0 = 1$		

02 - 51 Status of Multi-function Output Terminal

Factory Setting: Read Only

 For Example:
 If Pr.02-51 displays 000Bh (Hex), i.e. the value is 11, and 1011 (binary). It means RY1, RY2 and MO1 are ON.




NOTE

$2^7 = 128$	$2^6 = 64$	
$2^5 = 32$	$2^4 = 16$	$2^3 = 8$
$2^2 = 4$	$2^1 = 2$	$2^0 = 1$


02 - 52 Display External Output terminal occupied by PLC

Factory Setting: Read Only

P.02-52 shows the external multi-function input terminal that used by PLC.



For Example: When Pr.02-52 displays 0034h(hex) and switching to 110100 (binary), it means MI1, MI3 and MI4 are used by PLC



0: not used by PLC
1: used by PLC

Displays

$$= \text{bit}5 \times 2^5 + \text{bit}4 \times 2^4 + \text{bit}2 \times 2^2$$

$$= 1 \times 2^5 + 1 \times 2^4 + 1 \times 2^2$$


$$= 32 + 16 + 4 = 52$$

NOTE		
2 ¹⁴ = 16384	2 ¹³ = 8192	2 ¹² = 4096
2 ¹¹ = 2048	2 ¹⁰ = 1024	2 ⁹ = 512
2 ⁸ = 256	2 ⁷ = 128	2 ⁶ = 64
2 ⁵ = 32	2 ⁴ = 16	2 ³ = 8
2 ² = 4	2 ¹ = 2	2 ⁰ = 1

02- 53 Display Analog Input Terminal occupied by PLC

Factory Setting: Read Only

Pr.02-53 shows the external multi-function output terminal that used by PLC.




NOTE

$2^7 = 128$	$2^6 = 64$	
$2^5 = 32$	$2^4 = 16$	$2^3 = 8$
$2^2 = 4$	$2^1 = 2$	$2^0 = 1$

For example:

If the value of Pr.02-53 displays 0003h (Hex), it means RY1 and RY2 are used by PLC.




02 - 54 Display the Frequency Command Memory of External Terminal

Factory Setting:

Read Only

Settings Read Only


-
-  When the source of frequency command comes from the external terminal, if Lv or Fault occurs at this time, the frequency command of the external terminal will be saved in this parameter.


03 Analog Input/Output Parameter (↗ The parameter can be set during operation)

↗ 03 - 00	Analog Input 1 (AVI1)	Factory Setting: 1
↗ 03 - 01	Analog Input 2(ACI)	Factory Setting: 1
↗ 03 - 02	Analog Input 3 (AVI2)	Factory Setting: 1

Settings

- 0 : No function
- 1 : Frequency command
- 4 : PID target value (Refer to Group 8)
- 5 : PID feedback signal (Refer to Group 8)
- 6 : PTC thermistor input value
- 11 : PT100 thermistor input value
- 12~17: Reserved

 When it is frequency command, the corresponding value for 0~±10V/4~20mA is 0 – max. output frequency(Pr.01-00)



- ⚡ **03 - 03** Analog Input Bias 1 (AVI1) Factory Setting: 0
 Settings -100.0~100.0%


 📖 It is to set the corresponding AVI1 voltage of the external analog input 0.
- ⚡ **03 - 04** Analog Input Bias 1 (ACI) Factory Setting: 0
 Settings -100.0~100.0%

 📖 It is used to set the corresponding ACI voltage of the external analog input 0.
 📖
- ⚡ **03 - 05** AVI2 Analog Positive Input Bias Factory Setting: 0
 Settings -100.0~100.0%

 📖 It is used to set the corresponding AVI2 voltage of the external analog input 0.
 📖 The relation between external input voltage/current and setting frequency: 0~10V (4-20mA) corresponds to 0-60Hz.
- ⚡ **03 - 06** Reserved Factory Setting: 0
 Settings -

- ⚡ **03 - 07** Positive/negative Bias Mode (AVI1)
 ⚡ **03 - 08** Positive/negative Bias Mode (ACI)
 ⚡ **03 - 09** Positive/negative Bias Mode (AVI2)
 ⚡ **03 - 10** Reserved Factory Setting: 0
 Settings 0: Zero bias
 1: Lower than bias=bias
 2: Greater than bias=bias
 3: The absolute value of the bias voltage while serving as the center
 4: Serve bias as the center

 📖 In a noisy environment, it is advantageous to use negative bias to provide a noise margin. It is recommended NOT to use less than 1V to set the operation frequency.



- 03-11~03-14 gain is positive
- 0 Zero bias
 - 1 Lower than bias =bias
 - 2 Greater than bias=bias
 - 3 The absolute value of the bias voltage while serving as the center
 - 4 Serve bias as the center

- ↘ 03 - 11 Analog Input Gain 1 (AVI1)
- ↘ 03 - 12 Analog Input Gain 2 (ACI)
- ↘ 03 - 13 Analog Positive Input Gain 3 (AVI2)
- ↘ 03 - 14 Analog Negative Input Gain 4 (AVI2)

Factory Setting: 100.0

Settings -500.0~500.0%

📖 Parameters 03-03 to 03-14 are used when the source of frequency command is the analog voltage/current signal.

- ↘ 03 - 15 Analog Input Filter Time (AVI1)
- ↘ 03 - 16 Analog Input Filter Time (ACI)
- ↘ 03 - 17 Analog Input Filter Time (AVI2)

Factory Setting: 0.01

Settings 0.00~20.00 seconds

📖 These input delays can be used to filter noisy analog signal


📖 When the setting of the time constant is too large, the control will be stable but the control response will be slow. When the setting of time constant is too small, the control response will be faster but the control may be unstable. To find the optimal setting, please adjust the setting according to the control stable or response status.

- ↘ 03 - 18 Addition Function of the Analog Input

Factory Setting: 0

Settings 0 : Disable (AVI1 · ACI · AVI2)
1 : Enable

📖 When Pr.03-18 is set to 0 and the analog input setting is the same, the priority for AVI1, ACI and AVI2 are AVI1>ACI>AVI2.



$$F_{\text{command}} = [(a_y - \text{bias}) * \text{gain}] * \frac{F_{\text{max}}(01-00)}{10\text{V or }16\text{mA}}$$

F_{command} : the corresponding

frequency for 10V or 20mA

a_y : 10 or 16mA

bias: Pr.03-03, Pr.03-04, Pr.03-05

gain: Pr.03-11, Pr.03-12, Pr.03-13, Pr.03-14

03 - 19 Loss of the ACI Signal

Factory Setting: 0

- Settings
- 0: Disable
 - 1: Continue operation at the last frequency
 - 2: Decelerate to stop
 - 3: top immediately and display ACE

This parameter determines the behavior when ACI is lost.

When Pr.03-29 is set to 1, it means ACI terminal is for 0-10V voltage input. At this moment, Pr.03-19 will be invalid.

When setting is 1 or 2, it will display warning code “AnL” on the keypad. It will be blinking until the loss of the ACI signal is recovered or drive is stop

03 - 20 Multi-function Output 1 (AFM1)

Factory Setting: 0

03 - 23 Multi-function Output 2 (AFM2)

Factory Setting: 0

Settings 0~23

Function Chart

Settings	Functions	Descriptions
0	Output frequency (Hz)	Max. frequency Pr.01-00 is regarded as 100%.
1	Frequency command (Hz)	Max. frequency Pr.01-00 is regarded as 100%.
2	Motor speed (Hz)	600Hz is regarded as 100%
3	Output current (rms)	(2.5 X rated current) is regarded as 100%
4	Output voltage	(2 X rated voltage) is regarded as 100%
5	DC Bus Voltage	450V (900V)=100%
6	Power factor	-1.000~1.000=100%
7	Power	Rated power is regarded as 100%
8	Output torque	Full-load torque is regarded as 100%

9	AVI1 %	(0~10V=0~100%)
10	ACI %	(0~20mA=0~100%)
22	Analog output for communication card	For communication output (CMC-MOD01, CMC-EIP01, CMC-PN01, CMC-DN01)
23	Constant voltage output	Voltage output level can be controls by Pr.03-32 and Pr03-33. 0~100% of Pr.03-32 corresponds to 0~10V of AFM1.

↗ **03 - 21** Gain for Analog Output 1 (AFM1) Factory Setting: 100.0

↗ **03 - 24** Gain for Analog Output 2 (AFM2) Factory Setting: 100.0

Settings 0~500.0%


📖 It is used to adjust the analog voltage level (Pr.03-20) that terminal AFM outputs.

📖 This parameter is set the corresponding voltage of the analog output 0.

↗ **03 - 22** Analog Output 1 Value in REV Direction (AFM1) Factory Setting: 0

↗ **03 - 25** Analog Output 2 Value in REV Direction (AFM2) Factory Setting: 0

Settings 0: Absolute value in REV direction
 1: Output 0V in REV direction; output 0-10V in FWD direction
 2: Output 5-0V in REV direction; output 5-10V in FWD direction



↗ **03 - 26** Display Low-Pass Filter (AFM1) AFM1 Filter

↗ **03 - 27** Display Low-Pass Filter (AFM2) AFM2 Filter Factory Setting: 0

Settings 0.001~65.535 seconds

03 - 28 AV11 Selection

Factory Setting: 0

- Settings 0: 0-10V
 1: 0-20mA
 2: 4-20mA

03 - 29 ACI Selection

Factory Setting: 0

- Settings 0: 4-20mA
 1: 0-10V
 2: 0-20mA


When changing the input mode, please check if the switch of external terminal (SW3, SW4) corresponds to the setting of Pr.03-28~03-29.

03 - 30 Display Status of PLC Output Terminal

Factory Setting: 0

- Settings 0~65535
 Monitor the status of PLC analog output terminals


P.03-30 shows the external multi-function output terminal that used by PLC



NOTE

$2^7 = 128$	$2^6 = 64$	
$2^5 = 32$	$2^4 = 16$	$2^3 = 8$
$2^2 = 4$	$2^1 = 2$	$2^0 = 1$

For Example:
 If the value of Pr.02-30 displays 0002h(Hex), it means AFM1 and AFM2 are used by PLC.



03 - 31 AFM2 0-20mA Output Selection

Factory Setting: 0

- Settings 0: 0-20mA output
 1: 4-20mA output

03 - 32 AFM1 DC Output Setting Level

03 - 33 AFM2 DC Output Setting Level

Factory Setting: 0.00

Settings 0.00~100.00%

03-50 AI calculated selection

Factory Setting : 0

Settings 0 ~ 7

03-51 AVI Point1 - voltage

Factory Setting : 0.00

Setting 0.00 ~ 10.00 / 0.00 ~ 20.00

03-52 AVI Point 1- percentage

Factory Setting : 0%

Setting 0 ~ 100%

03-53 AVI Point 2- voltage

Factory Setting : 5.00

Setting 0.00 ~ 10.00 / 0.00 ~ 20.00

03-54 AVI Point2-percent

Factory Setting : 50%

Setting 0 ~ 100%

03-55 AVI Point 3 - voltage

Factory Setting : 10.00

Setting 0.00 ~ 10.00 / 0.00 ~ 20.00

03-56 AVI Point 3- percent

Factory Setting : 50%

Setting 0 ~ 100%

03-57 ACI Point 1 – voltage

Factory Setting : 4.00

Setting 0.00 ~ 10.00 / 0.00 ~ 20.00

03-58 ACI Point 1- percent

Factory Setting : 0%

Setting 0 ~ 100%

03-59 ACI Point 2 – voltage

Factory Setting : 12.00

Setting 0.00 ~ 10.00 / 0.00 ~ 20.00

03-60 ACI Point2 - percent

Factory Setting : 50%

Setting 0 ~ 100%

03-61 ACI Point 3 – voltage

Factory Setting : 20.00

Setting 0.00 ~ 10.00 / 0.00 ~ 20.00

03-62 ACI Point3 - percent

Factory Setting : 100

Setting 0 ~ 100%

03-63 AUI Point1 - voltage

Factory Setting : 0V

Setting 0.00 ~ 10.00V

03-64 AUI Point 2- percent

Factory Setting : 0%

Setting 0 ~ 100%

03-65 AUI Point 2- voltage

Factory Setting : 5.00V

Setting 0.00 ~ 10.00V

03-66 AUI Point2 -percent

Factory Setting : 50%

Setting 0 ~ 100%

03-67 AUI Point 3- voltage

Factory Setting :10.00V
















Setting 0.00 ~ 10.00V

03-68 AUI Point 3 - percent

Factory Setting :100%


Setting 0 ~ 100%


04 Multi-Step Speed Parameters The parameter can be set during operation.


	04 - 00	1st Step Speed Frequency
	04 - 01	2nd Step Speed Frequency
	04 - 02	3rd Step Speed Frequency
	04 - 03	4th Step Speed Frequency
	04 - 04	5th Step Speed Frequency
	04 - 05	6th Step Speed Frequency
	04 - 06	7th Step Speed Frequency
	04 - 07	8th Step Speed Frequency
	04 - 08	9th Step Speed Frequency
	04 - 09	10th Step Speed Frequency
	04 - 10	11th Step Speed Frequency
	04 - 11	12th Step Speed Frequency
	04 - 12	13th Step Speed Frequency
	04 - 13	14th Step Speed Frequency
	04 - 14	15th Step Speed Frequency


Factory Setting: 0.00

Settings 0.00~600.00Hz

 The Multi-function Input Terminals (refer to setting 1~4 of Pr.02-01~02-08 and 02-26~02-31) are used to select one of the AC motor drive Multi-step speeds (max. 15 speeds). The speeds (frequencies) are determined by Pr.04-00 to 04-14 as shown in the following.


 The run/stop command can be controlled by the external terminal/digital keypad/communication via Pr.00-21.

 Each one of multi-step speeds can be set within 0.0~600.0Hz during operation

 Explanation for the timing diagram for multi-step speeds and external terminals
The Related parameter settings are:

1. Pr.04-00~04-14: setting multi-step speeds (to set the frequency of each step speed)
2. Pr.02-01~02-08, 02-26~02-31: setting multi-function input terminals (multi-step speed 1~4)

➤ Related parameters: 01-22 JOG Frequency, 02-01 Multi-function Input Command 1 (MI1), 02-02 Multi-function Input Command 2 (MI2), 02-03 Multi-function Input Command 3 (MI3), 02-04 Multi-function Input Command 4 (MI4)



05 Motor Parameters

⚡ The parameter can be set during operation.

05 - 00 Motor Auto Tuning

Factory Setting: 0

- Settings
- 0 : No function
 - 1 : Measure induction motor in dynamic status (motor spinning)
(Rs, Rr, Lm, Lx, no-load current)
 - 2 : Measure induction motor in static status (motor not spinning)

Induction Motor


📖 Start auto tuning by press the **【Run】** key and the measured value will be written into motor 1 (Pr.05-05 ~05-09, Rs, Rr, Lm, Lx, no-load current) and motor 2 (Pr.05-17 to Pr.05-21) automatically.

📖 AUTO-Tuning Process (dynamic motor):

1. Make sure that all the parameters are set to factory settings and the motor wiring is correct.
2. Make sure the motor has no-load before executing auto-tuning and the shaft is not connected to any belt or gear motor. It is recommended to set to 2 if the motor can't separate from the load.
- 3.

	Motor 1	Motor 2
Motor Rated Frequency	01-01	01-35
Motor Rated Voltage	01-02	01-36
Motor Full-load Current	05-01	05-13
Motor Rated Power	05-02	05-14
Motor Rated Speed	05-03	05-15
Motor Pole Numbers	05-04	05-16

4. Set Pr.05-00=1 and press the the **【Run】** key, the drive will begin auto-tuning. Please be aware motor starts spinning when the **【Run】** key is pressed.
5. When auto-tuning is complete, please check if the measured values are written into motor 1 (Pr.05-05 ~05-09) and motor 2 (Pr.05-17 ~05-21) automatically.
6. Mechanical equivalent circuit



※ If Pr.05-00 is set to 2, it needs to input Pr.05-05 for motor 1/Pr.05-17 for motor 2.

NOTE

- ☑ In torque/vector control mode, it is not recommended to have motors run in parallel.
- ☑ It is not recommended to use torque/vector control mode if motor rated power exceeds the rated power of the AC motor drive
- ☑ When auto-tuning 2 motors, it needs to set multi-function input terminals (setting 14) or change Pr.05-22 for motor 1/motor 2 selection 無載電流一般為額定電流之 20~50%。
- ☑ The rated speed can't be larger or equal to 120f/p (f: rated frequency 01-01/01-35; P: number of motor poles 05-04/05-16).

05 - 01 Full-Load Current of Induction Motor 1 (A)

Unit: Ampere

Factory Setting: 0

Settings 10 to 120% of drive's rated current

This value should be set according to the rated frequency of the motor as indicated on the motor nameplate. The factory setting is 90% X rated current

Example: The rated current for 7.5HP (5.5kW) is 25 and factory setting is 22.5A. The range for setting will be 10~30A.(25*40%=10A and 25*120%=30A)

↘ 05 - 02 Rated Power of Induction Motor 1(kW)

Factory Setting: 0

Settings 0~655.35 kW

It is used to set rated power of the motor 1. The factory setting is the power of the drive

↘ 05 - 03 Rated Speed of Induction Motor 1 (rpm)

Factory Setting:

1710 (60Hz 4 poles)

1410 (50Hz 4 poles)

Settings 0~65535

It is used to set the rated speed of the motor and need to set according to the value indicated on the motor nameplate.

05 - 04 Pole Number of Induction Motor 1

Factory Setting: 4

Settings 2~20


It is used to set the number of motor poles (must be an even number).

05 - 05 No-load Current of Induction Motor 1 (A)

Unit: Ampere

Factory Setting: 0

Settings 0 to the factory setting in Pr.05-01

 Factory setting is 40% of the drive's rated current. .**05 - 06** Stator Resistance(Rs) of Induction Motor 1

Factory Setting: 0.000

Settings 0.000~65.535Ω

05 - 07 Rotor Resistance (Rr) of Mo1

Factory Setting : 0

Settings 0.000~65.535Ω

05 - 08 Magnetizing Inductance (Lm) og Induction Motor 1

Factory Setting : 0.0

Settings 0.0~6553.5mH

05 - 09 Stator Inductance (Lx) of Induction Motor 1

Factory Setting : 0.0

Settings 0.0~6553.5mH



	05 - 07	Reserved
	05 -08	
	05 -09	
	05 - 10	
	05 - 11	
	05 - 12	

05 - 13 Full Load Current of Induction Motor 2 (A)

Unit: Ampere

Factory Setting: 0

Settings 10~120%


 This value should be set according to the rated frequency of the motor as indicated on the motor nameplate. The factory setting is 90% X rated current. Example: The rated current for 7.5HP (5.5kW) is 25A and factory setting is 22.5A. The range for setting will be 10~30A.(25*40%=10A and 25*120%=30A)

- ↗ **05 - 14** Rated Power of Induction Motor 2 (kW)
- Factory Setting: ###
- Settings 0~655.35 kW
-
- 📖 It is used to set rated power of the motor 2. The factory setting is the power of the drive.
- ↗ **05 - 15** Rated Speed of Induction Motor 2 (rpm)
- Factory Setting: 1710
1710(60Hz 4 poles) ;
1410(50Hz 4 poles)
- Settings 0~65535
-
- 📖 It is used to set the rated speed of the motor and need to set according to the value indicated on the motor nameplate.
- 05 - 16** Pole Number of Induction Motor 2
- Factory Setting: 4
- Settings 2~20
-
- 📖 It is used to set the number of motor poles (must be an even number)
- 05 - 17** No-load Current of Induction Motor 2 (A)
- Unit: Ampere
Factory Setting: 0
- Settings 0 to the factory setting in Pr.05-01
-
- 📖 The factory setting is 40% X rated current.
- 05 - 18** Stator Resistance (Rs) of Induction Motor 2
- Factory Setting: 0.000
- Settings 0.000~65.535Ω
-
- ↗ **05 - 19** Rotor Resistance (Rr) of Motor 2
- Factory Setting : 0.000
- Settings 0.000~65.535mΩ
-
- ↗ **05 - 20** Magnetizing Inductance (Lm) of Induction Motor 2
- Factory Setting : 0.0
- Settings 0.0~6553.5mH
-
- ↗ **05 - 21** Stator Inductance (Lx) of Induction Motor 2
- Factory Setting : 0.0
- Settings 0.0~65535mH
-

05 - 22 Induction Motor 1/ 2 Selection

Factory Setting: 1

Settings 1: Motor 1
 2: Motor 2

 It is used to set the motor that driven by the AC motor drive.

05 - 23 Frequency for Y-connection/ Δ -connection Switch of Induction Motor

Factory Setting: 60.00

Settings 0.00~600.00Hz

05 - 24 Y-connection/ Δ -connection Switch of Induction Motor IM

Factory Setting: 0


Settings 0: Disable
 1: Enable

05 - 25 Delay Time for Y-connection/ Δ -connection Switch of Induction Motor


Factory Setting: 0.200


Settings 0~60.000 seconds

- 📖 Pr 05-23 and Pr.05-25 are applied in the wide range motors and the motor coil will execute the switch of Y-connection/ Δ -connection as required. (The wide range motors has relation with the motor design. In general, it has higher torque at low speed and Y-connection and it has higher speed at high speed and Δ -connection.
- 📖 Pr.05-24 is used to enable/disable Y-connection/ Δ -connection Switch.
- 📖 When Pr.05-24 is set to 1, the drive will select by Pr.05-23 setting and current motor frequency to switch motor to Y-connection or Δ -connection. At the same time, it will also affect motor parameters.
- 📖 Pr.05-25 is used to set the switch delay time of Y-connection/ Δ -connection.
- 📖 When output frequency reaches Y-connection/ Δ -connection switch frequency, drive will delay by Pr.05-25 before multi-function output terminals are active.



- Y- Δ connection switch: can be used for wide range motor
- Y-connection for low speed: higher torque can be used for rigid tapping
- Δ -connection for high speed: higher torque can be used for high-speed drilling





05 – 26
~05 -30 Reserved

05 - 31 Accumulative Motor Operation Time (Min)
Factory Setting: 00
Settings 00~1439

05 - 32 Accumulative Motor Operation Time (day)
Factory Setting: 0
Settings 00~65535

📖 Pr. 05-31 and Pr.05-32 are used to record the motor operation time. They can be cleared by setting to 00 and time won't be recorded when it is less than 60 seconds


06 Protection Parameters The parameter can be set during operation


06 - 00 Low Voltage Level

Factory Setting: 180.0/360.0

Settings 230V models: 160.0~220.0V

460V models: 320.0~440.0V

 It is used to set the Lv level. When the drive is in the low voltage, it will stop output and free to stop.








06 - 01 Over-voltage Stall Prevention

Factory Setting: 380.0/760.0

Settings 230V models: 350.0~450.0V


460V models: 700.0~900.0V

0 : Disable this function

-  When the setting is 0.0, the over-voltage Stall prevention is disabled.
-  During deceleration, the DC bus voltage may exceed its Maximum Allowable Value due to motor regeneration. When this function is enabled, the AC motor drive will not decelerate further and keep the output frequency constant until the voltage drops below the preset value again.
-  This function is used for the occasion that the load inertia is unsure. When it stops in the normal load, the over-voltage won't occur during deceleration and fulfill the setting of deceleration time. Sometimes, it may not stop due to over-voltage during decelerating to stop when increasing the load regenerative inertia. At this moment, the AC drive will auto add the deceleration time until drive stop
-  When the over-voltage stall prevention is enabled, drive deceleration time will be larger than the setting
-  When there is any problem as using deceleration time, refer to the following items to solve it.
 1. Add the suitable deceleration time.
 2. Add brake resistor (refer to appendix B-1 for details) to consume the electrical energy that regenerated from the motor with heat type.

➤ Related parameters: Pr.01-13, 01-15, 01-17, 01-19 (settings of decel. time 1~4), Pr.02-13~02-14

(Multi-function Output 1 RY1, RY2), Pr. 02-16~02-17 Multi-function Output (MO1, 2)


**06 - 02** Reserved**06 - 03** Over-current Stall Prevention during Acceleration

Settings	Normal duty : 0~160% (100% drive's rated current)	Factory Setting: 120
	Light duty : 0~130% (100% drive's rated current)	Factory Setting: 120

- 📖 If the motor load is too large or drive acceleration time is too short, the AC drive output current may increase abruptly during acceleration and it may cause motor damage or trigger protection functions (OL or OC). This parameter is used to prevent this situation
- 📖 During acceleration, the AC drive output current may increase abruptly and exceed the value specified by Pr.06-03 due to rapid acceleration or excessive load on the motor. When this function is enabled, the AC drive will stop accelerating and keep the output frequency constant until the current drops below the maximum value.
- 📖 When the over-current stall prevention is enabled, drive deceleration time will be larger than the setting
- 📖 When the Over-Current Stall Prevention occurs due to too small motor capacity or in the factory setting, please decrease Pr.06-03 setting.
- 📖 When there is any problem by using acceleration time, refer to the following items to solve it

Related parameters: Pr.01-12, 01-14, 01-16, 01-18 (settings of accel. time 1~4), Pr.01-44

1. Add the suitable acceleration time.
2. Related parameters: Pr01-12, 01-14, 01-16, 01-18 for Acceleration Time 1, Time 2, Time 3 and Time 4; Pr.01-44 for Optimal Acceleration/Deceleration Setting to 1, 3 or 4 (auto accel.), Pr.02-13~02-14 for (Multi-function Output 1 RY1, RY2), Pr. 02-16~02-17 for Multi-function Output (MO1, 2)




3.

06 - 04 Over-current Stall Prevention during Operation

Settings	Normal duty : 0~160% (100% drive's rated current)	Factory Setting: 120%
	Light duty : 0~130% (100% drive's rated current)	Factory Setting: 120%

It is a protection for drive to auto decrease output frequency when the motor is over-load abruptly during motor constant operation.


If the output current exceeds the setting specified in Pr.06-04 when the drive is operating, the drive will decrease its output frequency (according to Pr.06-05) to prevent the motor stall. If the output current is lower than the setting specified in Pr.06-04, the drive will accelerate (according to Pr.06-05) again to catch up with the set frequency command value.



↗ 06 - 05 Accel./Decel. Time Selection of Stall Prevention at Constant Speed

Factory Setting: 0

- Settings
- 0: by current accel/decel time
 - 1: by the 1st accel/decel time
 - 2: by the 2nd accel/decel time
 - 3: by the 3rd accel/decel time
 - 4: by the 4th accel/decel time
 - 5: by auto accel/decel

 It is used to set the accel./decel. time selection when stall prevention occurs at constant speed

↗ 06 - 06 Over-torque Detection Selection (OT1)


Factory Setting: 0


- Settings
- 0: Disable
 - 1: Over-torque detection during constant speed operation, continue to operate after detection
 - 2: Over-torque detection during constant speed operation, stop operation after detection
 - 3: Over-torque detection during operation, continue to operate after detection
 - 4: Over-torque detection during operation, stop operation after detection

↗ 06 - 09 Over-torque Detection Selection (OT2)

Factory Setting: 0

- Settings
- 0: Disable
 - 1: Over-torque detection during constant speed operation, continue to operate after detection
 - 2: Over-torque detection during constant speed operation, stop operation after detection
 - 3: Over-torque detection during operation, continue to operation after detection
 - 4: Over-torque detection during operation, stop operation after detection

 When Pr.06-06 and Pr.06-09 are set to 1 or 3, it will display a warning message and won't have an abnormal record.

 When Pr.06-06 and Pr.06-09 are set to 2 or 4, it will display a warning message and will have an abnormal record.

↗ 06 - 07 Over-torque Detection Level (OT1)

Factory Setting: 120

- Settings 10 to 250% (100%: drive's rated current)

↗ 06 - 08 Over-torque Detection Level (OT1)

Factory Setting: 0.1

- Settings 0.0~60.0 seconds

06 - 10 Over-torque Detection Level (OT2)

Factory Setting: 120


Settings 10~200% (100% drive's rated current)

06 - 11 Over-torque Detection Time (OT2)

Factory Setting: 0.1

Settings 0.0~60.0 秒

Over torque detection is determine by the following method: if the output current exceeds the over-torque detection level (Pr.06-07, factory setting: 150%) and also exceeds Pr.06-08 Over-Torque Detection Time, the fault code “ot1/ot2” will appear. If a Multi-Functional Output Terminal is to over-torque detection (setting 7 or 8), the output is on. Please refer to Pr.02-13~02-14 for details.



06 - 12 Maximum Current Limit

Factory Setting: 150

Settings 0~200% (100% drive's rated current)

This parameter sets the max. current output of the drive.

06 - 13 Electronic Thermal Relay Selection (Motor 1)

06 - 27 Electronic Thermal Relay Selection (Motor 2)

Factory Setting: 2

Settings 0: Inverter motor
1: Standard motor
2: Disable

It is used to prevent self-cooled motor overheats under low speed. User can use electronic thermal relay to limit driver's output power.


06 - 14 Electronic Thermal Characteristic for Motor 1

06 - 28 Electronic Thermal Characteristic for Motor 2

Factory Setting: 60.0

Settings 30.0~600.0 seconds

📖 The parameter is set by the 150% of motor rated current and the setting of Pr.06-14 and Pr.06-28 to prevent the motor damaged from overheating. When it reaches the setting, it will display “EoL1/EoL2” and the motor will be in free running.



↗ 06 - 15 Heat Sink Over-heat (OH) Warning

Factory Setting: 85.0

Settings 0.0~110.0°C

↗ 06 - 16 Stall Prevention Limit Level

Factory Setting: 50

Settings 0~100% (Refer to Pr.06-03 and 06-04)

📖 When operation frequency is larger than Pr.01-01

For example: Pr06-03=150%, Pr. 06-04=100% and Pr. 06-16=80%:

Stall Prevention Level during acceleration = $06-03 \times 06-16 = 150 \times 80\% = 120\%$.

Stall Prevention Level at constant speed = $06-04 \times 06-16 = 100 \times 80\% = 80\%$

📖 When operation frequency is larger than Pr.01-01 (Base Frequency/Motor Rated Frequency);

e.g. Pr06-03=150%, Pr. 06-04=100% and Pr. 06-16=80%

Stall Prevention Level during acceleration = $06-03 \times 06-16 = 150 \times 80\% = 120\%$.

Stall Prevention Level at constant speed = $06-04 \times 06-16 = 100 \times 80\% = 80\%$.

- 06 - 17 Present Fault Record
- 06 - 18 Second Most Recent Fault Record
- 06 - 19 Third Most Recent Fault Record
- 06 - 20 Fourth Most Recent Fault Record
- 06 - 21 Fifth Most Recent Fault Record
- 06 - 22 Sixth Most Recent Fault Record

Settings:

- 0: No fault record
- 1: Over-current during acceleration (ocA)
- 2: Over-current during deceleration (ocd)
- 3: Over-current during constant speed(ocn)
- 4: Ground fault (GFF)
- 5: IGBT short-circuit (occ)
- 6: Over-current at stop (ocS)
- 7: Over-voltage during acceleration (ovA)
- 8: Over-voltage during deceleration (ovd)
- 9: Over-voltage during constant speed (ovn)
- 10: Over-voltage at stop (ovS)
- 11: Low-voltage during acceleration (LvA)
- 12: Low-voltage during deceleration (Lvd)
- 13: Low-voltage during constant speed (Lvn)
- 14: Stop mid-low voltage (LvS)
- 15: Phase loss protection (OrP)
- 16: IGBT over-heat (oH1)
- 17: Capacitance over-heat (oH2) (for 40hp above)
- 18: tH1o (TH1 open: IGBT over-heat protection error)
- 19: tH2o (TH2 open: capacitance over-heat protection error)
- 20: Reserved
- 21: Drive over-load (oL)
- 22: Electronics thermal relay 1 (EoL1)
- 23: Electronics thermal relay 2 (EoL2)
- 24: Motor PTC overheat (oH3) (PTC)
- 25: Reserved
- 26: Over-torque 1 (ot1)
- 27: Over-torque 2 (ot2)
- 28: Low current (uC)
- 29: Home limit error (LMIT)
- 30: Memory write-in error (cF1)
- 31: Memory read-out error (cF2)
- 32: Reserved
- 33: U-phase current detection error (cd1)
- 34: V-phase current detection error (cd2)
- 35: W-phase current detection error (cd3)
- 36: Clamp current detection error (Hd0)
- 37: Over-current detection error (Hd1)
- 38: Over-voltage detection error (Hd2)
- 39: occ IGBT short circuit detection error (Hd3)

- 40: Auto tuning error (AUE)
- 41: PID feedback loss (AFE)
- 42: Reserved
- 43: Reserved
- 44: Reserved
- 45: Reserved
- 46: Reserved
- 47: Reserved
- 48: Analog current input loss (ACE)
- 49: External fault input (EF)
- 50: Emergency stop (EF1)
- 51: External Base Block (bb)
- 52: Password error (PcodeE)
- 53: Reserved
- 54: Communication error (CE1)
- 55: Communication error (CE2)
- 56: Communication error (CE3)
- 57: Communication error (CE4)
- 58: Communication Time-out (CE10)
- 59: PU Time-out (CP10)
- 60: Brake transistor error (bF)
- 61: Y-connection/ Δ -connection switch error (ydc)
- 62: Decel. Energy Backup Error (dEb)
- 63: Slip error (oSL)
- 64: Reserved
- 65 : Reserved
- 66~72 : Reserved
- 73 : External safety gate S1
- 74: 火災模式輸出 Output in Fire Mode
- 75~78 : Reserved
- 79: Uocc U phase over current (Detection begins as RUN is pressed, software protection)
- 80: Vocc V phase over current (Detection begins as RUN is pressed, software protection)
- 81: Wocc W phase over current (Detection begins as RUN is pressed, software protection)
- 82: OPHL U phase output phase loss
- 83: OPHL Vphase output phase loss
- 84: OPHL Wphase output phase loss
- 85~100 : Reserved
- 101: CGdE CANopen software disconnect1
- 102: CHbE CANopen software disconnect2
- 103: CSYE CANopen synchronous error

- 104: CbFE CANopen hardware disconnect
 105: CIeE CANopen index setting error
 106: CAeE CANopen slave station number setting error
 107: CFrE CANopen index setting exceed limit

📖 When the fault occurs and force stopping, it will record in this parameter.

📖 At stop with low voltage Lv (LvS warn, no record). During operation with mid-low voltage Lv (LvA, Lvd, Lvn error, will record).

📖 Setting 62: when dEb function is enabled, the drive will execute dEb and record to the Pr.06-17 to Pr.06-22 simultaneously.

- ↗ **06 - 23** Fault Output Option 1
 ↗ **06 - 24** Fault Output Option 2
 ↗ **06 - 25** Fault Output Option 3
 ↗ **06 - 26** Fault Output Option 4

Factory Setting: 0

Settings 0 to 65535 sec (refer to bit table for fault code)

📖 These parameters can be used with multi-function output (set to 35-38) for the specific requirement. When the fault occurs, the corresponding terminals will be activated (It needs to convert binary value to decimal value to fill in Pr.06-23 to Pr.06-26)

Fault Code	Bit0	Bit1	Bit2	Bit3	Bit4	Bit5	Bit6
	current	Volt.	OL	SYS	FBK	EXI	CE
0: No fault							
1: Over-current during acceleration (ocA)	●						
2: Over-current during deceleration (ocd)	●						
3: Over-current during constant speed(ocn)	●						
4: Ground fault (GFF)	●						
5: IGBT short-circuit (occ)	●						
6: Over-current at stop (ocS)	●						
7: Over-voltage during acceleration (ovA)		●					
8: Over-voltage during deceleration (ovd)		●					
9: Over-voltage during constant speed (ovn)		●					
10: Over-voltage at stop (ovS)		●					
11: Low-voltage during acceleration (LvA)		●					
12: Low-voltage during deceleration (Lvd)		●					
13: Low-voltage during constant speed (Lvn)		●					
14: Stop mid-low voltage (LvS)		●					
15: Phase loss protection (OrP)		●					
16: IGBT over-heat (oH1)			●				
17: Capacitance over-heat (oH2)			●				
18: tH1o (TH1 open)			●				

19: tH2o (TH2 open)			●				
20 : Reserved						●	
21: Drive over-load (oL)			●				
22: Electronics thermal relay 1 (EoL1)			●				
23: Electronics thermal relay 2 (EoL2)			●				
24: Motor PTC overheat (oH3) (PTC)			●				
25 : Reserved						●	
26: Over-torque 1 (ot1)			●				
27: Over-torque 2 (ot2)			●				
28: Low current (uC)	●						
29 : Reserved							
30: Memory write-in error (cF1)				●			
31: Memory read-out error (cF2)				●			
32 : Reserved				●			
33: U-phase current detection error (cd1)				●			
34: V-phase current detection error (cd2)				●			
35: W-phase current detection error (cd3)				●			
36: Clamp current detection error (Hd0)				●			
37: Over-current detection error (Hd1)				●			
38: Over-voltage detection error (Hd2)				●			
39: occ IGBT short circuit detection error (Hd3)				●			
40: Auto tuning error (AUE)				●			
41: PID feedback loss (AFE)					●		
42 : Reserved					●		
43 : Reserved					●		
44 : Reserved					●		
45 : Reserved					●		
46 : Reserved					●		
47 : Reserved					●		
48: Analog current input loss (ACE)					●		
49: External fault input (EF)						●	
50: Emergency stop (EF1)						●	
51: External Base Block (bb)						●	
52: Password error (PcodE)				●			
53 : Reserved							
54: Communication error (CE1)							●
55: Communication error (CE2)							●
56: Communication error (CE3)							●
57: Communication error (CE4)							●
58: Communication Time-out (CE10)							●

59: PU Time-out (CP10)							●
60: Brake transistor error (bF)						●	
61: Y-connection/ Δ -connection switch error (ydc)						●	
62: Decel. Energy Backup Error (dEb)		●					
63: Slip error (oSL)						●	
64: Electromagnet switch error (ryF)						●	
65 : Reserved						●	
73 : External safety gate S1				●			
74~78 : Reserved							
79: U phase over current (Uocc)	●						
80: V phase over current (Vocc)	●						
81: W phase over current (Wocc)	●						
82: OPHL U phase output phase loss	●						
83: OPHL Vphase output phase loss	●						
84: OPHL Wphase output phase loss	●						
85~100 : Reserved							
101: CGdE CANopen software disconnect1							●
102: CHbE CANopen software disconnect2							●
103: CSYE CANopen synchronous error							●
104: CbFE CANopen hardware disconnect							●
105: CIdE CANopen index setting error							●
106: CAde CANopen slave station number setting error							●
107: CFrE CANopen index setting exceed limit							●

✎ 06 - 29 PTC (Positive Temperature Coefficient) Detection Selection

Factory Setting: 0

- Settings
- 0: Warn and keep operating
 - 1: Warn and ramp to stop
 - 2: Warn and coast to stop
 - 3: No warning

📖 This is the operating mode of a drive after Pr.06-29 is set to define PTC detection.

✎ 06 - 30 PTC Level

Factory Setting: 50.0

- Settings 0.0~100.0%


📖 It needs to set AVI1/ACI/AVI2 analog input function Pr.03-00~03-02 to 6 (P.T.C. thermistor input value).

📖 It is used to set the PTC level, and the corresponding value for 100% is max. analog input value.

06 - 31 Frequency Command for Malfunction

Factory Setting: Read Only


Settings 0.00~655.35Hz

 When malfunction occurs, user can check the frequency command. If it happens again, it will overwrite the previous record.

06 - 32 Output Frequency at Malfunction

Factory Setting: Read Only


Settings 0.00~655.35Hz

 When malfunction occurs, user can check the current frequency command. If it happens again, it will overwrite the previous record.

06 - 33 Output Voltage at Malfunction

Factory Setting: Read Only


Settings 0.0~6553.5V

 When malfunction occurs, user can check current output voltage. If it happens again, it will overwrite the previous record.

06 - 34 DC Voltage at Malfunction

Factory Setting: Read Only


Settings 0.0~6553.5V

 When malfunction occurs, user can check the current DC voltage. If it happens again, it will overwrite the previous record.

06 - 35 Output Current at Malfunction

Factory Setting: Read Only


Settings 0.00~655.35Amp

 When malfunction occurs, user can check the current output current. If it happens again, it will overwrite the previous record.

06 - 36 IGBT Temperature at Malfunction

Factory Setting: Read Only


Settings 0.0~6553.5°C

 When malfunction occurs, user can check the current IGBT temperature. If it happens again, it will overwrite the previous record.

06 - 37 Capacitance Temperature at Malfunction

Factory Setting: Read Only


Settings 0.0~6553.5°C

 When malfunction occurs, user can check the current capacitance temperature. If it happens again, it will overwrite the previous record.

06 - 38 Motor Speed in rpm at Malfunction

Factory Setting: Read Only

Settings 0.0~6553.5°C

 When malfunction occurs, user can check the current motor speed in rpm. If it happens again, it will overwrite the previous record

06 - 39 Reserved**06 - 40** Status of Multi-function Input Terminal at Malfunction


Factory Setting: Read Only

Settings 0~65535

06 - 41 Status of Multi-function Output Terminal at Malfunction

Factory Setting: Read Only


Settings 0~65535

 When malfunction occurs, user can check the status of multi-function input/output terminals. If it happens again, it will overwrite the previous record

06 - 42 Drive Status at Malfunction

Factory Setting: Read Only

Settings 0~65535

 When malfunction occurs, please check the drive status (communication address 2119H). If malfunction happens again, the previous record will be overwritten by this parameter.

**06 - 43** Reserved**06 - 44** Reserved**06 - 45** Treatment for Output Phase Loss Detection (OPHL)

Factory Setting: 3

Settings 0: Warn and keep operating
 1: Warn and ramp to stop
 2: Warn and coast to stop
 3: No warning

 OPHL: Output Phase Loss

06 - 46	Deceleration Time of Output Phase Loss	Factory Setting: 0.500
	Settings 0.000~65.535 seconds	
06 - 47	Current Bandwidth	Factory Setting: 1.00
	Settings 0.00~655.35%	
06 - 48	DC Brake Time of Output Phase Loss	Factory Setting: 0.100
	Settings 0.000~65.535 seconds	
06 - 49	Reserved	
06 - 50	Time for Input Phase Loss Detection	Factory Setting: 0.20
	Settings 0.00~600.00 seconds	
06 - 51	Reserved	
06 - 52	Ripple of Input Phase Loss	Factory Setting: 30.0 / 60.0
	Settings 230V models: 0.0~160.0 Vdc 460V models 0.0~320.0 Vdc	
06 - 53	Treatment for the detected Input Phase Loss (OrP)	Factory Setting: 0
	Settings 0: warn, ramp to stop 1: warn, coast to stop	
	 Over ripple protect	
06 - 54	Reserved	
06 - 55	Derating Protection	Factory Setting: 0
	Settings 0: constant rated current and limit carrier wave by load current and temperature 1: constant carrier frequency and limit load current by setting carrier wave 2: constant rated current(same as setting 0), but close current limit	

Setting 0: When the rated current is constant, carrier frequency (Fc) outputted by PWM will auto decrease according to surrounding temperature, overload output current and time. If overload situation is not frequent and only cares the carrier frequency operated with the rated current for a long time and carrier wave changes during short overload, it is recommended to set to 0.


Refer to the following diagram for the level of carrier frequency. Take VFD007C43A in normal duty as example, surrounding temperature 50°C with independent installation and UL open-type. When the carrier frequency is set to 15kHz, it corresponds to 72% rated output current. When it outputs higher than the value, it will auto decrease the carrier frequency. If the output is 83% rated current and the carrier frequency will decrease to 12kHz. In addition, it will also decrease the carrier frequency when overload. When the carrier frequency is 15kHz and the current is $120\% \times 72\% = 86\%$ for a minute, the carrier frequency will decrease to the factory setting.

Setting 1: It is used for the fixed carrier frequency and prevents the carrier wave changes and motor noise caused by the surrounding temperature and frequent overload.

Refer to the following for the derating level of rated current. Take VFD007CP43A-21 in normal duty as example, when the carrier frequency keeps in 15kHz and the rated current is decreased to 72%, it will have OL protection when the current is $120\% \times 72\% = 86\%$ for a minute. Therefore, it needs to operate by the curve to keep the carrier frequency.

Setting 2: It sets the protection method and action to 0 and disables the current limit for the Ratio*160% of output current in the normal duty and Ratio*180% of output current in the heavy duty. The advantage is that it can provide higher output current when the setting is higher than the factory setting of carrier frequency. The disadvantage is that it decreases carrier wave easily when overload.

Derating Curve diagram while Light Duty and Normal Duty



Derating Curve diagram while Light Duty and

Normal Duty (continues)

Setting = 1

Light Duty


(40°C: UL open type and type1)

Normal Duty

(50°C: UL open-type)

(40°C: UL type1 and open type_size by size)

230V



Setting = 0 or 2

Light Duty


(30°C: UL open type and type1)

Normal Duty


(40°C: UL open-type)

(30°C: UL type1 or open type_size by size)

230V



It should go with Pr. 00-16 and Pr.00-17 for setting.



NOTE

- ※ (As shown in the left figure), The mounting clearances are not for installing the drive in a confined space (such as cabinet or electric box). When installing in a confined space, except the same minimum mounting clearances, it needs to have the ventilation equipment or air conditioner to keep the surrounding temperature lower than the operation temperature.
- ※ The following table shows heat dissipation and the required air volume when installing a single drive in a confined space. When installing multiple drives, the required air volume shall be multiplied by the number the drives.
- ※ Please refer to the chart “Air Flow Rate for Cooling” for ventilation equipment design and selection.
- ※ Please refer to the chart “Power Dissipation” for air conditioner design and selection.
- ※ For more detail, please refer to Chapter 2 Installation.

Minimum Mounting Distance

Frame	A (mm)	B (mm)	C (mm)	D (mm)
A~C	60	30	10	0
D~F	100	50	-	0
G	200	100	-	0
H	350	0	0	200 (100, Ta=40°C)

Air flow rate for cooling							Power Dissipation		
Model No.	Flow Rate (cfm)			Flow Rate (m ³ /hr)			Power Dissipation (watt)		
	External	Internal	Total	External	Internal	Total	Loss External (Heat sink)	Internal	Total
VFD007CP23A-21	-	-	-	-	-	-	40	31	71
VFD015CP23A-21	-	-	-	-	-	-	61	39	100
VFD022CP23A-21	14	-	14	24	-	24	81	45	126
VFD037CP23A-21	14	-	14	24	-	24	127	57	184
VFD055CP23A-21	10	-	10	17	-	17	158	93	251
VFD075CP23A-21	40	14	54	68	24	92	291	101	392
VFD110CP23A-21	66	14	80	112	24	136	403	162	565
VFD150CP23A-21	58	14	73	99	24	124	570	157	727
VFD185CP23A-21	166	12	178	282	20	302	622	218	840
VFD220CP23A-21	166	12	178	282	20	302	777	197	974
VFD300CP23A-21	146	12	158	248	20	268	878	222	1100
VFD370CP23A-00/23A-21	179	30	209	304	51	355	1271	311	1582
VFD450CP23A-00/23A-21	179	30	209	304	51	355	1550	335	1885
VFD550CP23A-00/23A-21	228	73	301	387	124	511	1762	489	2251
VFD750CP23A-00/23A-21	228	73	301	387	124	511	2020	574	2594
VFD900CP23A-00/23A-21	246	73	319	418	124	542	2442	584	3026
VFD007CP43A/4EA-21	-	-	-	-	-	-	35	32	67
VFD015CP43A/4EA-21	-	-	-	-	-	-	44	31	75
Air flow rate for cooling							Power Dissipation		
Model No.	Flow Rate (cfm)			Flow Rate (m ³ /hr)			Power Dissipation (watt)		
	External	Internal	Total	External	Internal	Total	Loss External (Heat sink)	Internal	Total
VFD037CP43A/4EA-21	14	-	14	24	-	24	92	60	152
VFD040CP43A/4EA-21	10	-	10	17	-	17	124	81	205
VFD055CP43A/4EA-21	10	-	10	17	-	17	135	99	234
VFD075CP43A/4EA-21	10	-	10	17	-	17	165	98	263
VFD110CP43A/4EA-21	40	14	54	68	24	92	275	164	439
VFD150CP43A/4EA-21	66	14	80	112	24	136	370	194	564
VFD185CP43A/4EA-21	58	14	73	99	24	124	459	192	651
VFD220CP43A/4EA-21	99	21	120	168	36	204	455	358	813
VFD300CP43A/4EA-21	99	21	120	168	36	204	609	363	972
VFD370CP43A/4EA-21	126	21	147	214	36	250	845	405	1250
VFD450CP43A-00/43A-21	179	30	209	304	51	355	1056	459	1515
VFD550CP43A-00/43A-21	179	30	209	304	51	355	1163	669	1832

VFD750CP43A-00/43A-21	179	30	209	304	51	355	1639	657	2296
VFD900CP43A-00/43A-21	186	30	216	316	51	367	1787	955	2742
VFD1100CP43A-00/43A-21	257	73	330	437	124	561	2112	1084	3196
VFD1320CP43A-00/43A-21	223	73	296	379	124	503	2417	1157	3574
VFD1600CP43A-00/43A-21	224	112	336	381	190	571	3269	1235	4504
VFD1850CP43A-00/43A-21	289	112	401	491	190	681	3632	1351	4983
VFD2200CP43A-00/43A-21			454			771			6358
VFD2800CP43A-00/43A-21			454			771			7325
VFD3150CP43A-00/43C-00/43C-21			769			1307			8513
VFD3550CP43A-00/43C-00/43C-21			769			1307			9440
VFD4000CP43A-00/43C-00/43C-21			769			1307			10642
※ The required airflow shown in chart is for installing single drive in a confined space. ※ When installing the multiple drives, the required air volume should be the required air volume for single drive X the number of the drives.							※ The heat dissipation shown in the chart is for installing single drive in a confined space. ※ When installing multiple drives, volume of heat dissipation should be the heat dissipated for single drive X the number of the drives. ※ Heat dissipation for each model is calculated by rated voltage, current and default carrier		

06 - 56 PT100 Detection Level 1

Factory Setting: 5.000

Settings 0.000~10.000V

06 - 57 PT100 Detection Level 2

Factory Setting: 7.000

Settings 0.000~10.000V


06 - 58 PT100 Level 1 Frequency Protection


Factory Setting: 0.00

Settings 0.00~600.00 Hz

06 - 59 Reserved

06 - 60	Software Detection GFF Current Level	Factory Setting: 60.0
	Settings 0.0~6553.5 %	
06 - 61	Software Detection GFF Filter Time	Factory Setting: 0.10
	Settings 0.0~655.35 秒	
06 - 62	Disable Level of dab	Factory Setting: 180.0/360.0
	Settings 230V models: 0.0~220.0 Vdc 460V models 0.0~440.0 Vdc	
06 - 63	Fault Record 1 (min)	
06 - 64	Fault Record 2 (min)	
06 - 65	Fault Record 3 (min)	
06 - 66	Fault Record 4 (min)	
06 - 67	Fault Record 5 (min)	
06 - 68	Fault Record 6 (min)	
		Factory Setting: Read Only
	Settings 0~65535 minutes	

 Pr.06-63 to Pr.06-68 are used to record the operation time for 6 malfunctions and it can also check if there is any wrong with the drive according to the internal time.

 When the malfunction occurs during operation, it records fault in Pr.06-17~06-22 and operation time is recorded in Pr.06-63~06-68.

For example: When the first fault ovA occurs after operation 3000 min., second fault ovd occurs at 3482 min., third fault ovA occurs at 4051 min., fourth fault ocA at 5003 min., fifth fault ocA at 5824 min., sixth fault ocd occurs at 6402 min. and seven fault ocS at 6951 min..

It'll be recorded as the following table

It will be recorded as the table below.

First Fault	Pr.06-17	ovA	Pr.06-63	3000
Second Fault	Pr. 06-17	ovd	Pr. 06-63	3482
	Pr. 06-18	ovA	Pr. 06-64	3000
Third Fault	Pr. 06-17	ovA	Pr. 數 06-63	4051
	Pr. 06-18	ovd	Pr. 06-64	3482
	Pr. 06-19	ovA	Pr. 06-65	3000

Seventh Fault	Pr. 06-17	ocS	Pr. 06-63	6951
	Pr 06-18	ocA	Pr 06-64	5824
	Pr 06-19	ocA	Pr 06-65	5003
	Pr 06-20	ovA	Pr 06-66	4051
	Pr 06-21	ovd	Pr 06-67	3482
	Pr 06-22	ovA	Pr 06-68	3000

06 - 69 Number of Days of Malfunction (V)

Factory Setting: Read Only

Settings Read Only

06 - 70 Duration of Malfunction

Factory Setting: Read Only

Settings Read Only

06 - 71 Low Current Setting Level

Factory Setting: 0.0

Settings 0.0 ~ 100.0 %

06 - 72 Low Current Detecting Time

Factory Setting: 0.00

Settings 0.00 ~ 360.00 seconds

06 - 73 Treatment for low current

Factory Setting: 0

Settings


- 0 : No function
- 1 : warn and coast to stop
- 2 : warn and ramp to stop by 2nd deceleration time
- 3 : warn and operation continue

06 - 80 Fire Mode

Factory Setting: 0.00

Settings

- 0: No Function
- 1: Forward Operation
- 2: Reverse Operation

 This parameter needs to work with multi-input function terminal #58 or #59 and multi-output function terminal #53 and #54.

Setting is 0: Fire mode is disabled


Setting is 1: When there is a fire, motors will operating clockwise (U,V,W).

Setting is 2: When there is a fire, motors will operate counter-clockwisely.

06 - 81 Operating Frequency when running Fire Mode (hz)

Factory Setting: 6000

Settings 0.00 ~ 600.00 hz

 This parameter is to set up the drive's frequency when the fire mode is enabled.

06 - 82 Enable Bypass on Fire Mode

Factory Setting: 0.00

Settings 0: Disable Bypass
1: Enable Bypass

06 - 83 Bypass Delay Time on Fire Mode

Factory Setting: 0.00

Settings 0.00 ~ 6550.0 seconds

06 - 84 Auto-restart counter of Fire Mode

Factory Setting: 0.00

Settings 0 ~ 10

06 - 85 Length of Time to reset auto counter

Factory Setting: 0.00

Settings 0.00 ~ 6000.0sec



 The settings of Pr06-82 to Pr06-85 decide if switch motors to operating under mains electricity.

Diagram of Bypass function's Sequence



When Pr06-82 is set to 1 and under one of two conditions below.

- (1) When operating at fire mode , there is error(as shown in the table below) and the fire alarm rings according to the time setting of Pr06-83, then the bypass function will be enabled. MFO bypass indication will be ON.
- (2) When operating at fire mode, there is an error on auto-reset and the number of time to auto-reset remains zero or the fire alarm rings according to the time setting of Pr06-83, then the bypass function will be enabled. MFO bypass indication will be ON. If the auto rest is successful before the bypass function is enabled, then the bypass delay counter will return to zero to wait for next trigger.

Table 1: Error detection under Normal mode, Fire mode and Bypass function at Fire mode. (V means detectable)

Code	Error name	Normal mode	Fire Mode	Enable bypass function
1	Over current during Acceleration (ocA)	V(RS)	V(able to auto-reset)	V
2	Over current during deceleration (ocd)	V(RS)	V(able to auto-reset)	V
3	Over current during normal speed (ocn)	V(RS)	V(able to auto-reset)	V
4	Ground Fault (GFF)	V	V(able to auto-reset)	V
5	IGBT short circuit (occ)	V(RS)	V(able to auto-reset)	V
6	Over current during Stop (ocS)	V(RS)	V(able to auto-reset)	V
7	Over voltage during Acceleration (ovA)	V(RS)	V(able to auto-reset)	V
8	Over voltage during deceleration (ovd)	V(RS)	V(able to auto-reset)	V
9	Over voltage during normal speed (ovn)	V(RS)	V(able to auto-reset)	V
10	Over voltage during Stop (ovS)	V(RS)	V(able to auto-reset)	V
11	Low voltage during Acceleration (LvA)	V	Not-detectable	Not-detectable
12	Low voltage during deceleration (Lvd)	V	Not-detectable	Not-detectable
13	Low voltage during normal speed (Lvn)	V	Not-detectable	Not-detectable
14	Low voltage during Stop (LvS)	V	Not-detectable	Not-detectable
15	Input phase loss (PHL)	V	V(able to	V

			auto-reset)	
16	Over heat 1 (oH1)	V	V(able to auto-reset)	V
17	Over heat 2 (oH2)	V	V(able to auto-reset)	V
18	Thermister 1 open (tH1o)	V	V(able to auto-reset)	V
19	Thermister 2 open (tH2o)	V	V(able to auto-reset)	V
20	Main Power OFF	V	Not-detectable	Not-detectable
21	Over Load (oL) (150% 1Min, Inverter)	V	Not-detectable	Not-detectable
22	Motor 1 over load (EoL1)	V	Not-detectable	Not-detectable
23	Motor 2 over load (EoL2)	V	Not-detectable	Not-detectable
24	Over heat 3 (oH3) (PTC)	V	V(able to auto-reset)	V
26	Over torque 1 (ot1)	V	Not-detectable	Not-detectable
27	Over torque 2 (ot2)	V	Not-detectable	Not-detectable
30	EEPROM write error (cF1)	V	Not-detectable	Not-detectable
31	EEPROM read error (cF2)	V	V	Not-detectable
33	U phase current sensor detection error (cd1)	V	V	Not-detectable
34	V phase current sensor detection error (cd2)	V	V	Not-detectable
35	W phase current sensor detection error (cd3)	V	V	Not-detectable
36	Hardware Logic error 0 (Hd0) - cc	V	V	Not-detectable
37	Hardware Logic error 1 (Hd1) - oc	V	V	Not-detectable
38	Hardware Logic error 2 (Hd2) - ov	V	V	Not-detectable
39	Hardware Logic error 3 (Hd3) – occ	V	V	Not-detectable
40	Motor auto tuning error (AuE)	V	Not-detectable	Not-detectable
41	ACI feedback loss (AFE)	V	Not-detectable	Not-detectable
48	ACI Loss	V	Not-detectable	Not-detectable
49	External fault (EF)	V	Not-detectable	Not-detectable
50	Emergency stop (EF1)	V	Not-detectable	Not-detectable
51	base block (bb)	V	Not-detectable	Not-detectable
52	PcodE (Password)	V	Not-detectable	Not-detectable
53	Software code lock (ccodE)	V	Not-detectable	Not-detectable
54	Communication error 1 (cE1)	V	Not-detectable	Not-detectable
55	Communication error 2 (cE2)	V	Not-detectable	Not-detectable
56	Communication error 3 (cE3)	V	Not-detectable	Not-detectable
57	Communication error 4 (cE4)	V	Not-detectable	Not-detectable
58	cE10 (Communication Time Out)	V	Not-detectable	Not-detectable
59	Communication time out (cP10)	V	Not-detectable	Not-detectable
60	Braking Transistor Fault (bf)	V	Not-detectable	Not-detectable

61	Y-Delta connected Error (ydc)	V	Not-detectable	Not-detectable
62	Decel. Energy Backup Error (dEb)	V	Not-detectable	Not-detectable
63	Over Slip Error (oSL)	V	Not-detectable	Not-detectable
64	MC Fault over Frame E	V	Not-detectable	Not-detectable
66	Unknow oc	V(RS)	V(able to auto-reset)	V
67	Unknow ov	V(RS)	V(able to auto-reset)	V
73	S1-Emergy STOP	V	V	Not-detectable
74	Fire Mode	V	V(keeps on operating)	V(keeps on operating)
79	A PHASE SHORT	V	V(able to auto-reset)	V
80	B PHASE SHORT	V	V(able to auto-reset)	V
81	C PHASE SHORT	V	V(able to auto-reset)	V
82	Output Phase Lose A	V	V(able to auto-reset)	V
83	Output Phase Lose B	V	V(able to auto-reset)	V
84	Output Phase Lose C	V	V(able to auto-reset)	V
99	CPU Trap	V	V	V
101	Guarding T-out	V	Not-detectable	Not-detectable
102	Heartbeat T-out	V	Not-detectable	Not-detectable
103	SYNC T-out	V	Not-detectable	Not-detectable
104	CAN Bus Off	V	Not-detectable	Not-detectable
105	CAN Idx exceed	V	Not-detectable	Not-detectable
106	CAN Address set	V	Not-detectable	Not-detectable
107	CAN FRAM fail	V	Not-detectable	Not-detectable

07 Special Parameters

✎ The parameter can be set during operation_

✎ **07 - 00** Software Brake Level

Factory Setting: 380.0/760.0

Settings 230V models : 350.0~450.0Vdc
 460V models : 700.0~900.0Vdc

📖 This parameter sets the DC-bus voltage at which the brake chopper is activated. Users can choose the suitable brake resistor to have the best deceleration. Refer to Chapter 7 Accessories for the information of the brake resistor

📖 It is only valid for the models below 30kW of 460 series and 22kW of 230 series.

✎ **07 - 01** DC Brake Current Level

Factory Setting: 0

Settings 0~100%

📖 This parameter sets the level of DC Brake Current output to the motor during start-up and stopping. When setting DC Brake Current, the Rated Current is regarded as 100%. It is recommended to start with a low DC Brake Current Level and then increase until proper holding torque has been attained.

✎ **07 - 02** DC Brake Time at Start-up

Factory Setting: 0.0

Settings 0.00~60.0 seconds

📖 馬 The motor may be in the rotation status due to external force or itself inertia. If the drive is used with the motor at this moment, it may cause motor damage or drive protection due to over current. This parameter can be used to output DC current before motor operation to stop the motor and get a stable start. This parameter determines the duration of the DC Brake current after a RUN command. When it is set to 0.0, it is invalid.

✎ **07 - 03** DC Brake Time at Stop

Factory Setting: 0.00

Settings 0.00~60.00 seconds

📖 The motor may be in the rotation status after drive stop outputting due to external force or itself inertia and can't stop accurately. This parameter can output DC current to force the motor drive stop after drive stops to make sure that the motor is stop

📖 This parameter determines the duration of the DC Brake current during stopping. To DC brake at stop, this function will be valid when Pr.00-22 is set to 0 or 2. When setting to 0.0, it is invalid


➤ Related parameters: Pr.00-22 Stop Method, Pr.07-04 Start-point for DC Brake

✎ **07 - 04** Start-Point for DC Brake

Factory Setting: 0.00

Settings 0.00~600.00Hz

📖 This parameter determines the frequency when DC Brake will begin during deceleration. When this setting is less than start frequency (Pr.01-09), the start-point for DC brake will start from the min. frequency.



📖 DC Brake at Start-up is used for loads that may move before the AC drive starts, such as fans and pumps. Under such circumstances, DC Brake can be used to hold the load in position before setting it in motion

📖 DC Brake at stop is used to shorten the stopping time and also to hold a stopped load in position, such as crane or cutting machine.

07 - 05 Reserved

Factory Setting:

Settings

🚩 07 - 06 Restart after Momentary Power Down

Factory Setting: 0

Settings 0: Stop operation
1: Speed search for last frequency command
2: Speed search for the minimum output frequency

📖 This parameter determines the operation mode when the AC motor drive restarts from a momentary power loss.

📖 The power connected to the drive may power off momentarily due to many reasons. This function allows the drive to keep outputting after power is on again after power off and won't cause drive stops.

📖 Setting 1: Operation continues after momentary power loss, speed search starts with the Master Frequency reference value after drive output frequency and motor rotator speed is synchronous. The motor has the characteristics of big inertia and small obstruction. For example, in the equipment with big inertia wheel, it doesn't need to wait to execute operation command until wheel is complete stop after re-start to save time.

📖 Setting 2: Operation continues after momentary power loss, speed search starts with the master frequency after drive output frequency and motor rotator speed is synchronous. The motor has the characteristics of small inertia and bigger obstruction.

🚩 07 - 07 Maximum Power Loss Duration

Factory Setting: 2.0

Settings 0.1~20.0 seconds

📖 If the duration of a power loss is less than this parameter setting, the AC motor drive will resume operation. If it exceeds the Maximum Allowable Power Loss Time, the AC motor drive output is then turned off (coast stop).

📖 The selected operation after power loss in Pr.07-06 is only executed when the maximum allowable power

loss time is ≤ 5 seconds and the AC motor drive displays “LU”.


But if the AC motor drive is powered off due to overload, even if the maximum allowable power loss time is ≤ 5 seconds, the operation mode as set in Pr.07-06 is not executed. In that case it starts up normally

07 - 08 Base block Time


Factory Setting: 0.5

Settings 0.1~5.0 seconds


When momentary power loss is detected, the AC drive will block its output and then wait for a specified period of time (determined by Pr.07-08, called Base-Block Time) before resuming operation. This parameter should be set at a value to ensure that any residual regeneration voltage from the motor on the output has disappeared before the drive is activated again.



B.B. Search with last output frequency downward timing chart



B.B. Search with minimum output frequency upward timing chart



B.B. Search with minimum output frequency upward timing chart

07 - 09 Current Limit for Speed Search

Factory Setting: 100

Settings 20~200%

- 📖 Following a momentary power loss, the AC motor drive will start its speed search operation only if the output current is greater than the value set by Pr.07-09.
- 📖 When executing speed search, the V/f curve is operated by group 1 setting. The maximum current for the optimum accel./decel. and start speed search is set by Pr.07-09.
- 📖 The speed search level will affect the synchronous time. It will get the synchronization faster when this parameter is set to larger value. But too large value may active overload protection

07 - 10 Treatment to Reboots After Fault

Factory Setting: 0

Settings 0: Stop operation

1: Speed search starts with current speed

2: Speed search starts with minimum output frequency

- 📖 Fault includes: bb,oc,ov,occ etc. To restart after oc, ov, occ, Pr.07-11 can not be set to 0

07 - 11 # of Automatic Reboots After Fault

Factory Setting: 0


Settings 0~10

- 📖 The maximum automatic rest and reboots times for the AC motor drive when faults (oc, ov, occ) occur is up to 10 times. When this parameter is set to 0, there will be no reset or reboots. When auto reset and reboots are enabled, the AC motor drive perform a speed search before activate the drive.
- 📖 When the number of fault occur exceed Pr.07-11 and is within the duration less than Pr.07-33, the drive will refuse to re-start. Please press "RESET" key to continue the operation ◦

07 - 12 Speed Search during Start-up

Factory Setting: 0


- Settings
- 0: Disable
 - 1: Speed search from maximum output frequency
 - 2: Speed search from start-up motor frequency
 - 3: Speed search from minimum output frequency

 This parameter is used for starting and stopping a motor with a high inertia. A motor with high inertia will take 2-5 minutes or longer to stop completely. By setting this parameter, the user does not need to wait for the motor to come to a complete stop before restarting the AC motor drive. If a PG card and encoder is used on the drive and motor, then the speed search will start from the speed that is detected by the encoder and accelerate quickly to the commanded frequency. The output current is set by the Pr.07-09.

07 - 13 Decel. Time at Momentary Power Loss (dEb function)

Factory Setting: 0


- Settings
- 0: Disable
 - 1: 1st decel. time
 - 2: 2nd decel. time
 - 3: 3rd decel. time
 - 4: 4th decel. time
 - 5: Current decel. time
 - 6: Auto decel. time

 This parameter is used for the decel. time selection for momentary power loss.


07 - 14 dEb Return Time

Factory Setting: 0.0

- Settings 0.0~25.0 seconds

 This function allows the AC motor drive decelerates to stop after momentary power loss. When the momentary power loss occurs, this function can be used for the motor to decelerate to 0 speed with deceleration stop method. When the power is on again, motor will run again after dEb return time. (has applied on high-speed spindle)


Situation 1: Insufficient power supply due to momentary power-loss/unstable power (due to low voltage)/sudden heavy-load



NOTE

When Pr.07-14 is set to 0, the AC motor drive will be stopped and won't re-start at the power-on again.

Situation 2: unexpected power off, such as momentary power loss



NOTE

For example, in textile machinery, you will hope that all the machines can be decelerated to stop to prevent broken stitching when power loss. In this case, the host controller will send a message to the AC motor drive to use dEb function with deceleration time via EF.


07 - 15 Dwell Time at Accel.

Factory Setting: 0.00

Settings 0.00~600.00 seconds

↘	07 - 16	Dwell Frequency at Accel.	Factory Setting: 0.00
		Settings 0.00~600.00 seconds	
↘	07 - 17	Dwell Frequency at Accel.	Factory Setting: 0.00
		Settings 0.00~600.00Hz	
↘	07 - 18	Dwell Frequency at Decel.	Factory Setting: 0.00
		Settings 0.00~600.00 Hz	

📖 Pr.07-15 to Pr.07-18 is for heavy load to prevent OV or OC occurs.



↘	07 - 19	Fan Cooling Control	Factory Setting: 0
		Settings 0: Fan always ON	
		1: 1 minute after the AC motor drive stops, fan will be OFF	
		2: When the AC motor drive runs, the fan is ON. When the AC motor drive stops, the fan is OFF	
		3: Fan turns ON when preliminary heat sink temperature (around 60°C) is attained.	
		4: Fan always OFF	

📖 This parameter is used for the fan control.

📖 Setting 0: Fan will be ON as the drive's power is turned ON.

📖 Setting 1: 1 minute after AC motor drive stops, fan will be OFF

📖 Setting 2: AC motor drive runs and fan will be ON. AC motor drive stops and fan will be OFF.


📖 Setting 3: Fan run according to IGBT and capacitance temperature. Fan will be ON when preliminary capacitance temperature is higher than 60°C. Fan will be OFF, when capacitance temperature is lower than 40°C.

📖 Setting 4: Fan is always OFF

07 - 20 Emergency Stop (EF) & Force Stop

Factory Setting: 0


- Settings
- 0: Coast to stop
 - 1: Stop by 1st deceleration time
 - 2: Stop by 2nd deceleration time
 - 3: Stop by 3rd deceleration time
 - 4: Stop by 4th deceleration time
 - 5: System Deceleration
 - 6: Automatic Deceleration


 Pr.07-20 determines AC motor drive stop method. When the multi-function input terminal is set to 10 or 18 and is activated, the drive will stop according to the setting in Pr.07-20.


07 - 21 Auto Energy-saving Setting

Factory Setting: 0

- Settings
- 0 : Disable
 - 1 : Enable


 When Pr.07-21 is set to 1, the acceleration and deceleration will operate with full voltage. During constant speed operation, it will auto calculate the best voltage value by the load power for the load. This function is not suitable for the ever-changing load or near full-load during operation.

 When the output frequency is constant, i.e. constant operation, the output voltage will auto decrease by the load reduction. Therefore, the drive will operate with min. power, multiplication of voltage and current.

**07 - 22** Energy-saving Gain

Factory Setting: 100







- Settings 10~1000%

 When Pr.00-19 is set to 1, this parameter can be used to adjust the gain of energy-sAVIIng. The factory setting is 100%. If the result is not good, it can adjust by decreasing the setting. If the motor oscillates, it should increase the setting.

07 - 23 Auto Voltage Regulation(AVR) Function

Factory Setting: 0


- Settings
- 0: Enable AVR
 - 1: Disable AVR
 - 2: Disable AVR during deceleration

-  The rated voltage of the motor is usually 220V/200VAC 60Hz/50Hz and the input voltage of the AC motor drive may vary between 180V to 264 VAC 50Hz/60Hz. Therefore, when the AC motor drive is used without AVR function, the output voltage will be the same as the input voltage. When the motor runs at voltages exceeding the rated voltage with 12% - 20%, its lifetime will be shorter and it can be damaged due to higher temperature, failing insulation and unstable torque output.
-  AVR function automatically regulates the AC motor drive output voltage to the motor rated voltage. For instance, if V/f curve is set at 200 VAC/50Hz and the input voltage is at 200V to 264VAC, then the motor Output Voltage will automatically be reduced to a maximum of 200VAC/50Hz. If the input voltage is at 180V to 200VAC, output voltage to motor and input power will be in direct proportion.
-  Setting 0: when AVR function is enabled, the drive will calculate the output voltage by actual DC-bus voltage. The output voltage won't be changed by DC bus voltage.
-  Setting 1: when AVR function is disabled, the drive will calculate the output voltage by DC-bus voltage. The output voltage will be changed by DC bus voltage. It may cause insufficient/over current.
-  Setting 2: the drive will disable the AVR during deceleration, such as operated from high speed to low speed.
-  When the motor ramps to stop, the deceleration time is longer. When setting this parameter to 2 with auto acceleration/deceleration, the deceleration will be quicker.

07 - 24 Filter Time of Torque Compensation (V/F and SVC control mode)

Factory Setting: 0.020



- Settings 0.001~10.000 seconds

-  When the setting is too long, the control will be stable but the control response will be delay. When the setting is too short, the response will be quickly but the control may be unstable. User can adjust the setting by the control and response situation.

07 - 25 Filter Time of Slip Compensation (V/F and SVC control mode)

Factory Setting: 0.100




- Settings 0.001~10.000 seconds

-  It can set Pr.05-22 and 05-23 to change the response time of compensation.
-  If Pr.05-22 and 05-23 are set to 10seconds, the response time of compensation is the slowest. But the system may be unstable when the setting is too short.

07 - 26 Torque Compensation Gain (V/F control mode)

Factory Setting: 0






Settings 0~10

-  When the motor load is large, a part of drive output voltage is absorbed by the resistor of stator winding and causes insufficient voltage at motor induction and result in over output current and insufficient output torque. It can auto adjust output voltage by the load and keep the air gap magnetic fields stable to get the optimal operation.
-  In the V/F control, the voltage will be decreased in direct proportion when the frequency is decreased. It'll cause decrease torque at low speed due to small AC resistor and the same DC resistor. Therefore, Auto torque compensation function will increase the output voltage in the low frequency to get higher start torque.
-  When Pr.07-26 is set to large, it may cause motor overflux and result in too large output current, motor overheat or triggers protection function.

07 - 27 Slip Compensation Gain (V/F and SVC control mode)

Factory Setting: 0.00

Settings 0.00~10.00

-  The induction motor needs the constant slip to produce magnetic torque. It can be ignore in the higher motor speed, such as rated speed or 2-3% slip.
-  In the operation with variable frequency, the slip and the synchronous frequency will be in reverse proportion to produce the same magnetic torque. That is the slip will be larger with the reduction of synchronous frequency. The motor may stop when the synchronous frequency is decreased to a specific value. Therefore, the slip serious affects the accuracy of motor speed at low speed ◦
-  In another situation, when the drive uses with induction motor, the slip will be increased by the increasing load. It also affects the accuracy of motor speed
-  This parameter can be used to set compensation frequency and reduce the slip to close the synchronous speed when the motor runs in the rated current to raise the drive accuracy. When the drive output current is larger than Pr.05-05 No-load Current of Induction Motor 1 (A), the drive will compensation the frequency by this parameter
-  When the control method (Pr.00-11) is changed from V/f mode to vector mode, this parameter will auto be set to 1.00. Otherwise, it will be set to 0.00. Please do the compensation of slip after overload and acceleration. The compensation value should be increased from small to large gradually. That is to add the output frequency with motor rated slip X Pr.07-27 Slip Compensation Gain when the motor is rated load. If the actual speed ratio is slow than expectation, please increase the setting. Otherwise, decrease the setting.





07 - 28 Reserved

07 - 29 Slip Deviation Level

Factory Setting: 0

Settings 0~1000%

0 : Not-detectable

↗	07 - 30	Detection Time of Slip Deviation	Factory Setting: 1.0
		Settings 0.0~10.0 seconds	
↗	07 - 31	Over Slip Treatment	Factory Setting: 0
		Settings 0: Warn and keep operation 1: Warn and ramp to stop 2: Warn and coast to stop 3: No warning	
		<p> Pr.07-29 to Pr.07-31 are used to set allowable slip level/time and over slip treatment when the drive is running.</p>	
↗	07 - 32	Motor Hunting Gain	Factory Setting: 1000
		Settings 0~10000 0 : Disable	
		<p> The motor will have current wave motion in some specific area. It can improve this situation by setting this parameter. (When it is high frequency or run with PG, it can be set to 0. when the current wave motion happens in the low frequency, please increase Pr.05-29.)</p> <p> .</p>	
↗	07 - 33	Recovery Time to Pr.07-11 (# of automatic reboots after fault)	Factory Setting: 60.0
		Settings 00~6000.0 seconds	
		<p> This parameter sets the time period for counting the # of faults (ov, oc, occ) occurred. If # of faults occurred within this time period does not exceed the setting in Pr.07-11, the counting will be cleared and start from 0 when the next reboots after fault happens. However, if the # of faults occurred within this time period have exceed the setting in Pr.07-11, user needs to press the RESET key manually.</p>	
	07 - 34	Auto Acceleration/Deceleration (Kp)	Factory Setting: 40
		Settings 0~65535	
	07 - 35	Auto Acceleration/Deceleration (Ki)	Factory Setting: 0.001
		Settings 0~65535	

07 - 36 Power Generating Slip Compensation Gain

Factory Setting: 1.00

Settings 0.00~1.00

**07-37
~07-49** Reserved**07 - 50** PWM Fan Speed

Factory Setting: 60

Settings 0~100%

08 High-function PID Parameters

✎ The parameter can be set during operation.

08 - 00 Input Terminal for PID Feedback

Factory Setting: 0

Settings 0: No function


1: Negative PID feedback: input from external terminal AV11 (Pr.03-00)

4: Positive PID feedback from external terminal AV11 (Pr.03-00)

- 📖 Negative feedback means: $+\text{target value} - \text{feedback}$. It is used for the detection value will be increased by increasing the output frequency.
- 📖 Positive feedback means: $-\text{target value} + \text{feedback}$. It is used for the detection value will be decreased by increasing the output frequency.
- 📖 Common applications for PID control
 1. Flow control: A flow sensor is used to feedback the flow data and performs accurate flow control.
 2. Pressure control: A pressure sensor is used to feedback the pressure data and performs precise pressure control.
 3. Air volume control: An air volume sensor is used to feedback the air volume data to have excellent air volume regulation.
 4. Temperature control: A thermocouple or thermistor is used to feedback temperature data for comfortable temperature control.
 5. Speed control: A speed sensor or encoder is used to feedback motor shaft speed or input another machines speed as a target value for closed loop speed control of master-slave operation.

Pr.10.00 sets the PID set point source (target value). PID control operates with the feedback signal as set by Pr.10.01 either 0~+10V voltage or 4-20mA current.\

📖 PID control loop :



K_p : Proportional gain(P) T_i : Integral time(I) T_d : Derivative control(D) S : Operator

Concept of PID control


1. Proportional gain(P): the output is proportional to input. With only proportional gain control, there will always be a steady-state error.

2. Integral time (I): the controller output is proportional to the integral of the controller input. To eliminate the steady-state error, an “integral part” needs to be added to the controller. The integral time decides the relation between integral part and error. The integral part will be increased by time even if the error is small. It gradually increases the controller output to eliminate the error until it is 0. In this way a system can be stable without steady-state error by proportional gain control and integral time control.


3. Differential control (D): the controller output is proportional to the differential of the controller input. During elimination of the error, oscillation or instability may occur. The differential control can be used to suppress these effects by acting before the error. That is, when the error is near 0, the differential control should be 0. Proportional gain (P) + differential control (D) can be used to improve the system state during PID adjustment.

When PID control is used in a constant pressure pump feedback application:

Set the application’s constant pressure value (bar) to be the set point of PID control. The pressure sensor will send the actual value as PID feedback value. After comparing the PID set point and PID feedback, there will be an error. Thus, the PID controller needs to calculate the output by using proportional gain (P), integral time (I) and differential time (D) to control the pump. It controls the drive to have different pump speed and achieves constant pressure control by using a 4-20mA signal corresponding to 0-10 bar as feedback to the drive.



1. Pr.00-04 is set to 10 (Display PID analog feedback signal value (b) (%))
2. Pr.01-12 Acceleration Time will be set as required
3. Pr.01-13 Deceleration Time will be set as required
4. Pr.00-21=0 to operate from the digital keypad
5. Pr.00-20=0, the set point is controlled by the digital keypad
6. Pr.08-00=1 (Negative PID feedback from analog input)
7. ACI analog input Pr. 03-01 set to 5, PID feedback signal.
8. Pr.08-01-08-03 will be set as required
 - 8.1 If there is no vibration in the system, increase Pr.08-01(Proportional Gain (P))
 - 8.2 If there is no vibration in the system, reduce Pr.08-02(Integral Time (I))

 Refer to Pr.08-00 to 08-21 for PID parameters settings.

08 - 01 Proportional Gain (P)

Factory Setting: 1.0

Settings 0.0~500

It is used to eliminate the system error. It is usually used to decrease the error and get the faster response speed. But if setting too large value in Pr.08-01, it may cause the system oscillation and instability.

If the other two gains (I and D) are set to zero, proportional control is the only one effective.

08 - 02 Integral Time (I)

Factory Setting: 1.00

Settings 0.00~100.00 seconds
0.00 : Disable

The integral controller is used to eliminate the error during stable system. The integral control doesn't stop working until error is 0. The integral is acted by the integral time. The smaller integral time is set, the stronger integral action will be. It is helpful to reduce overshoot and oscillation to make a stable system. At this moment, the decreasing error will be slow. The integral control is often used with other two controls to become PI controller or PID controller.

This parameter is used to set the integral time of I controller. When the integral time is long, it will have small gain of I controller, the slower response and bad external control. When the integral time is short, it will have large gain of I controller, the faster response and rapid external control.

When the integral time is too small, it may cause system oscillation.

If the integral time is set as 0.00, Pr.08-02 will be disabled.

08 - 03 Derivative Control (D)

Factory Setting: 0.00

Settings 0.00~1.00 seconds

The differential controller is used to show the change of system error and it is helpful to preview the change of error. So the differential controller can be used to eliminate the error to improve system state. With the suitable differential time, it can reduce overshoot and shorten adjustment time. However, the differential operation will increase the noise interference. Please note that too large differential will cause big noise interference. Besides, the differential shows the change and the output of the differential will be 0 when there is no change. Therefore, the differential control can't be used independently. It needs to be used with other two controllers to make a PD controller or PID controller.


This parameter can be used to set the gain of D controller to decide the response of error change. The suitable differential time can reduce the overshoot of P and I controller to decrease the oscillation and have a stable system. But too long differential time may cause system oscillation


The differential controller acts for the change of error and can't reduce the interference. It is not recommended to use this function in the serious interference.

08 - 04 Upper limit of Integral Control

Factory Setting: 100.0

Settings 0.0~100.0%


 This parameter defines an upper bound or limit for the integral gain (I) and therefore limits the Master Frequency. The formula is: Integral upper bound = Maximum Output Frequency (Pr.01-00) x (Pr.08-04 %).

 Too large integral value will make the slow response due to sudden load change. In this way, it may cause motor stall or machine damage

08 - 05 PID Output Frequency Limit

Factory Setting: 100.0

Settings 0.0~110.0%

 This parameter defines the percentage of output frequency limit during the PID control. The formula is Output Frequency Limit = Maximum Output Frequency (Pr.01-00) X Pr.08-05 %.

08 - 06 Reserved

08 - 07 PID Delay Time


Factory Setting: 0.0


Settings 0.0~35.0 seconds


08 - 20 PID Mode Selection

Factory Setting: 0


Settings 0: Serial connection
1: Parallel connection

 PI Control: controlled by the P action only, and thus, the deviation cannot be eliminated entirely. To eliminate residual deviations, the P + I control will generally be utilized. And when the PI control is utilized, it could eliminate the deviation incurred by the targeted value changes and the constant external interferences. However, if the I action is excessively powerful, it will delay the responding toward the swift variation. The P action could be used solely on the loading system that possesses the integral components.


 PD Control: when deviation occurred, the system will immediately generate some operation load that is greater than the load generated single handedly by the D action to restrain the increment of the deviation. If the deviation is small, the effectiveness of the P action will be decreasing as well. The control objects include occasions with integral component loads, which are controlled by the P action only, and sometimes, if the integral component is functioning, the whole system will be vibrating. On such occasions, in order to make the P action's vibration subsiding and the system stabilizing, the PD control could be utilized. In other words, this control is good for use with loadings of no brake functions over the processes.

 PID Control: Utilize the I action to eliminate the deviation and the D action to restrain the vibration, thereafter, combine with the P action to construct the PID control. Use of the PID method could obtain a control process with no deviations, high accuracies and a stable system.

Serial Connection



Parallel connection



08 - 08 Feedback Signal Detection Time

Factory Setting: 0.0


Settings 0.0~3600.0 seconds


- 📖 This parameter is only valid when the feedback signal is ACI.
- 📖 This parameter defines the time during which the PID feedback must be abnormal before a warning is given. It also can be modified according to the system feedback signal time.
- 📖 If this parameter is set to 0.0, the system would not detect any abnormality signal.

08 - 09 Feedback Fault Treatment

Factory Setting: 0

Settings 0: Warn and keep operation
 1: Warn and ramp to stop
 2: Warn and coast to stop
 3: Warn and operate at last frequency

 This parameter is only valid when the feedback signal is ACI.

 AC motor drive acts when the feedback signals (analog PID feedback) are abnormal.

08 - 10 Sleep Frequency

Factory Setting: 0.00

Settings 0.00~600.00Hz

08 - 11 Wake-up Frequency


Factory Setting: 0.00


Settings 0.00~600.00Hz

08 - 12 Sleep Time

Factory Setting: 0.0

Settings 0.00~600.00 seconds

 If the command frequency falls below the sleep frequency, for the specified time in Pr. 08-12, then the drive will shut off the output and wait until the command frequency rises above Pr.08-11.

**08 - 13** PID Deviation Level

Factory Setting: 10.0

Settings 1.0~50.0%

08 - 14 PID Deviation Time



Factory Setting: 5.0

Settings 0.1~300.0 秒

08 – 15 Filter Time for PID Feedback

Factory Setting: 5.0

Settings 0.1~300.0 seconds

-  When the PID control function is normal, it should calculate within a period of time and close to the setpoint value.
-  Refer to the PID control diagram for details. When executing PID feedback control, if $|\text{PID reference target value} - \text{detection value}| > \text{Pr.08-13 PID Deviation Level}$ and exceeds Pr.08-14 setting, the PID control fault occurs. The treatment will be done as Pr.08-09 setting.

08 - 16 PID Compensation Selection

Factory Setting: 0

Settings 0: Parameter setting
1: Analog input

08 - 17 PID Compensation

Factory Setting: 0

Settings -100.0~+100.0%

08 - 18 Setting of Sleep mode function

Factory Setting: 0

Settings 0: Follow PID output command; 1: Follow PID feedback signal

When Pr08-18=0, Pr08-10, Pr08-11, unit is Hz, setting range is 0~600.00Hz.

When Pr08-18=1, Pr08-10, Pr08-11, unit is %, setting range is 0~200.00%

08 - 19 Integral Limit during Wakeup

Factory Setting: 50.0%

Settings 0~200%


The upper limit when the VFD is at sleep mode to avoid running at high speed right after being waken up.

There are three types of Sleep mode and Wakeup mode.

01: Frequency command(Not using PID, Pr08-00=0)

Output Frequency \leq Sleep Frequency, the drive goes to Sleep mode, 0Hz.

Sleep Mode diagram




02: Internal PID Frequency Calculation Command (Not using PID, Pr08 \neq 0)

When arriving at the sleep frequency, the system starts to calculating sleep time and the output frequency starts to decrease. If it passes the preset sleep time, the system will go to sleep at 0Hz.


If the system is not yet reaching the preset sleep time, (if there is a preset) or will stay at Pr01-07, waiting to reach the sleep time then go to sleep at 0Hz.

Internal PID calculation frequency command of CP2000



03: Percentage of PID's Target Value (Set PID, Pr08-00 ≠ 0)

When reaching the percentage of PID's Target Value and the percentage of the feedback value, the system Starts to calculate the sleep time. The output frequency decreases immediately. If the system passes the preset sleep time, it will go to sleep at 0Hz. However, if it doesn't reach the preset sleep time, it will remain at Pr01-11 (if there is a preset value) or Pr01-07 waiting to reach the sleep time then go to sleep at 0Hz



Enable or disable the Sleep and Wakeup functions depends on the setting of Pr08-10. When Pr08-10=0, it means Disable, while Pr08-10 \neq 0, it means Enable.

08 - 21 Enable PID to Change the Operation Direction


Factory Setting: 0

Settings 0: Disable change of direction
 1: Enable change of direction

09 Communication Parameters

↗ The parameter can be set during the operation.

When controlling by communication, it needs to connect the drive and PC by IFD6530 or IFD6500 converter.



Serial
communication

1:+EV
2:GND
3:SG-
4:SG+
5:NC
6:NC

↗ 09 - 00 COM1 Communication Address

Factory Setting: 1

Settings 1~254

📖 If the AC motor drive is controlled by RS-485 serial communication, the communication address for this drive must be set via this parameter. And the communication address for each AC motor drive must be different and unique

↗ 09 - 01 COM1 Transmission Speed

Factory Setting: 9.6

Settings 4.8~115.2kbits/s

📖 This parameter is used to set the transmission speed between the RS485 master (PLC, PC, etc.) and AC motor drive.

↗ 09 - 02 COM1 Transmission Fault Treatment

Factory Setting: 3

Settings 0: Warn and keep operation
1: Warn and ramp to stop
2: Warn and coast to stop
3: No warning and continue operation

📖 This parameter is set to how to react if transmission errors occur

↗ 09 - 03 COM1 Time-out Detection

Factory Setting: 0.0

Settings 0.0~100.0 seconds
0.0 : Disable

📖 It is used to set the transmission time between communication and keypad.


↗ 09 - 04 COM1 Communication Protocol


Factory Setting: 1

Settings 0 : 7 , N , 1 for ASCII
1 : 7 , N , 2 for ASCII
2 : 7 , E , 1 for ASCII
3 : 7 , O , 1 for ASCII
4 : 7 , E , 2 for ASCII

- 5 : 7 , O , 2 for ASCII
- 6 : 8 , N , 1 for ASCII
- 7 : 8 , N , 2 for ASCII
- 8 : 8 , E , 1 for ASCII
- 9 : 8 , O , 1 for ASCII
- 10 : 8 , E , 2 for ASCII
- 11 : 8 , O , 2 for ASCII
- 12 : 8 , N , 1 for RTU
- 13 : 8 , N , 2 for RTU
- 14 : 8 , E , 1 for RTU
- 15 : 8 , O , 1 for RTU
- 16 : 8 , E , 2 for RTU
- 17 : 8 , O , 2 for RTU

Computer Link Control by PC or PLC (Computer Link)

 A VFD-CP2000 can be set up to communicate on Modbus networks using one of the following modes: ASCII (American Standard Code for Information Interchange) or RTU (Remote Terminal Unit). Users can select the desired mode along with the RS-485 serial port communication protocol in Pr.09-00.

 MODBUS ASCII (American Standard Code for Information Interchange) : Each byte data is the combination of two ASCII characters. For example, a 1-byte data: 64 Hex, shown as '64' in ASCII, consists of '6' (36Hex) and '4' (34Hex).

1. Code Description

Communication protocol is in hexadecimal, ASCII: "0", "9", "A", "F", every 16 hexadecimal represents ASCII code. For example:


Character	'0'	'1'	'2'	'3'	'4'	'5'	'6'	'7'
ASCII code	30H	31H	32H	33H	34H	35H	36H	37H

Character	'8'	'9'	'A'	'B'	'C'	'D'	'E'	'F'
ASCII code	38H	39H	41H	42H	43H	44H	45H	46H


Data Format

10-bit character frame (For ASCII)


(Data Format 7 , N , 2)



(Data Format 7 , E , 1)




(Data Format 7 , O , 1)




11-bit character frame (For RTU)


(Data Format 8 , N , 2)



(Data Format 8 , E , 1)



(Data Format 8 , O , 1)



2. Communication Protocol

Communication Data Frame

ASCII mode :

STX	Start character = ‘:’ (3AH)
Address Hi	Communication Address
Address Lo	8-bit address consists of 2 ASCII codes
Function Hi	Command code:
Function Lo	8-bit command consists of 2 ASCII codes
DATA (n-1)	Contents of data:
.....	Nx8-bit data consist of 2n ASCII codes
DATA 0	n<=16, maximum of 32 ASCII codes
LRC CHK Hi	LRC check sum:
LRC CHK Lo	8-bit check sum consists of 2 ASCII codes
END Hi	End characters:
END Lo	END1= CR (0DH), END0= LF(0AH)

RTU mode :

START	A silent interval of more than 10 ms
Address	Communication address: 8-bit address
Function	Command code: 8-bit command
DATA (n-1)	Contents of data:
.....	n×8-bit data, n<=16
DATA 0	
CRC CHK Low	CRC check sum:
CRC CHK High	16-bit check sum consists of 2 8-bit characters
END	A silent interval of more than 10 ms

Address (Communication Address)

Valid communication addresses are in the range of 0 to 254. A communication address equal to 0, means broadcast to all AC drives (AMD). In this case, the AMD will not reply any message to the master device.

00H: broadcast to all AC drives

01H: AC drive of address 01

0FH: AC drive of address 15

10H: AC drive of address 16

:

FEH: AC drive of address 254

Function (Function code) and DATA (data characters)

The format of data characters depends on the function code.

03H: read data from register

06H: write single register

Example: reading continuous 2 data from register address 2102H, AMD address is 01H.

ASCII mode:

Command Message:		Response Message	
STX	' : '	STX	' : '
Address	'0'	Address	'0'
	'1'		'1'
Function	'0'	Function	'0'
	'3'		'3'
Starting address	'2'	Number of data (count by byte)	'0'
	'1'		'4'
	'0'	Content of starting address 2102H	'1'
	'2'		'7'
Number of data (count by word)	'0'	Content of address 2103H	'7'
	'0'		'0'
	'0'	LRC Check	'0'
	'2'		'0'
LRC Check	'D'	LRC Check	'7'
	'7'		'1'
END	CR	END	CR
	LF		LF

RTU mode :

Command Message:		Response Message	
Address	01H	Address	01H
Function	03H	Function	03H
Starting data address	21H	Number of data (count by byte)	04H
	02H		Content of data address 2102H
Number of data (count by world)	00H		17H
	02H	Content of data address 2103H	70H
CRC CHK Low	6FH	CRC CHK Low	00H
CRC CHK High	F7H	CRC CHK High	00H
			FEH
			5CH

06H: single write, write single data to register.

Example: writing data 6000(1770H) to register 0100H. AMD address is 01H ◦

ASCII mode :

Command Message:		Response Message	
STX	'.'	STX	'.'
Address	'0'	Address	'0'
	'1'		'1'
Function	'0'	Function	'0'
	'6'		'6'
Data address	'0'	Data address	'0'
	'1'		'1'
	'0'	Data content	'0'
	'0'		'1'
Data content	'1'	Data content	'7'
	'7'		'7'
	'7'		'7'

	'0'
LRC Check	'7'
	'1'
END	CR
	LF

	'0'
LRC Check	'7'
	'1'
END	CR
	LF

RTU mode :

Command Message:

Address	01H
Function	06H
Data address	01H
	00H
Data content	17H
	70H
CRC CHK Low	86H
CRC CHK High	22H

Response Message

Address	01H
Function	06H
Data address	01H
	00H
Data content	17H
	70H
CRC CHK Low	86H
CRC CHK High	22H

10H: write multiple registers (write multiple data to registers)

Example: Set the multi-step speed,

Pr.04-00=50.00 (1388H), Pr.04-01=40.00 (0FA0H). AC drive address is 01H.

ASCII Mode

ASCII mode :

Command Message:

STX	‘.’
ADR 1	‘0’
ADR 0	‘1’
CMD 1	‘1’
CMD 0	‘0’
Starting data address	‘0’
	‘5’
	‘0’
	‘0’
Number of data (count by word)	‘0’
	‘0’
	‘2’
Number of data (count by byte)	‘0’
	‘4’
The first data content	‘1’
	‘3’
	‘8’
The second data content	‘0’
	‘F’
	‘A’
LRC Check	‘0’
	‘9’
END	‘A’
	CR
	LF

Response Message

STX	‘.’
ADR 1	‘0’
ADR 0	‘1’
CMD 1	‘1’
CMD 0	‘0’
Starting data address	‘0’
	‘5’
	‘0’
	‘0’
Number of data (count by word)	‘0’
	‘0’
	‘2’
LRC Check	‘E’
	‘8’
END	CR
	LF

RTU Mode :

Command Message:		Response Message	
ADR	01H	ADR	01H
CMD	10H	CMD 1	10H
Starting data address	05H	Starting data address	05H
	00H		00H
Number of data (count by word)	00H	Number of data (count by word)	00H
	02H		02H
Number of data (count by byte)	04	CRC Check Low	41H
The first data content	13H	CRC Check High	04H
	88H		
The second data content	0FH		
	A0H		
CRC Check Low	'9'		
CRC Check High	'A'		

Check sum**ASCII mode:**

LRC (Longitudinal Redundancy Check) is calculated by summing up, module 256, and the values of the bytes from ADR1 to last data character then calculating the hexadecimal representation of the 2's-complement negation of the sum.

For example,

$01H+03H+21H+02H+00H+02H=29H$, the 2's-complement negation +1 of 29H is **D7H**.

RTU mode:

CRC (Cyclical Redundancy Check) is calculated by the following steps:

Step 1: Load a 16-bit register (called CRC register) with FFFFH.

Step 2: Exclusive OR the first 8-bit byte of the command message with the low order byte of the 16-bit CRC register, putting the result in the CRC register.

Step 3: Examine the LSB of CRC register.

Step 4: If the LSB of CRC register is 0, shift the CRC register one bit to the right with MSB zero filling, then repeat step 3. If the LSB of CRC register is 1, shift the CRC register one bit to the right with MSB zero filling, Exclusive OR the CRC register with the polynomial value A001H, then repeat step 3.

Step 5: Repeat step 3 and 4 until eight shifts have been performed. When this is done, a complete 8-bit byte will have been processed.

Step 6: Repeat step 2 to 5 for the next 8-bit byte of the command message. Continue doing this until all bytes have been processed. The final contents of the CRC register are the CRC value. When transmitting the CRC value in the message, the upper and lower bytes of the CRC value must be swapped, i.e. the lower order byte will be transmitted first.

The following is an example of CRC generation using C language. The function takes two arguments:

Unsigned char* data ← a pointer to the message buffer

Unsigned char length ← the quantity of bytes in the message buffer

The function returns the CRC value as a type of unsigned integer.

Unsigned int crc_chk(unsigned char* data, unsigned char length)

```

{
  int j;
  unsigned int reg_crc=0Xffff;
  while(length--){
    reg_crc ^= *data++;
    for(j=0;j<8;j++){
      if(reg_crc & 0x01){ /* LSB(b0)=1 */
        reg_crc=(reg_crc>>1) ^ 0Xa001;
      }else{
        reg_crc=reg_crc >>1;
      }
    }
  }
}

return reg_crc; // return register CRC

```

3. Address list

Content	Address	Function		
AC drive Parameters	GGnnH	GG means parameter group, nn means parameter number, for example, the address of Pr 4-01 is 0401H.		
Command Write only	2000H	Bit0~3	0: No function	
			1: Stop	
			2: Run	
			3: Jog + Run	
		Bit4~5	00B: No function	
			01B: FWD	
			10B: REV	
			11B: Change direction	
			Bit6~7	00B: 1st accel/decel
				01B: 2nd accel/decel
10B: 3rd accel/decel				
11B: 4th accel/decel				
Bit08~11	0000B: master speed			
	0001B: 1st accel/decel.			
	0010B: 2nd accel/decel			
	0011B: 3rd accel/decel			
	0100B: 4th accel/decel			
	0101B: 5th accel/decel			
0110B: 6th accel/decel				
0111B: 7th accel/decel				
1000B: 8th accel/decel				
1001B: 9th accel/decel				
1010B: 10th accel/decel				

			1011B: 11th accel/decel
			1100B: 12th accel/decel
			1101B: 13th accel/decel
			1110B: 14th accel/decel
			1111B: 15th accel/decel
	Bit12		1: enable bit06-11 function
	Bit13~14		00B: No function
			01B: operated by digital keypad
			10B: operated by Pr.00-21 setting
			11B: change operation source
	Bit15		Reserved
	2001H		Frequency command
	2002H	Bit 0	Bit 0
		Bit 1	Bit 1
		Bit 2	Bit 2
		Bit 3-15	Bit 3-15
Status monitor Read only	2100H		Error code: refer to Pr.06-17 to Pr.06-22
	2119H	Bit0	1: FWD command
		Bit1	1: Operation status
		Bit2	1: Jog command
		Bit3	1: REV command
		Bit4	1: REV command
		Bit8	1: Master frequency Controlled by communication interface
		Bit9	1: Master frequency controlled by analog signal
		Bit10	1: Operation command controlled by communication interface
		Bit11	1: Parameters have been locked
		Bit12	1: enable to copy parameter from keypad
	Bit13~15	Reserved	
	2102H		Frequency command (F)
	2103H		Output frequency (H)
	2104H		Output current (AXXX.X)
	2105H		DC-BUS Voltage (UXXX.X)
	2106H		Output voltage (EXXX.X)
	2107H		Current step number of Multi-Step Speed Operation
	2109H		Counter value
	2116H		Multi-function display (Pr.00-04)
	211BH		Max. setting frequency
	2200H		Display output current (A)
	2201H		Display counter value of TRG terminal (c)
	2202H		Display actual output frequency (H)
	2203H		Display DC-BUS voltage (u)
	2204H		Display output voltage of U, V, W (E)
	2205H		Display output power angle of U, V, W (n)
2206H		Display actual motor speed kW of U, V, W (P)	
2207H		Display motor speed in rpm estimated by the drive or encoder feedback (r00: positive speed, -00: negative speed)	
2208H		Display positive/negative output torque N-m estimated by the drive (t0.0: positive torque, -0.0: negative torque)	
2209H		Display PG feedback (as NOTE 1)	
220AH		Display PID feedback value after enabling PID function in % (b)	
220BH		Display signal of AVI1 analog input terminal, 0-10V corresponds to 0-100% (1.) (as NOTE 2)	

220CH	Display signal of ACI analog input terminal, 4-V20mA/0-10V corresponds to 0-100% (2.) (as NOTE 2)
220DH	Display signal of AVI2 analog input terminal, -10V~10V corresponds to -100~100% (3.) (as NOTE 2)
220EH	Display the IGBT temperature of drive power module in °C (c.)
220FH	Display the temperature of capacitance in °C (i.)
2210H	The status of digital input (ON/OFF), refer to Pr.02-10 (as NOTE 3)
2211H	The status of digital output (ON/OFF), refer to Pr.02-15 (as NOTE 4)
2212H	Display the multi-step speed that is executing (S)
2213H	The corresponding CPU pin status of digital input (d.) (as NOTE 3)
2214H	The corresponding CPU pin status of digital output (O.) (as NOTE 4)
2215H	Reserved
2216H	Reserved
2217H	Reserved
2218H	Reserved
2219H	Display times of counter overload (0.)
221AH	Display GFF in % (G.)
221BH	Reserved
221CH	Display PLC register D1043 data (C)
221DH	Reserved
221EH	User page displays the value in physical measure
221FH	Output Value of Pr.00-05

4. Exception response:

The AC motor drive is expected to return a normal response after receiving command messages from the master device. The following depicts the conditions when no normal response is replied to the master device.

The AC motor drive does not receive the messages due to a communication error; thus, the AC motor drive has no response. The master device will eventually process a timeout condition.

The AC motor drive receives the messages without a communication error, but cannot handle them. An exception response will be returned to the master device and an error message “CExx” will be displayed on the keypad of AC motor drive. The xx of “CExx” is a decimal code equal to the exception code that is described below.

In the exception response, the most significant bit of the original command code is set to 1, and an exception code which explains the condition that caused the exception is returned.

For example :

ASCII mode :

RTU mode :

STX	‘.’	Address	01H
Address	‘0’	Function	86H
	‘1’	Exception code	02H
Function	‘8’	CRC CHK Low	C3H
	‘6’	CRC CHK High	A1H
Exception code	‘0’		
	‘2’		
LRC CHK	‘7’		
	‘7’		
END	CR		
	LF		

The explanation of exception codes:

Exception code	Explanation
1	Illegal data value: The data value received in the command message is not available for the AC drive.
2	Illegal data address: The data address received in the command message is not available for the AC motor drive.
3	Parameters are locked: parameters can't be changed
4	Parameters can't be changed during operation
10	Communication time-out.


↘ 09 - 05 ~09- 08 Reserved

↘ 09 - 09 Response Delay Time

Factory Setting: 2.0

Settings 0.0~200.0ms

📖 This parameter is the response delay time after AC drive receives communication command as shown in the following.



↘ 09 - 10 Main Frequency of the Communication

Factory Setting: 60.00

Settings 0.00~600.00Hz

📖 When Pr.00-20 is set to 1 (RS485 communication). The AC motor drive will save the last frequency command into Pr.09-10 when abnormal turn-off or momentary power loss. After reboots the power, it will regards the frequency set in Pr.09-10 if no new frequency command is inputted

↘ 09 - 11 Block Transfer 1

↘ 09 - 12 Block Transfer 2

↘ 09 - 13 Block Transfer 3

↘ 09 - 14 Block Transfer 4

↘ 09 - 15 Block Transfer 5


↘ 09 - 16 Block Transfer 6

↘ 09 - 17 Block Transfer 7

↗ 09 - 18	Block Transfer 8
↗ 09 - 19	Block Transfer 9
↗ 09 - 20	Block Transfer 10
↗ 09 - 21	Block Transfer 11
↗ 09 - 22	Block Transfer 12
↗ 09 - 23	Block Transfer 13
↗ 09 - 24	Block Transfer 14
↗ 09 - 25	Block Transfer 15
↗ 09 - 26	Block Transfer 16

Factory Setting: 0

Settings 0~65535

 There is a group of block transfer parameter available in the AC motor drive (Pr.09-11 to Pr.09-20). User can use them (Pr.09-11 to Pr.09-20) to save those parameters that you want to read.

09 - 27
~09- 29

Reserved

09 - 30

Communication Decoding Method

Factory Setting: 1

Settings 0 : by 20XX
1 : by 60XX

09 - 31

COM 1 Protocol

Setting 0: RS485
1: Bacnet

Factory Setting: 0

09 - 35

PLC address

Factory Setting: 2

Settings 1~254

09 - 36

CANopen Slave Address

Factory Setting: 0

Settings 0: Disable
1~127

09 - 37

CANopen Speed

Factory Setting: 0

Settings 0: 1M
 1: 500k
 2: 250k
 3: 125k
 4: 100k (Data only)
 5: 50k

09 - 38 CANopen Frequency Gain

Factory Setting: 100

Settings 0.00 ~ 200

09 - 39 CANopen Warning Record

Factory Setting: Read Only

Settings bit 0 : CANopen Guarding Time out
 bit 1 : CANopen Heartbeat Time out
 bit 2 : CANopen SYNC Time out
 bit 3 : CANopen SDO Time out
 bit 4 : CANopen SDO buffer overflow
 bit 5 : Can Bus Off
 bit 6 : Error protocol of CANOPEN

09 - 40 CANopen Decoding Standard DS402

Factory Setting: 1

Settings 0 : Communication definition of CP2000 series
 1 : CANopen Standard DS402 protocol

09 - 41 CANopen Status

Factory Setting: Read Only

Settings 0: Node Reset State
 1: Com Reset State
 2: Boot up State
 3: Pre Operation State
 4: Operation State
 5: Stop State

09 - 42 CANopen Control Status

Factory Setting: Read Only

Settings 0: Not ready for use state

- 1: Inhibit start state
 - 2: Ready to switch on state
 - 3: Switched on state
 - 4: Enable operation state
 - 7: Quick stop active state
 - 13: Err reaction activation state
 - 14: Error state
-

09 - 43 Reset CANopen Index

Factory Setting: 65535

Settings 0 ~ 65535

09 - 44 Reserved**09 - 45** CANopen Master Function

Factory Setting: 0

Settings 0: Disable
1: Enable

09 - 46 CANopen Master Address

Factory Setting: 100

Settings 1~127

09 - 47~**09 - 49**

Reserved

09 - 50 BACnet MAC ID

Factory Setting: 1

Settings 0~127

09 - 51 BACnet Baud Rate

Factory Setting: 384

Settings 96~384 Kbps

09 - 52	BACnet Device ID L	Factory Setting: 1
	Settings 0~65535	
09 - 53	BACnet Device ID H	Factory Setting: 0
	Settings 0~63	
09 - 55	BACnet Polling Address	Factory Setting: 127
	Settings 0~127	
09 - 56	BACnet Password	Factory Setting: 0
	Settings 0~65535	
09 - 60	Identifications for Communication Card	Factory Setting: Read Only
	Settings 0 : No Communication Card 1 : DeviceNet Slave 2 : Profibus-DP Slave 3 : CANopen Slave/Master 4 : Modbus-TCP Slave 5 : EtherNet/IP Slave 6~8 : Reserved	
09 - 61	Firmware Version of Communication Card	Factory Setting: ##
	Settings Read Only	
09 - 62	Product Code	Factory Setting: ##
	Settings Read Only	
09 - 63	Error Code	Factory Setting: ##
	Settings Read Only	

09 – 64
~09 – 69

Reserved

09 - 70 Address of Communication Card

Factory Setting: ##

Settings DeviceNet: 0-63
Profibus-DP: 1-125

09 - 71 Setting of DeviceNet Speed(according to Pr.09-72)


Factory Setting: 2


Settings Standard DeviceNet:
0: 100Kbps
1: 125Kbps
2: 250Kbps
3: 1Mbps (Delta only)
Non standard DeviceNet: (Delta only)
0: 10Kbps
1: 20Kbps
2: 50Kbps
3: 100Kbps
4: 125Kbps
5: 250Kbps
6: 500Kbps
7: 800Kbps
8: 1Mbps

09 - 72 Other setting of Device net Speed

Factory Setting: 1

Settings 0 : Disable
1 : Enable

 This parameter needs to co-work with Pr09-71.

 Setting 0 : the baud rate can only be set to 0, 1, 2 or 3. °

 Setting 1 : setting of DeviceNet baud rate can be the same as CANopen (setting 0-8


09 - 73 Reserved


09 - 74 Reserved

09 - 75 IP Configuration of the Communication Card

Factory Setting: 0

Settings 0 : Static IP
1 : Dynamic IP (DHCP)

 Setting 0: it needs to set IP address manually.

 Setting 1: IP address will be auto set by host controller

09 - 76 IP Address 1 of the Communication Card

09 - 77 IP Address 2 of the Communication Card

09 - 78 IP Address 3 of the Communication Card

09 - 79 IP Address 4 of the Communication Card

Factory Setting: 0

Settings 0~255

09 - 80 Address Mask 1 of the Communication Card

09 - 81 Address Mask 2 of the Communication Card

09 - 82 Address Mask 3 of the Communication Card

09 - 83 Address Mask 4 of the Communication Card

Factory Setting: 0

Settings 0~255

09 - 84 Gateway Address 1 of the Communication Card

09 - 85 Gateway Address 2 of the Communication Card

09 - 86 Gateway Address 3 of the Communication Card

09 - 87 Gateway Address 4 of the Communication Card

Factory Setting: 0

Settings 0~255

09 - 88 Password for Communication Card (Low word)

09 - 89 Password for Communication Card (High word)

Factory Setting: 0

Settings 0~99

09 - 90 Reset Communication Card

Factory Setting: 0

Settings 0 : Disable

1 : Reset to the factory setting

09 - 91 Additional Setting for Communication Card

Factory Setting: 1

Settings Bit 0: Enable IP Filter

Bit 1: Internet parameters enable(1bit)

Enable to write internet parameters (1bit). This bit will change to disable when it finishes sAVING the update of internet parameters.

Bit 2: Login password enable(1bit)

Enable login password (1bit). This bit will be changed to disable when it finishes sAVING the update of internet parameters.

09 - 92 Status of Communication Card

Factory Setting: 0

Settings Bit 0: password enable

When the communication card is set with password, this bit is enabled. When the password is clear, this bit is disabled.

12 Pump Parameter

⚡ The parameter can be set during operation.

12 - 00 Circulative Control

Factory Setting: 0

- Settings
- 0: No operation
 - 1: Fixed Time Circulation (by time)
 - 2: Fixed Quantity
 - 3: Fixed quantity control**
 - 4: Fixed **T**ime Circulation + Fixed **Q**uantity Circulation
 - 5: Fixed Time **C**irculation + Fixed Quantity **C**ontrol

📖 In this mode, CP2000 can control up to 8 motors at a time. The total number of the motors can be determined by Pr.12-01. In accordance with the Fixed Time Circulation of Pr12-02, you can adjust the switching time between Start/Stop of each motor. That means when an operating motor reaches the time setting of Pr12-02, CP2000 will stop that motor. Then after the delay time setting of Pr12-03, next motor will start operating. See diagram below.




Diagram 12-1: Sequential Diagram of the Fixed Time Circulation (by time)

Disable Motors' Output

Set the Multifunction Input Commands as Disable Motors' Output can stop corresponding motors. The settings are:

P02-01~P02-06=	60	61	62	63	64	65	66	67	68
Disable Motors' Output	ALL	1	2	3	4	5	6	7	8

When a motor's output is disabled, this motor will park freely.

Wiring: Fixed Time Circulation (by time) Control can control up to 8 motors. The diagram 12-2 is an example of controlling 4 motors at the same time.




Diagram 12-2: Wiring

12 – 01 Number of Motors to be connected

Factory Setting: 1

Settings 1 to 8



Number of Motors: Maximum 8 motors. After setting number of motor to be connected at the same time, multi-function output terminals will follow automatically the setting as shown in the table below.

P12-01	01	02	03	04	05	06	07	08
P02-13	55	55	55	55	55	55	55	55
P02-14		56	56	56	56	56	56	56
P02-15			57	57	57	57	57	57
P02-36				58	58	58	58	58
P02-37					59	59	59	59
P02-38						60	60	60
P02-39							61	61
P02-40								62

Table 1: Setting of Multi-function Output Terminal on Circulating Motors**12 - 02** Operating time of each motor (minutes)

Factory Setting: 0

Settings 0 to 65500 minutes

Setting of Fixed Time Circulation by minute. If Pr12-02 = 0, that means stop timing, the current running motors will keep on operating until a stop command is given.

12 - 03 Delay Time due to the Acceleration (or the Increment) at Motor Switching (seconds)

Factory Setting: 10

Settings 0.0 to 3600.0 seconds

Delay time when switching motors in seconds. When the current running motors reach the time setting of Pr12-02, CP2000 will follow the delay time setting of Pr12-03 and then switch to run the next motors.

12 - 04 Delay Time due to the Deceleration (or the Decrement) at Motor Switching (seconds)

Factory Setting: 10

Settings 0.0 to 3600.0 seconds

12 - 05 Delay time while fixed quantity circulation at Motor Switching (seconds)

Factory Setting: 100

Settings 0.0 to 3600.0 seconds

Fixed quantity circulation with PID

Sequential Diagram

In this mode, CP2000 can control up to 4 motors to increase controlling flow quantity and pressure range. When controlling flow quantity, motors will be in parallel connection. When controlling pressure range, motors will be in series connection

If need to increase flow quantity or pressure range, CP2000 will increase first motor's pressure from 0Hz to the largest operating frequency. If output frequency reaches the frequency setting of Pr12-06 and delay time of Pr12-05, then CP2000 will delay the time setting of Pr12-03. Then CP2000 will switch the motor to use mains electricity and delay the time setting of Pr12-03 to run next motor. If necessary, other motors will be activated in sequence. See sequential diagram of 12-3 and 12-4




Diagram 12-3: Sequence of Fixed quantity circulation with PID – Increasing Demand




Diagram 12-4: Sequence of switching motors at Fixed quantity circulation with PID – Increasing Demands

However if decreasing demands when flow quantity and pressure are too big, CP2000 will stop the current operating motors and wait for the delay time setting of Pr12-04. Then keep on doing this until the last motor stop using mains electricity. See sequential diagram 12-5 and 12-6 below.




Diagram 12-5: Sequence of switching motors at Fixed quantity circulation with PID – Decreasing Demands




Diagram 12-6: Sequence of switching motors at Fixed quantity circulation with PID – Decreasing Demands

Parameter Setting

Parameter setting	Description
P12-00=2	Choose Fixed quantity circulation with PID
P12-01=X	Number of Motors: Maximum 4 motors. After setting number of motor to be connected at the same time, multi-function output terminals will follow automatically the setting as shown in the table below.
P12-01	01 02 03 04 05 06 07 08
P02-13	55 55 55 55 55 55 55 55 55 Motor #1 by Drive
P02-14	56 56 56 56 56 56 56 56 56 Motor #1 by Mains
P02-15	57 57 57 57 57 57 57 57 57 Motor #2 by Drive
P02-36	58 58 58 58 58 58 58 58 58 Motor #2 by Mains
P02-37	59 59 59 59 59 59 59 59 59 Motor #3 by Drive
P02-38	60 60 60 60 60 60 60 60 60 Motor #3 by Mains
P02-39	61 61 61 61 61 61 61 61 61 Motor #4 by Drive
P02-40	62 62 62 62 62 62 62 62 62 Motor #4 by Mains
Table 2: Setting of Multi-function Output Terminal on Circulating Motors	
P12-03=X	Delay Time due to the Acceleration (or the Increment) at Motor Switching (unit: second)
P12-04=X	Delay Time due to the Deceleration (or the Decrement) at Motor Switching (unit: sec)

P12-05=X	Delay time while fixed quantity circulation at Motor Switching with PID (unit: seconds)
P12-06=X	Frequency when switching motors at fixed quantity circulation (Hz)

Disable Motor Output

Set the Multifunction Input Commands as Disable Motors' Output can stop corresponding motors. The settings are:

P02-01~P02-06=	60	61	62	63	64	65	66	67	68
Disable Motor Output	ALL	1	2	3	4	5	6	7	8

When a motor's output is disabled, this motor will park freely

Fixed quantity circulation with PID can control up to 4 motors. The Diagram 12-7 below is an example of controlling 4 motors.




Diagram 12-7

12 - 06 Frequency when switching motors at fixed quantity circulation (Hz)

Factory Setting: 6000

Settings 0.0 to 600.00 hz

When the drive's output frequency reaches the setting value of Pr12-06, the system will start preparing to switch motors.

12 - 07 Action to do when Fixed Quantity Circulation breaks down

Factory Setting: 0

Settings 0: Turn off all output

1: Motors powered by mains electricity continues to operate

12 - 08 Frequency when stopping auxiliary motor (Hz)

Factory Setting: 0

Settings 0.00 to 600.00 hz

When the output frequency is smaller than the setting value of Pr12-08 and remains at the the time setting of Pr12-04, motors will be shut down one by one.

Fixed quantity control with PID

In this mode, CP2000 can control up to 8 motors to increase controlling flow quantity and pressure range. CP2000 connects directly to a main motor while the rest of motors are using mains electricity and controlled by a relay. When controlling flow quantity, motors will be in parallel connection. When controlling pressure range, motors will be in series connection

If need to increase flow quantity or pressure range, CP2000 will increase the main motor's pressure from 0Hz to the largest operating frequency. If necessary, CP2000 will switch in sequence the motors to use mains electricity. See sequential diagram of 12-8 and 12-9.




Diagram 12-8: Fixed quantity control with PID – Increasing Demand




Diagram 12-9: Sequence of switching motors at Fixed quantity control with PID – Increasing Demand

However, if the flow quantity or pressure is too big, CP2000 will stop, one by one, the motors from using mains electricity until CP2000 decrease the main motor’s frequency to 0Hz.

See diagram 12-10 and diagram 12-11.




Diagram 12-10: Sequence of switching motors at Fixed quantity control with PID – Decreasing Demand




Diagram 12-10: Sequence of switching motors at Fixed quantity control with PID – Decreasing Demand

Parameter Setting	Description																																																																																										
P12-00=3	Choose Fixed quantity control																																																																																										
P12-01=X	<p>Number of Motors: Maximum 8 motors. After setting number of motor to be connected at the same time, multi-function output terminals will follow automatically the setting as shown in the table below.</p> <table border="1"> <thead> <tr> <th>P12-01</th> <th>01</th> <th>02</th> <th>03</th> <th>04</th> <th>05</th> <th>06</th> <th>07</th> <th>08</th> <th></th> </tr> </thead> <tbody> <tr> <td>P02-13</td> <td>55</td> <td>55</td> <td>55</td> <td>55</td> <td>55</td> <td>55</td> <td>55</td> <td>55</td> <td>Motor #1 by Mains</td> </tr> <tr> <td>P02-14</td> <td></td> <td>56</td> <td>56</td> <td>56</td> <td>56</td> <td>56</td> <td>56</td> <td>56</td> <td>Motor #2 by Mains</td> </tr> <tr> <td>P02-15</td> <td></td> <td></td> <td>57</td> <td>57</td> <td>57</td> <td>57</td> <td>57</td> <td>57</td> <td>Motor #3 by Mains</td> </tr> <tr> <td>P02-36</td> <td></td> <td></td> <td></td> <td>58</td> <td>58</td> <td>58</td> <td>58</td> <td>58</td> <td>Motor #4 by Mains</td> </tr> <tr> <td>P02-37</td> <td></td> <td></td> <td></td> <td></td> <td>59</td> <td>59</td> <td>59</td> <td>59</td> <td>Motor #5 by Mains</td> </tr> <tr> <td>P02-38</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>60</td> <td>60</td> <td>60</td> <td>Motor #6 by Mains</td> </tr> <tr> <td>P02-39</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>61</td> <td>61</td> <td>Motor #7 by Mains</td> </tr> <tr> <td>P02-40</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>62</td> <td>Motor #8 by Mains</td> </tr> </tbody> </table> <p>Table 2: Setting of Multi-function Output Terminal on Circulating Motors</p>	P12-01	01	02	03	04	05	06	07	08		P02-13	55	55	55	55	55	55	55	55	Motor #1 by Mains	P02-14		56	56	56	56	56	56	56	Motor #2 by Mains	P02-15			57	57	57	57	57	57	Motor #3 by Mains	P02-36				58	58	58	58	58	Motor #4 by Mains	P02-37					59	59	59	59	Motor #5 by Mains	P02-38						60	60	60	Motor #6 by Mains	P02-39							61	61	Motor #7 by Mains	P02-40								62	Motor #8 by Mains
P12-01	01	02	03	04	05	06	07	08																																																																																			
P02-13	55	55	55	55	55	55	55	55	Motor #1 by Mains																																																																																		
P02-14		56	56	56	56	56	56	56	Motor #2 by Mains																																																																																		
P02-15			57	57	57	57	57	57	Motor #3 by Mains																																																																																		
P02-36				58	58	58	58	58	Motor #4 by Mains																																																																																		
P02-37					59	59	59	59	Motor #5 by Mains																																																																																		
P02-38						60	60	60	Motor #6 by Mains																																																																																		
P02-39							61	61	Motor #7 by Mains																																																																																		
P02-40								62	Motor #8 by Mains																																																																																		

P12-05=X	Delay time while fixed quantity circulation at Motor Switching (seconds)
P12-06=X	Frequency when switching motors at fixed quantity circulation (Hz)

 Disable Motor's Output

Set the Multifunction Input Commands as Disable Motors' Output can stop corresponding motors.

The settings are: :

P02-01~P02-06=	60	61	62	63	64	65	66	67	68
Disable Motor's Output	ALL	1	2	3	4	5	6	7	8

When a motor's output is disabled, this motor will park freely

Wiring: Fixed Quantity Control can control up to 8 motors. The diagram 12-12 is an example of controlling 4 motors at the same time.




Diagram 12-12

Time circulation and Fixed quantity circulation with PID

This mode combines **Time circulation and Fixed quantity circulation with PID**. It is to prevent motors to become rusty if they are not in use for a long period of time. If some motors are not activated, set the fixed time circulation to run motors one by one to make sure each of them has the chance to run.


Time circulation and Fixed quantity control with PID

This mode combines **Time circulation and Fixed quantity control with PID**. It is to prevent motors to become rusty if they are not in use for a long period of time. If some motors are not activated, set the fixed time circulation to run motors one by one to make sure each of them has the chance to run.

13 Product Applications

1. Multi Motors on Fixed Quantity Circulation Control (V/F control; 1 VFD vs. 3 Motors)

Wiring Diagram (Optional Card: EMC-RA66 Relay card x 1)



2. Applied Parameter Table

Parameter	Function	Decimal Place	Max. Value	Mini. Value	Factory Setting	Applied Setting
00-00	Identity Code of the AC Motor Drive	0	65535	0	0	17
00-01	Rated Current (Amps)	2	655.35	0.00	0.00	22.50
00-22	Stop method	0	1	0	0	1
01-00	Max. Operating Frequency (Hz)	2	600.00	50.00	60.00	50.00
01-01	M1: Max Output Frequency (Hz)	2	600.00	0.00	60.00	50.00
01-02	M1: Max Output Voltage (V)	1	510.0	0.0	400.0	380.0
01-35	M2: Max Output Frequency (Hz)	2	600.00	0.00	60.00	50.00
01-36	M2: Max Output Voltage (V)	1	510.0	0.0	400.0	380.0
02-13	RLY1: Multi Output Terminal	0	62	0	11	55
02-14	RLY2: Multi Output Terminal	0	62	0	1	56
02-15	RLY3: Multi Output Terminal	0	62	0	0	57
02-22	Desired arrival frequency 1 (Hz)	2	600.00	0.00	60.00	50.00
02-24	Desired arrival frequency 2 (Hz)	2	600.00	0.00	60.00	50.00
02-36	Expansion Card Output Terminal (MO3)	0	62	0	0	58
02-37	Expansion Card Output Terminal (MO4)	0	62	0	0	59
02-38	Expansion Card Output Terminal (MO5)	0	62	0	0	60
02-51	Multi Function Output Terminal status	0	65535	0	0	4
02-54	Display the Saved Memory of the Frequency Command Executed by External Terminal	2	600.00	0.00	60.00	50.00
03-00	AVI analog input function	0	17	0	1	5
03-03	AVI analog input bias (%)	1	100.0	-100.0	0.0	0.2
03-07	AVI positive/negative bias mode	0	4	0	0	1
05-01	IM Motor 1 Full-Load current (Amps)	2	27.00	2.25	0.00	16.19
05-02	IM1 Motor 1 Rated Power (kW)	2	655.35	0.00	0.00	11.00
05-03	IM1 Motor 1 Rated Rotational Speed (rpm)	0	65535	0	1710	1410
05-05	IM1Motor1 No Load Current (Amps)	2	16.19	0.00	0.00	7.19
05-13	IM Moto 2 Rated Current (Amps)	2	27.00	2.25	0.00	16.19
05-14	IM Motor 2 Rated Power (kW)	2	655.35	0.00	0.00	11.00
05-15	IM2 Motor 2 Rated Rotational Speed (rpm)	0	65535	0	1710	1410

Parameter	Function	Decimal Place	Max. Value	Mini. Value	Factory Setting	Applied Setting
05-17	IM Motor 2 No Load Current (Amps)	2	16.19	0.00	0.00	7.19
05-31	Accumulated Motor Functioning Time (minutes)	0	1439	0	0	27
08-00	PID feedback Terminal option	0	6	0	0	1
08-01	Proportional Gain (%)	1	500.0	0.0	80.0	1.0
08-25	Reserved	0	65535	0	0	500
08-29	Reserved	0	65535	0	0	3000
08-30	Reserved	0	65535	0	0	1000
08-31	Proportional Gain 2 (%)	1	500.0	0.0	80.0	1.0
08-34	Reserved	0	65535	0	0	10
09-10	Main Communication Frequency (Hz)	2	600.00	0.00	60.00	50.00
12-00	Circulative Control	0	5	0	0	2
12-01	Multi Motor Control	0	8	1	1	3
12-04	Motor Switch Delay Time while Deceleration (or Decrement) (seconds)	1	3600.0	0.0	1.0	10.0
12-06	Frequency when switching motors at fixed quantity circulation (Hz)	2	600.00	0.00	60.00	50.00
12-08	Frequency when stopping auxiliary motor (Hz)	2	600.00	0.00	0.00	20.00

2.1 Blown Film Extrusion Machine:
SVC Mode (Sensorless Vector Control)
Load: 18.5KW, 50 Hz, 380V, 6p, 37.7A, 970rpm
Wiring: See wiring diagram of the Frame B

Applied Parameter Table

Parameter	Function	Decimal Place	Max. Value	Mini. Value	Factory Setting	Applied Setting
00-00	ID code of the AC Motor Drive	0	65535	0	0	21
00-01	Rated Current (Amps)	2	655.35	0.00	0.00	32.00
00-11	Speed Mode Control	0	4	0	0	2
00-16	Loading mode selection	0	1	0	0	1
00-23	Motor Operating Direction Control	0	2	0	0	2
01-00	Max. Operating Frequency (Hz)	2	600.00	50.00	60.00	50.00
01-01	M1: Max. Output Frequency (Hz)	2	600.00	0.00	60.00	50.00
01-02	M1: Max Output Voltage (V)	1	510.0	0.0	400.0	380.0
01-35	M2: Max Output Frequency (Hz)	2	600.00	0.00	60.00	50.00
01-36	M2: Max Output Voltage (V)	1	510.0	0.0	400.0	380.0
02-22	Desired Arrival Frequency 1 (Hz)	2	600.00	0.00	60.00	50.00
02-24	Desired Arrival Frequency 2 (Hz)	2	600.00	0.00	60.00	50.00
05-01	IM Motor 1 Full-Load current (Amps)	2	38.40	3.20	0.00	30.00
05-02	IM Motor 1 Rated Power (kW)	2	655.35	0.00	0.00	15.00
05-03	IM Motor 1 Rated Rotational Speed (rpm)	0	65535	0	1710	1460
05-05	IM1 Motor 1 No Load Current (Amps)	2	30.00	0.00	0.00	8.99
05-06	Reserved	3	65.535	0.000	0.000	0.347
05-07	Reserved	3	65.535	0.000	0.000	0.401
05-08	Reserved	1	6553.5	0.0	0.0	146.5
05-09	Reserved	1	6553.5	0.0	0.0	9.4
05-13	IM2 Motor 2 Full Load Current (Amps)	2	38.40	3.20	0.00	28.79
05-14	IM2 Motor 2 Rated Power (kW)	2	655.35	0.00	0.00	18.50
05-15	IM2 Motor 2 Rotational Speed (rpm)	0	65535	0	1710	1410
05-17	IM2 Motor 2 No Load Current (Amps)	2	28.79	0.00	0.00	12.79
05-31	Accumulated Motor Functioning Time (minutes)	0	1439	0	0	11

Parameter	Function	Decimal Place	Max. Value	Mini. Value	Factory Setting	Applied Setting
07-27	Slip Compensation Gain	2	10.00	0.00	0.00	1.00
08-25	Reserved	0	65535	0	0	500
08-29	Reserved	0	65535	0	0	3000
08-30	Reserved	0	65535	0	0	1000
08-34	Reserved	0	65535	0	0	10
09-10	Main Communication Frequency (Hz)	2	600.00	0.00	60.00	50.00

2.2 Air Compressor Machine:

SVC mode (Sensorless Vector Control

Load: 18.5KW CP2000 to control an 11 kW motor at 23Amps, 1450 rpm


Wiring: See wiring diagram of the Frame B










Applied Parameter Table














Parameter	Function	Decimal Place	Max. Value	Mini. Value	Factory Setting	Applied Setting
00-00	ID Code of the AC Motor Drive	0	65535	0	0	21
00-01	Rated Current (Amps)	2	655.35	0.00	0.00	36.00
00-11	Velocity Control Mode	0	4	0	0	2
00-17	Carrier Frequency (KHz)	0	15	2	8	6
00-21	Source of AUTO Functioning Command	0	5	0	0	1
00-22	Stop Method	0	1	0	0	1
01-00	Max. Operating Frequency (Hz)	2	600.00	50.00	60.00	50.00
01-01	M1: Max. Output Frequency (Hz)	2	600.00	0.00	60.00	50.00
01-02	M1: Max Output Voltage (V)	1	510.0	0.0	400.0	380.0
01-35	M2: Max Output Frequency (Hz)	2	600.00	0.00	60.00	50.00
01-36	M2: Max Output Voltage (V)	1	510.0	0.0	400.0	380.0
02-22	Desired Arrival Frequency 1 (Hz)	2	600.00	0.00	60.00	50.00
02-24	Desired Arrival Frequency 2 (Hz)	2	600.00	0.00	60.00	50.00
02-54	Frequency command memory of External Terminal (Hz)	2	600.00	0.00	60.00	50.00
05-01	IM Motor 1 Full-Load current (Amps)	2	43.20	3.60	0.00	23.00
05-02	IM Motor 1 Rated Power (kW)	2	655.35	0.00	0.00	11.00
05-03	IM1 Motor 1 Rated Rotational Speed (rpm)	0	65535	0	1710	1410
05-05	IM1 Motor 1 No Load Current (Amps)	2	23.00	0.00	0.00	6.89
05-06	Reserved	3	65.535	0.000	0.000	0.705
05-07	Reserved	3	65.535	0.000	0.000	0.528
05-08	Reserved	1	6553.5	0.0	0.0	189.1
05-09	Reserved	1	6553.5	0.0	0.0	14.5
05-13	IM2 Motor 2 Full Load Current (Amps)	2	43.20	3.60	0.00	28.79
05-14	IM2 Motor 2 Rated Power (kW)	2	655.35	0.00	0.00	18.50
05-15	IM2 Motor 2 Rotational Speed (rpm)	0	65535	0	1710	1410
05-17	IM2 Motor 2 No Load Current (Amps)	2	28.79	0.00	0.00	12.79
05-31	Accumulated Motor Functioning Time(minutes)	0	1439	0	0	8

Parameter	Function	Decimal Place	Max. Value	Mini. Value	Factory Setting	Applied Setting
07-27	Slip Compensation Gain	2	10.00	0.00	0.00	1.00
08-25	Reserved	0	65535	0	0	500
08-29	Reserved	0	65535	0	0	3000
08-30	Reserved	0	65535	0	0	1000
08-34	Reserved	0	65535	0	0	10
09-10	Main Communication Frequency (Hz)	2	600.00	0.00	60.00	50.00












Chapter 14 Warning Codes












	<ul style="list-style-type: none"> ① Display error signal ② Abbreviate error code The code is displayed as shown on KPC-CE01. ③ Display error description
---	--

Display on LCM Keypad	Descriptions
	Modbus function code error
	Address of Modbus data is error
	Modbus data error
	Modbus communication error
	Modbus transmission time-out
	Keypad transmission time-out
	Keypad COPY error 1
	Keypad COPY error 2
	Keypad COPY error 3

 <p>Warning oH1 Over heat 1 warn</p>	IGBT over-heating warning
 <p>Warning oH2 Over heat 2 warn</p>	Capacity over-heating warning
 <p>Warning PID PID FBK Error</p>	PID feedback error
 <p>Warning ANL Analog loss</p>	ACI signal error When Pr03-19 is set to 1 and 2.
 <p>Warning uC Under Current</p>	Low current
 <p>Warning AUE Auto-tune error</p>	Auto tuning error
 <p>Warning oSPD Over Speed Warn</p>	Over-speed warning
 <p>Warning DAvE Deviation Warn</p>	Over speed deviation warning
 <p>Warning PHL Phase Loss</p>	Phase loss
 <p>Warning ot1 Over Torque 1</p>	Over torque 1
 <p>Warning ot2 Over Torque 2</p>	Over torque 2
 <p>Warning oH3 Motor Over Heat</p>	Motor over-heating
 <p>Warning oSL Over Slip Warn</p>	Over slip


<p>Warning HAND tUn Auto tuning</p>	Auto tuning processing
<p>Warning HAND CGdn Guarding T-out</p>	CAN guarding time-out 1
<p>Warning HAND CHbn Heartbeat T-out</p>	CAN heartbeat time-out 2
<p>Warning HAND CSYn SYNC T-out</p>	CAN synchrony time-out
<p>Warning HAND CbFn Can Bus Off</p>	CAN bus off
<p>Warning HAND CSdn SDO T-out</p>	CAN SDO transmission time-out
<p>Warning HAND CSbn Buf Overflow</p>	CAN SDO received register overflow
<p>Warning HAND Cbtn Boot up fault</p>	CAN boot up error
<p>Warning HAND CPtn Error Protocol</p>	CAN format error
<p>Warning HAND CIdn CAN/S Idx exceed</p>	CAN index error
<p>Warning HAND CAdn CAN/S Address set</p>	CAN station address error
<p>Warning HAND CFrn CAN/S FRAM fail</p>	CAN memory error
<p>Warning HAND PLod Opposite Defect</p>	PLC download error

 <p>Warning PLSv Save mem defect</p>	Save error of PLC download
 <p>Warning PLdA Data defect</p>	Data error during PLC operation
 <p>Warning PLFn Function defect</p>	Function code of PLC download error
 <p>Warning PLor Buf overflow</p>	PLC register overflow
 <p>Warning PLFF Function defect</p>	Function code of PLC operation error
 <p>Warning PLSn Check sum error</p>	PLC checksum error
 <p>Warning PLEd No end command</p>	PLC end command is missing
 <p>Warning PLCr PLC MCR error</p>	PLC MCR command error
 <p>Warning PLdF Download fail</p>	PLC download fail
 <p>Warning PLSF Scane time fail</p>	PLC scan time exceed
 <p>Warning PCGd CAN/M Guard err</p>	CAN Master guarding error
 <p>Warning PCbF CAN/M bus off</p>	CAN Master bus off

 <p>Warning PCnL CAN/M Node Lack</p>	CAN Master node error
 <p>Warning PCCt CAN/M Cycle Time</p>	CAN/M cycle time-out
 <p>Warning PCSF CAN/M SDO over</p>	CAN/M SDOover
 <p>Warning PCSD CAN/M Sdo Tout</p>	CAN/M SDO time-out
 <p>Warning PCAd CAN/M Address set</p>	CAN/M station address error
 <p>Warning ECid ExCom ID failed</p>	Duplicate MAC ID error Node address setting error
 <p>Warning ECLv ExCom pwr loss</p>	Low voltage of communication card
 <p>Warning ECtt ExCom Test Mode</p>	Communication card in test mode
 <p>Warning ECbF ExCom Bus off</p>	DeviceNet bus-off
 <p>Warning ECnP ExCom No power</p>	DeviceNet no power
 <p>Warning ECFF ExCom Factly def</p>	Factory default setting error

<p style="text-align: right; margin: 0;">HAND</p> <p>Warning ECiF ExCom Inner err</p>	Serious internal error
<p style="text-align: right; margin: 0;">HAND</p> <p>Warning ECio ExCom IONet brk</p>	IO connection break off
<p style="text-align: right; margin: 0;">HAND</p> <p>Warning ECPP ExCom Pr data</p>	Profibus parameter data error
<p style="text-align: right; margin: 0;">HAND</p> <p>Warning ECPi ExCom Conf data</p>	Profibus configuration data error
<p style="text-align: right; margin: 0;">HAND</p> <p>Warning ECEf ExCom Link fail</p>	Ethernet Link fail
<p style="text-align: right; margin: 0;">HAND</p> <p>Warning ECTo ExCom Inr T-out</p>	Communication time-out for communication card and drive
<p style="text-align: right; margin: 0;">HAND</p> <p>Warning ECCS ExCom Inr CRC</p>	Check sum error for Communication card and drive
<p style="text-align: right; margin: 0;">HAND</p> <p>Warning ECrF ExCom Rtn def</p>	Communication card returns to default setting
<p style="text-align: right; margin: 0;">HAND</p> <p>Warning ECo0 ExCom MTCP over</p>	Modbus TCP exceed maximum communication value
<p style="text-align: right; margin: 0;">HAND</p> <p>Warning ECo1 ExCom EIP over</p>	EtherNet/IP exceed maximum communication value
<p style="text-align: right; margin: 0;">HAND</p> <p>Warning ECiP ExCom IP fail</p>	IP fail
<p style="text-align: right; margin: 0;">HAND</p> <p>Warning EC3F ExCom Mail fail</p>	Mail fail
<p style="text-align: right; margin: 0;">HAND</p> <p>Warning Ecby ExCom Busy</p>	Communication card busy

Chapter 15 Fault Codes and Descriptions



① Fault

② ocA

③ Oc at accel









① Display error signal










② Abbreviated error code
The code is displayed as shown on KPC-CE01











③ Display error description.











Fault Name	Fault Descriptions	Corrective Actions
	Over-current during acceleration (Output current exceeds triple rated current during acceleration.)	<ol style="list-style-type: none"> Short-circuit at motor output: Check for possible poor insulation at the output. Acceleration Time too short: Increase the Acceleration Time. AC motor drive output power is too small: Replace the AC motor drive with the next higher power model.
	Over-current during deceleration (Output current exceeds triple rated current during deceleration.)	<ol style="list-style-type: none"> Short-circuit at motor output: Check for possible poor insulation at the output. Deceleration Time too short: Increase the Deceleration Time. AC motor drive output power is too small: Replace the AC motor drive with the next higher power model.
	Over-current during steady state operation (Output current exceeds triple rated current during constant speed.)	<ol style="list-style-type: none"> Short-circuit at motor output: Check for possible poor insulation at the output. Sudden increase in motor loading: Check for possible motor stall. AC motor drive output power is too small: Replace the AC motor drive with the next higher power model.
	Hardware failure in current detection	Return to the factory
	Ground fault	<p>When (one of) the output terminal(s) is grounded, short circuit current is more than 50% of AC motor drive rated current, the AC motor drive power module may be damaged.</p> <p>NOTE: The short circuit protection is provided for AC motor drive protection, not for protecting the user.</p> <ol style="list-style-type: none"> Check the wiring connections between the AC motor drive and motor for possible short circuits, also to ground. Check whether the IGBT power module is damaged. Check for possible poor insulation at the output.











Fault Name	Fault Descriptions	Corrective Actions
Fault occ Short Circuit	Short-circuit is detected between upper bridge and lower bridge of the IGBT module	Return to the factory
Fault ovA Ov at accel	DC BUS over-voltage during acceleration (230V: DC 450V; 460V: DC 900V)	<ol style="list-style-type: none"> 1. Check if the input voltage falls within the rated AC motor drive input voltage range. 2. Check for possible voltage transients. 3. If DC BUS over-voltage due to regenerative voltage, please increase the Deceleration Time or add an optional brake resistor.
Fault ovd Ov at decel	DC BUS over-voltage during deceleration (230V: DC 450V; 460V: DC 900V)	<ol style="list-style-type: none"> 1. Check if the input voltage falls within the rated AC motor drive input voltage range. 2. Check for possible voltage transients. 3. If DC BUS over-voltage due to regenerative voltage, please increase the Deceleration Time or add an optional brake resistor.
Fault ovn Ov at normal SPD	DC BUS over-voltage at constant speed (230V: DC 450V; 460V: DC 900V)	<ol style="list-style-type: none"> 1. Check if the input voltage falls within the rated AC motor drive input voltage range. 2. Check for possible voltage transients. 3. If DC BUS over-voltage due to regenerative voltage, please increase the Deceleration Time or add an optional brake resistor.
Fault ovS Ov at stop	Hardware failure in voltage detection	<ol style="list-style-type: none"> 1. Check if the input voltage falls within the rated AC motor drive input voltage range. 2. Check for possible voltage transients.
Fault LvA Lv at accel	DC BUS voltage is less than Pr.06-00 during acceleration	<ol style="list-style-type: none"> 1. Check if the input voltage is normal 2. Check for possible sudden load
Fault Lvd Lv at decel	DC BUS voltage is less than Pr.06-00 during deceleration	<ol style="list-style-type: none"> 1. Check if the input voltage is normal 2. Check for possible sudden load
Fault Lvn Lv at normal SPD	DC BUS voltage is less than Pr.06-00 in constant speed	<ol style="list-style-type: none"> 1. Check if the input voltage is normal 2. Check for possible sudden load
Fault LvS Lv at stop	DC BUS voltage is less than Pr.06-00 at stop	<ol style="list-style-type: none"> 1. Check if the input voltage is normal 2. Check for possible sudden load











Fault Name	Fault Descriptions	Corrective Actions
	Phase Loss	Check Power Source Input if all 3 input phases are connected without loose contacts. For models 40hp and above, please check if the fuse for the AC input circuit is blown.
	IGBT overheating IGBT temperature exceeds protection level 1 to15HP: 90 °C 20 to 100HP: 100 °C	<ol style="list-style-type: none"> 1. Ensure that the ambient temperature falls within the specified temperature range. 2. Make sure that the ventilation holes are not obstructed. 3. Remove any foreign objects from the heatsinks and check for possible dirty heat sink fins. 4. Check the fan and clean it. 5. Provide enough spacing for adequate ventilation.
	Heatsink overheating Capacitance temperature exceeds 90°C cause heatsink overheating.	<ol style="list-style-type: none"> 1. Ensure that the ambient temperature falls within the specified temperature range. 2. Make sure heat sink is not obstructed. Check if the fan is operating 3. Check if there is enough ventilation clearance for AC motor drive.
	Motor overheating The AC motor drive detects that the internal temperature exceeds Pr.06-30 (PTC level)	<ol style="list-style-type: none"> 1. Make sure that the motor is not obstructed. 2. Ensure that the ambient temperature falls within the specified temperature range. 3. Take the next higher power AC motor drive model.
	The environment temperature is too low or IGBT temperature detection fails..	<ol style="list-style-type: none"> 1.If the environment temperature is under -10°C , use heater to increase the temperature to more than -10°C . 2.If the solution above doesn't work, please contact local service provider.
	The environment temperature is too low or the capacitor temperature detection fails.	<ol style="list-style-type: none"> 1.If the environment temperature is under -10°C , use heater to increase the temperature to more than -10°C . 2.If the solution above doesn't work, please contact local service provider.
	Power off	
	Overload The AC motor drive detects excessive drive output current.	<ol style="list-style-type: none"> 1. Check if the motor is overloaded. 2. Take the next higher power AC motor drive model.

Fault Name	Fault Descriptions	Corrective Actions
	Electronics thermal relay 1 protection	<ol style="list-style-type: none"> 1. Check the setting of electronics thermal relay (Pr.06-14) Take the next higher power AC motor drive model
	Electronics thermal relay 2 protection	<ol style="list-style-type: none"> 1. Check the setting of electronics thermal relay (Pr.06-28) 2. Take the next higher power AC motor drive model
	These two fault codes will be displayed when output current exceeds the over-torque detection level (Pr.06-07 or Pr.06-10) and exceeds over-torque detection (Pr.06-08 or Pr.06-11) and it is set to 2 or 4 in Pr.06-06 or Pr.06-09.	<ol style="list-style-type: none"> 1. Check whether the motor is overloaded. 2. Check whether motor rated current setting (Pr.05-01) is suitable 3. Take the next higher power AC motor drive model.
		
	Low current detection	Check Pr.06-71, Pr.06-72, Pr.06-73.
	Limit error	
	Internal EEPROM can not be programmed.	<ol style="list-style-type: none"> 1. Press "RESET" key to the factory setting 2. Return to the factory.
	Internal EEPROM can not be read.	<ol style="list-style-type: none"> 1. Press "RESET" key to the factory setting 2. Return to the factory.
	U-phase error	Reboots the power. If fault code is still displayed on the keypad please return to the factory

Fault Name	Fault Descriptions	Corrective Actions
 <p>Fault cd2 lbs sensor err</p>	V-phase error	Reboots the power. If fault code is still displayed on the keypad please return to the factory
 <p>Fault cd3 lcs sensor err</p>	W-phase error	Reboots the power. If fault code is still displayed on the keypad please return to the factory
 <p>Fault Hd0 cc HW error</p>	CC (current clamp)	Reboots the power. If fault code is still displayed on the keypad please return to the factory
 <p>Fault Hd1 Oc HW error</p>	OC hardware error	Reboots the power. If fault code is still displayed on the keypad please return to the factory
 <p>Fault Hd2 Ov HW error</p>	OV hardware error	Reboots the power. If fault code is still displayed on the keypad please return to the factory
 <p>Fault Hd3 occ HW error</p>	Occ hardware error	Reboots the power. If fault code is still displayed on the keypad please return to the factory
 <p>Fault AUE Auto tuning err</p>	Auto tuning error	<ol style="list-style-type: none"> 1. Check cabling between drive and motor 2. Try again.
 <p>Fault AFE PID Fbk error</p>	PID loss (ACI)	<ol style="list-style-type: none"> 1. Check the wiring of the PID feedback 2. Check the PID parameters settings
 <p>Fault ACE ACI loss</p>	ACI loss	<ol style="list-style-type: none"> 1. Check the ACI wiring 2. Check if the ACI signal is less than 4mA
 <p>Fault EF External fault</p>	External Fault	<ol style="list-style-type: none"> 1. Input EF (N.O.) on external terminal is closed to GND. Output U, V, W will be turned off. 2. Give RESET command after fault has been cleared.

Fault Name	Fault Descriptions	Corrective Actions
 <p>Fault EF1 Emergency stop</p>	Emergency stop	<ol style="list-style-type: none"> When the multi-function input terminals MI1 to MI6 are set to emergency stop, the AC motor drive stops output U, V, W and the motor coasts to stop. Press RESET after fault has been cleared.
 <p>Fault bb Base block</p>	External Base Block	<ol style="list-style-type: none"> When the external input terminal (B.B) is active, the AC motor drive output will be turned off. Deactivate the external input terminal (B.B) to operate the AC motor drive again.
 <p>Fault Pcod Password error</p>	Password is locked.	Keypad will be locked. Turn the power ON after power OFF to re-enter the correct password. See Pr.00-07 and 00-08.
 <p>Fault ccod SW Code Error</p>	Software code error	
 <p>Fault CE1 PC err command</p>	Illegal function code	Check if the function code is correct (function code must be 03, 06, 10, 63)
 <p>Fault CE2 PC err address</p>	Illegal data address (00H to 254H)	Check if the communication address is correct
 <p>Fault CE3 PC err data</p>	Illegal data value	Check if the data value exceeds max./min. value
 <p>Fault CE4 PC slave fault</p>	Data is written to read-only address	Check if the communication address is correct
 <p>Fault CE10 PC time out</p>	Modbus transmission time-out	
 <p>Fault CP10 PU time out</p>	Keypad transmission time-out	

Fault Name	Fault Descriptions	Corrective Actions
 <p>Fault bF Braking fault</p>	Brake resistor fault	If the fault code is still displayed on the keypad after pressing "RESET" key, please return to the factory.
 <p>Fault ydc Y-delta connect</p>	Y-connection/ Δ -connection switch error	<ol style="list-style-type: none"> 1. Check the wiring of the Y-connection/Δ-connection 2. Check the parameters settings
 <p>Fault dEb Dec. Energy back</p>	When Pr.07-13 is not set to 0 and momentary power off or power cut, it will display dEb during accel./decel. stop.	<ol style="list-style-type: none"> 1. Set Pr.07-13 to 0 2. Check if input power is stable
 <p>Fault oSL Over slip error</p>	It will be displayed when slip exceeds Pr.05-26 setting and time exceeds Pr.05-27 setting.	<ol style="list-style-type: none"> 1. Check if motor parameter is correct (please decrease the load if overload) 2. Check the settings of Pr.05-26 and Pr.05-27
 <p>Fault S1 S1-emergency stop</p>	Emergency stop for external safety	
 <p>Fault Fire On Fire</p>	Fire Mode	
 <p>Fault Uocc A phase short</p>	Phase A short circuit	
 <p>Fault Vocc B phase short</p>	Phase B short circuit	
 <p>Fault Wocc C phase short</p>	Phase C short circuit	
 <p>Fault ryF MC Fault</p>	The electromagnet switch of the power board is not sealed. (For larger power model: Frame E and above)	

Fault Name	Fault Descriptions	Corrective Actions
 <p>Fault ocU Unknow over Amp</p>	Unknown over current	
 <p>Fault ovU Unknow over volt.</p>	Unknown over voltage	
 <p>Fault OPHL U phase lacked</p>	Output phase loss (Phase U)	
 <p>Fault OPHL V phase lacked</p>	Output phase loss (Phase V)	
 <p>Fault OPHL W phase lacked</p>	Output phase loss (Phase W)	
 <p>Fault TRAP CPU Trap Error</p>	CPU trap error	
 <p>Fault CGdE Guarding T-out</p>	CANopen guarding error	
 <p>Fault CHbE Heartbeat T-out</p>	CANopen heartbeat error	
 <p>Fault CSYE SYNC T-out</p>	CANopen synchronous error	
 <p>Fault CbFE Can bus off</p>	CANopen bus off error	

Fault Name	Fault Descriptions	Corrective Actions
<div style="border: 1px solid black; background-color: #00AEEF; color: white; padding: 5px;"> HAND Fault CIdE Can bus Index Err </div>	CANopen index error	
<div style="border: 1px solid black; background-color: #00AEEF; color: white; padding: 5px;"> HAND Fault CAde Can bus Add. Err </div>	CANopen station address error	
<div style="border: 1px solid black; background-color: #00AEEF; color: white; padding: 5px;"> HAND Fault CFrE Can bus off </div>	CANopen memory error	

Chapter 16 CANopen Overview

Newest version is available at <http://www.delta.com.tw/industrialautomation/>

- 1 CANopen Overview
- 2 CANopen Wiring
- 3 How to control by CANopen
 - 3-1 CANopen Control Mode
 - 3-2 DS402 Standard Mode
 - 3-3 Delta Standard Mode
- 4 CANopen Supporting Index
- 5 CANopen Fault Code
- 6 CANopen LED Function

Built-in EMC-COP01 card is included in VFDXXXC23E/VFDXXXC43E models.

The built-in CANopen function is a kind of remote control. Master can control the AC motor drive by using CANopen protocol. CANopen is a CAN-based higher layer protocol. It provides standardized communication objects, including real-time data (Process Data Objects, PDO), configuration data (Service Data Objects, SDO), and special functions (Time Stamp, Sync message, and Emergency message). And it also has network management data, including Boot-up message, NMT message, and Error Control message. Refer to CiA website <http://www.can-cia.org/> for details. The content of this instruction sheet may be revised without prior notice. Please consult our distributors or download the most updated version at <http://www.delta.com.tw/industrialautomation>

Delta CANopen supporting functions:

- Support CAN2.0A Protocol;
- Support CANopen DS301 V4.02;
- Support DSP-402 V2.0.

Delta CANopen supporting services:

- PDO (Process Data Objects): PDO1~ PDO2
- SDO (Service Data Object):
 - Initiate SDO Download;
 - Initiate SDO Upload;
 - Abort SDO;
 - SDO message can be used to configure the slave node and access the Object Dictionary in every node.
- SOP (Special Object Protocol):
 - Support default COB-ID in Predefined Master/Slave Connection Set in DS301 V4.02;
 - Support SYNC service;
 - Support Emergency service.
- NMT (Network Management):
 - Support NMT module control;
 - Support NMT Error control;
 - Support Boot-up.


Delta CANopen not supporting service:

- Time Stamp service



16.1 CANopen Overview

CANopen Protocol

CANopen is a CAN-based higher layer protocol, and was designed for motion-oriented machine control networks, such as handling systems. Version 4 of CANopen (CiA DS301) is standardized as EN50325-4. The CANopen specifications cover application layer and communication profile (CiA DS301), as well as a framework for programmable devices (CiA 302), recommendations for cables and connectors (CiA 303-1) and SI units and prefix representations (CiA 303-2).



RJ-45 Pin Definition



PIN	Signal	Description
1	CAN_H	CAN_H bus line (dominant high)
2	CAN_L	CAN_L bus line (dominant low)
3	CAN_GND	Ground / 0V /V-
6	CAN_GND	Ground / 0V /V-

Pre-Defined Connection Set

To reduce configuration effort for simple networks, CANopen define a mandatory default identifier allocation scheme. The 11-bit identifier structure in predefined connection is set as follows:

COB Identifier (CAN Identifier)										
10	9	8	7	6	5	4	3	2	1	0
Function Code				Node Number						

Object	Function Code	Node Number	COB-ID	Object Dictionary Index
Broadcast messages				
NMT	0000	-	0	-
SYNC	0001	-	80H	1005H, 1006H, 1007H
TIME STAMP	0010	-	100H	1012H, 1013H
Point-to-point messages				
Emergency	0001	1-127	81H-FFH	1014H, 1015H
TPDO1	0011	1-127	181H-1FFH	1800H
RPDO1	0100	1-127	201H-27FH	1400H
TPDO2	0101	1-127	281H-2FFH	1801H
RPDO2	0110	1-127	301H-37FH	1401H
TPDO3	0111	1-127	381H-3FFH	1802H
RPDO3	1000	1-127	401H-47FH	1402H
TPDO4	1001	1-127	481H-4FFH	1803H
RPDO4	1010	1-127	501H-57FH	1403H
Default SDO (tx)	1011	1-127	581H-5FFH	1200H
Default SDO (rx)	1100	1-127	601H-67FH	1200H
NMT Error Control	1110	1-127	701H-77FH	1016H, 1017H


CANopen Communication Protocol

It has services as follows:

- NMT (Network Management Object)
- SDO (Service Data Objects)
- PDO (Process Data Object)
- EMCY (Emergency Object)

NMT (Network Management Object)


The Network Management (NMT) follows a Master/Slave structure for executing NMT service. Only one NMT master is in a network, and other nodes are regarded as slaves. All CANopen nodes have a present NMT state, and NMT master can control the state of the slave nodes. The state diagram of a node is shown as follows:



- (1) After power is applied, it is auto in initialization state
 (2) Enter pre-operational state automatically
 (3) (6) Start remote node
 (4) (7) Enter pre-operational state
 (5) (8) Stop remote node
 (9) (10) (11) Reset node
 (12) (13) (14) Reset communication
 (15) Enter reset application state automatically
 (16) Enter reset communication state automatically
- A: NMT
 B: Node Guard
 C: SDO
 D: Emergency
 E: PDO
 F: Boot-up

	Initializing	Pre-Operational	Operational	Stopped
PDO			○	
SDO		○	○	
SYNC		○	○	
Time Stamp		○	○	
EMCY		○	○	
Boot-up	○			
NMT		○	○	○

NMT Protocol is shown as follows:



SDO (Service Data Objects)

SDO is used to access the Object Dictionary in every CANopen node by Client/Server model. One SDO has two COB-ID (request SDO and response SDO) to upload or download data between two nodes. No data limit for SDOs to transfer data. But it needs to transfer by segment when data exceeds 4 bytes with an end signal in the last segment.

The Object Dictionary (OD) is a group of objects in CANopen node. Every node has an OD in the system, and OD contains all parameters describing the device and its network behavior. The access path of OD is the index and sub-index, each object has a unique index in OD, and has sub-index if necessary. The request and response frame structure of SDO communication is shown as follows:

Type		Data 0								Data 1	Data 2	Data 3	Data 4	Data 5	Data 6	Data 7
		7	6	5	4	3	2	1	0	Index	Index	Index	Data	Data	Data	Data
		command								L	H	Sub	LL	LH	HL	HH
Initiate Domain Download	Client	0	0	1	-	N	E	S								
	Server	0	1	1	-	-	-	-								
Initiate Domain Upload	Client	0	1	0	-	-	-	-								
	Server	0	1	0	-	N	E	S								
Abort Domain Transfer	Client	1	0	0	-	-	-	-								
	Server	1	0	0	-	-	-	-								

N: Bytes not use

E: normal(0)/expedited(1)

S: size indicated

PDO (Process Data Object)

PDO communication can be described by the producer/consumer model. Each node of the network will listen to the messages of the transmission node and distinguish if the message has to be processed or not after receiving the message. PDO can be transmitted from one device to one another device or to many other devices. Every PDO has two PDO services: a TxPDO and a RxPDO. PDOs are transmitted in a non-confirmed mode.

PDO Transmission type is defined in the PDO communication parameter index (1400h for the 1st RxPDO or 1800h for the 1st TxPDO), and all transmission types are listed in the following table:

Type Number	PDO				
	Cyclic	Acyclic	Synchronous	Asynchronous	RTR only
0		○	○		
1-240	○		○		
241-251	Reserved				
252			○		○
253				○	○
254				○	
255				○	

Type number 1-240 indicates the number of SYNC message between two PDO transmissions.

Type number 252 indicates the data is updated (but not sent) immediately after receiving SYNC.



Type number 253 indicates the data is updated immediately after receiving RTR.

Type number 254: Delta CANopen doesn't support this transmission format.

Type number 255 indicates the data is asynchronous transmission.

All PDO transmission data must be mapped to index via Object Dictionary.

Example:



EMCY (Emergency Object)

Emergency objects are triggered when hardware failure occurs for a warning interrupt. The data format of an emergency object is a 8 bytes data as shown in the following:

Byte	0	1	2	3	4	5	6	7
Content	Emergency Error Code		Error register (Object 1001H)	Manufacturer specific Error Field				

Please refer to Chapter 5 CANopen error codes for emergency definition of CP2000.

Example:

NO.	COB-ID	RTR	DLC	D0	D1	D2	D3	D4	D5	D6	D7	Time	Description
1	000	0	2	81	01							93633355289810	NMT
2	081	0	8	00	00	00	00	00	00	00	00	93633469867147	EMG:node 1
3	701	0	1	00								93633470029134	NMT Err:node 1
4	601	0	8	28	40	60	00	7E	00	00	00	93638456352665	SDO R<(Master):node 1
5	581	0	8	60	40	60	00	00	00	00	00	93638457784984	SDO T<(Slaver):node 1
6	601	0	8	28	40	60	00	7F	00	00	00	93641854704580	SDO R<(Master):node 1
7	581	0	8	60	40	60	00	00	00	00	00	93641855252946	SDO T<(Slaver):node 1
8	601	0	8	40	41	60	00	00	00	00	00	93644908425033	SDO R<(Master):node 1
9	581	0	8	4B	41	60	00	37	06	00	00	93644909145739	SDO T<(Slaver):node 1
10	080	0	0									93646699436227	SYNC
11	201	0	2	11	22							93649160925635	PDO R<(Master)1:node 1

Master send NM message to slave 1 for RESET request.

Slave 1 responds no error

Slave 1 responds a boot up message

Master enter Index6040 = 7EH in slave 1

Slave 1 responds OK

Master enter Index6040= 7FH in slave 1

Slave 1 responds OK

Master enter value for Index6041 to slave 1


Slave 1 responds 0640H

Master enter SYNC

Master enter PD01=2211H to slave 1

16.2 CANopen Wiring

An external adapter card: EMC-COP01 is used for CANopen wiring; establish CANopen to VFD CP2000 connection. The link is enabled by using RJ45 cable. The two farthest ends must be terminated with 120Ω terminating resistors.



16.3 How to Control by CANopen

16.3.1 CANopen Control Mode

There are two control modes for CANopen; Pr.09.40 set to 1 is the factory setting mode DS402 standard and Pr.09.40 set to 0 is Delta's standard setting mode.

16.3.2 DS402 Standard Mode

To control the AC motor drive by CANopen, please set the parameters by the following steps:

1. Wiring for hardware (refer to Chapter 2 Wiring for CANopen)
2. Operation source setting: set Pr.00.21 to 3 (CANopen communication. Keypad STOP/RESET disabled.)
3. Frequency source setting: set Pr.02.00 to 6 (CANopen communication)
4. CANopen station setting: set Pr.09-36 (Range of setting is 1~127. When Pr.09-36=0, CANopen slave function is disabled.) (Note: If error arised (CAeE or CANopen memory error) as station setting is completed, press Pr.00-02=7 for reset.)
5. CANopen baud rate setting: set Pr.09.37 (CANBUS Baud Rate: 1M(0), 500K(1), 250K(2), 125K(3), 100K(4) and 50K(5))
6. Set multiple input functions to Quick Stop (it can also be enable or disable, default setting is disable). If it is necessary to enable the function, set MI terminal to 53 in one of the following parameter: Pr.02.01 ~Pr.02.08 or Pr.02.26 ~ Pr.02.31. (Note: This function is available in DS402 only.)
7. Switch to CP2000 operation mode via the NMT string; control word 0x6040 (bit 0, bit 1, bit 2, bit 3 and bit 7) and status word 0x6041.

For example:

1. If the multi-function input terminal MI set Quick Stop to disable, enable the responsive terminal of such MI terminal.
2. Set index 6040H to 7EH.
3. Set index 6040H to 7FH, the drive is now in operation mode.
4. Set index 6042H to 1500 (rpm), the default setting for pole is 4 (50Hz). Set the pole in Pr.05.04 (Motor1) and Pr.05.16 (Motor 2).

Calculation for motor speed: $n = f \times \frac{120}{p}$ where n = ramp per minute (rpm);
 P = poles
 f = frequency (Hz)

Example 1: set motor running in forward direction, $f = 30\text{Hz}$, $P = 4$.

$$(120 \times 30) / 4 = 900\text{rpm}$$

Example 2: set motor running in reverse direction, $f = 20\text{Hz}$, $P = 6$.


$$(120 \times 15) / 6 = 300\text{rpm}; 300\text{rpm} = 0x012C$$

Also,

Bit15 defines the positive and negative sign.

$$\text{i.e. Index } 6042 = -300 = (300' + 1) = 012CH' + 1 = FED3H + 1 = FED4H$$

Switching mode:



< Status Switching Graph >

8. The operation of AC motor drive in DS402 standard is controlled by the Control Word 0x6040 (bit4~bit6), as shown in the following chart:

bit 6	bit 5	bit 4	Outcome
ramp function reference	ramp function disable	ramp function enable	
0	0	0	STOP
1	0	0	STOP
0	1	0	STOP
1	1	0	STOP
0	0	1	STOP
1	0	1	LOCK (at present frequency)
0	1	1	STOP
1	1	1	RUN

9. Follow the same steps, refer to status switching process for status word 0x6041 (bit 0 to bit 6), bit 7= warn, bit 9 = 1 (permanently), bit 10= target frequency reached, bit 11= output exceeds maximum frequency.

16.3.3 Delta Standard Mode

1. Wiring (refer to Chapter 2 Wiring for CANopen).
2. Operating source setting: set Pr.00.21 to 3 (Select CANopen communication mode)
3. Frequency source setting: set Pr.00.20 to 6
4. CANopen station setting: set Pr.09.36 (CANopen communication address 1-127; 0 is to disable CANopen station setting)
5. CANopen baud rate setting: set Pr.09.37 (Baud rate options: 1M(0), 500K(1), 250K(2), 125K(3), 100K(4) and 50K(5))
6. CANopen decode method setting: set Pr.09.40 to 0.
7. 20XX address (old): in index 2020.01 enter 0002H for motor run; 0001H for motor stop. In index 2020.02 enter 1000, frequency will be 10.00Hz. Refer to Index 2020 and 2021 for more detail.

16.4 CANopen Supporting Index

Basic Index Support by CP2000:

Index	Sub	Definition	Factory Setting	R/W	Size	Note
1000H	0	Device type	00010192H	R	U32	
1001H	0	Error register	0	R	U8	
1005H	0	COB-ID SYNC message	80H	R	U32	
1006H	0	Communication cycle period	0	RW	U32	Unit: us The setting value should be in a multiple of 500us (integer) within the range 500us to 16ms
1008H	0	Manufacturer device name	0	R	U32	
1009H	0	Manufacturer hardware version	0	R	U32	
100AH	0	Manufacturer software version	0	R	U32	
100CH	0	Guarding time	0	RW	U16	Unit: ms
100DH	0	Guarding factor	0	RW	U8	
1010H	0	Store Parameter	2	R	U8	
	1	Save all parameters	0	RW	U32	
	2	Save communication parameter	1	RW	U32	
1011H	0	Restore Parameter	2	R	U8	
	1	Restore all parameters	0	RW	U32	
	2	Restore communication parameter	1	RW	U32	
1014H	0	COB-ID emergency	0000080H+Node-ID	R	U32	
1015H	0	Inhibit time EMCY	0	RW	U16	Unit:100us The setting value should be in a multiple of 10 (integer)
1016H	0	Consumer heartbeat time	1	R	U8	
	1	Consumer 1	0	RW	U32	Unit: 1ms Disable Guarding time to function properly
1017H	0	Producer heartbeat time	0	RW	U16	Unit: 1ms Disable Guarding time to function properly
1018H	0	Number	0	R	U8	
	1	Vender ID	000001DDH	R	U32	
	2	Product code	2A00+machine code	R	U32	
	3	Revision	00010000H	R	U32	
1200H	0	Server SDO Parameter	2	R	U8	
	1	COB-ID Client -> Server	0000600H+Node-ID	R	U32	
	2	COB-ID Client <- Server	0000580H+Node-ID	R	U32	
1400H	0	Number	2	R	U8	

Index	Sub	Definition	Factory Setting	R/W	Size	Note
	1	COB-ID used by PDO	00000200H+Node-ID	RW	U32	
	2	Transmission Type	5	RW	U8	00:Acyclic& Synchronous
						01~240:Cyclic & Synchronous
255:Asynchronous						
1401H	0	Number	2	R	U8	
	1	COB-ID used by PDO	80000300H+Node-ID	RW	U32	
	2	Transmission Type	5	RW	U8	00: Acyclic & Synchronous
01~240:Cyclic & Synchronous						
255:Asynchronous						
1402H	0	Number	2	R	U8	
	1	COB-ID used by PDO	80000400H+Node-ID	RW	U32	
	2	Transmission Type	5	RW	U8	00: Acyclic & Synchronous
01~240:Cyclic & Synchronous						
255:Asynchronous						
1403H	0	Number	2	R	U8	
	1	COB-ID used by PDO	80000500H+Node-ID	RW	U32	
	2	Transmission Type	5H	RW	U8	00: Acyclic & Synchronous
01~240:Cyclic & Synchronous						
255:Asynchronous						
1600H	0	Number	2	RW	U8	
	1	1.Mapped Object	60400010H	RW	U32	
	2	2.Mapped Object	60420010H	RW	U32	
	3	3.Mapped Object	0	RW	U32	
	4	4.Mapped Object	0	RW	U32	
1601H	0	Number	3	RW	U8	
	1	1.Mapped Object	20264110H	RW	U32	
	2	2.Mapped Object	2026A110H	RW	U32	
	3	3.Mapped Object	2026A210H	RW	U32	
	4	4.Mapped Object	0	RW	U32	
1602H	0	Number	3	RW	U8	
	1	1.Mapped Object	60400010H	RW	U32	
	2	2.Mapped Object	607A0020H	RW	U32	
	3	3.Mapped Object	60600008H	RW	U32	
	4	4.Mapped Object	0	RW	U32	
1603H	0	Number	3	RW	U8	
	1	1.Mapped Object	60400010H	RW	U32	
	2	2.Mapped Object	60710010H	RW	U32	
	3	3.Mapped Object	60600008H	RW	U32	
	4	4.Mapped Object	0	RW	U32	

Index	Sub	Definition	Factory Setting	R/W	Size	Note	
1800H	0	Number		5	R	U8	
	1	COB-ID used by PDO	00000180H+Node-ID		RW	U32	
	2	Transmission Type		5	RW	U8	00: Acyclic & Synchronous
							01~240: Cyclic & Synchronous
							255: Asynchronous
	3	Inhibit time		0	RW	U16	Unit: 100us The setting value should be in a multiple of 10 (integer)
	4	CMS-Priority Group		3	RW	U8	
5	Event timer		0	RW	U16	Unit: 1ms	
1801H	0	Number		5	R	U8	
	1	COB-ID used by PDO	80000280H+Node-ID		RW	U32	
	2	Transmission Type		5	RW	U8	00: Acyclic & Synchronous
							01~240: Cyclic & Synchronous
							255: Asynchronous
	3	Inhibit time		0	RW	U16	Unit: 100us The setting value should be in a multiple of 10 (integer)
	4	CMS-Priority Group		3	RW	U8	
5	Event timer		0	RW	U16	Unit: 1ms	
1802H	0	Number		5	R	U8	
	1	COB-ID used by PDO	80000380H+Node-ID		RW	U32	
	2	Transmission Type		5	RW	U8	00: Acyclic & Synchronous
							01~240: Cyclic & Synchronous
							255: Asynchronous
	3	Inhibit time		0	RW	U16	Unit: 100us The setting value should be in a multiple of 10 (integer)
	4	CMS-Priority Group		3	RW	U8	
5	Event timer		0	RW	U16	Unit: 1ms	
1803H	0	Number		5	R	U8	
	1	COB-ID used by PDO	80000480H+Node-ID		RW	U32	
	2	Transmission Type		5	RW	U8	00: Acyclic & Synchronous
							01~240: Cyclic & Synchronous
							255: Asynchronous
	3	Inhibit time		0	RW	U16	Unit: 100us The setting value should be in a multiple of 10 (integer)
	4	CMS-Priority Group		3	RW	U8	
5	Event timer		0	RW	U16	Unit: 1ms	
1A00H	0	Number		2	RW	U8	
	1	1.Mapped Object	60410010H		RW	U32	
	2	2.Mapped Object	60430010H		RW	U32	

Index	Sub	Definition	Factory Setting	R/W	Size	Note
	3	3.Mapped Object	0	RW	U32	
	4	4.Mapped Object	0	RW	U32	
1A01H	0	Number	4	RW	U8	
	1	1.Mapped Object	20260110H	RW	U32	
	2	2.Mapped Object	20266110H	RW	U32	
	3	3.Mapped Object	20266210H	RW	U32	
	4	4.Mapped Object	20266310H	RW	U32	
1A02H	0	Number	3	RW	U8	
	1	1.Mapped Object	60410010H	RW	U32	
	2	2.Mapped Object	60640020H	RW	U32	
	3	3.Mapped Object	60610008H	RW	U32	
	4	4.Mapped Object	0	RW	U32	
1A03H	0	Number	3	RW	U8	
	1	1.Mapped Object	60410010H	RW	U32	
	2	2.Mapped Object	60770010H	RW	U32	
	3	3.Mapped Object	60610008H	RW	U32	
	4	4.Mapped Object	0	RW	U32	

CP2000 Index:

Parameter index corresponds to each other as following:

Index	sub-Index
2000H + Group	member+1

For example:

Pr.10.15 (Encoder Slip Error Treatment)

Group	member
10(0A H)	15(0FH)

Index = 2000H + 0AH = 200A

Sub Index = 0FH + 1H = 10H

CP2000 Control Index:

Delta Standard Mode (Old definition)

Index	Sub	Definition	Factory Setting	R/W	Size	Note
2020H	0	Number	3	R	U8	
	1	Control word	0	RW	U16	Bit 0~1 00B:disable 01B:stop 10B:disable 11B: JOG Enable Bit2~3 Reserved Bit4~5 00B:disable 01B: Direction forward

Index	Sub	Definition	Factory Setting	R/W	Size	Note
						10B: Reverse 11B: Switch Direction
						Bit6~7 00B: 1 st step acceleration/deceleration 01B: 2 nd step acceleration/deceleration
						Bit8~15 Reserved
	2	vl target velocity (Hz)	0	RW	U16	
	3	Other trigger	0	RW	U16	Bit0 1: E.F. ON Bit1 1: Reset Bit2~15 Reserved
2021H	0	Number	DH	R	U8	
	1	Error code	0	R	U16	
2021H	2	AC motor drive status	0	R	U16	Bit 0~1 00B: stop 01B: decelerate to stop 10B: waiting for operation command 11B: in operation Bit 2 1: JOG command Bit 3~4 00B: forward running 01B: switch from reverse running to forward running 10B: switch from forward running to reverse running 11B: reverse running Bit 5~7 reserved Bit 8 1: master frequency command controlled by communication interface Bit 9 1: master frequency command controlled by analog signal input Bit 10 1: operation command controlled by communication interface Bit 11~15 Reserved
	3	Frequency command (F)	0	R	U16	
	4	Output frequency (H)	0	R	U16	
	5	Output current (AXX.X)	0	R	U16	
	6	Reserved	0	R	U16	
	7	Reserved	0	R	U16	
	8	Reserved	0	R	U16	
	9	Display output current (A)	0	R	U16	
	A	Display counter value (c)	0	R	U16	
	B	Display actual output frequency (H)	0	R	U16	
	C	Display DC-BUS voltage (u)	0	R	U16	
	D	Display output voltage (E)	0	R	U16	
	E	Display output power angle (n)	0	R	U16	
	F	Display output power in kW (P)	0	R	U16	
	10	Display actual motor speed in rpm (r)	0	R	U16	
	11	Display estimate output torque N-m (t)	0	R	U16	

Index	Sub	Definition	Factory Setting	R/W	Size	Note
	12	Display PG feedback (G) (refer to Pr.10.00 and Pr.10.01)	0	R	U16	
	13	Display PID feedback in % (b)	0	R	U16	
	14	Display AVI in % (1.)	0	R	U16	
	15	Display ACI in % (2.)	0	R	U16	
	16	Display AUI in % (3.)	0	R	U16	
	17	Display the temperature of heat sink in oC (i.)	0	R	U16	
2021H	18	Display the IGBT temperature of drive power module oC (c.)	0	R	U16	
	19	The status of digital input (ON/OFF) (i)	0	R	U16	
	1A	The status of digital output (ON/OFF) (o)	0	R	U16	
	1B	Display the multi-step speed that is executing (S)	0	R	U16	
	1C	The corresponding CPU pin status of digital input (d.)	0	R	U16	
	1D	The corresponding CPU pin status of digital output (0.)	0	R	U16	
	1E	Number of actual motor revolution (PG1 of PG card) (P.)	0	R	U16	
	1F	Pulse input frequency (PG2 of PG card) (S.)	0	R	U16	
	20	Pulse input position (PG2 of PG card) (4.)	0	R	U16	
	21	Position command tracing error (P.)	0	R	U16	
	22	Reserved	0	R	U16	
	23	Reserved	0	R	U16	
	24	Reserved	0	R	U16	
	25	Display PLC register D1043 data (C)	0	R	U16	

Delta Standard Mode (New definition):

Index	sub	R/W	bit	Bit	Bit name	Limit	Speed	Torque mode	
2060h	00h	R							
	01h	RW		0	CMD_ACT	4	fcmd = 0	Tcmd = 0	
			Pulse 0						
			1				fcmd = Fset(Fpid)	Tcmd = Tset	
				Pulse 1					
			1		EXT_CMD	4	Pulse 00	None	
							Pulse 01	Forward running	
							Pulse 10	Reverse running	
			2				Pulse 11	Change current running direction	
				0	HALT	3	Running till target speed is reached	Free (running till target torque is reached)	
			1				Temporary stop according to deceleration setting	Lock (torque stop at present speed)	
			4	0	LOCK	4	Running till target speed is reached		

Index	sub	R/W	bit	Bit	Bit name	Limit	Speed	Torque mode
				1			Frequency stop at present frequency level	
			5	0	JOG	4	JOG OFF	JOG OFF
				1			JOG RUN	JOG RUN
				Pulse 1				
			6	0	QSTOP	2	None	None
				1			Quick Stop	Quick Stop
			7	0	SERVO_ON	1	Servo OFF	Servo OFF
				1			Servo ON	Servo ON
			11~8	0000	GEAR	4	Main speed	Main torque
				0001~11			1~15 multi-steps frequency switch	
				11				
			13~12	00	ACC/DEC	4	1 st step acceleration/deceleration time	
				01			2 nd step acceleration/deceleration time	
				10			3 rd step acceleration/deceleration time	
				11			4 th step acceleration/deceleration time	
14	0	EN_SW	4	Switch in multi-step frequency and acceleration/deceleration time are not allow	Switch in multi-step frequency and acceleration/deceleration time are not allow			
	1			Switch in multi-step frequency and acceleration/deceleration time are allow	Switch in multi-step frequency and acceleration/deceleration time are allow			
15	Pulse 1	RST	4	Clear error code	Clear error code			
02h	RW							
03h	RW					Velocity command (unsigned)	Profile velocity(unsigned)	
04h	RW						-	
05h	RW						-	
06h	RW						Torque command(signed)	
07h	RW							
2061h	01h	R	0	0	ARRIVE		Target frequency is not reached	Target torque is not reached
				1			Target frequency is not reached	Target torque is not reached
			2~1	00	DIR		Forward direction	Forward run
				01			Switch from reverse direction to forward direction	Switch from reverse direction to forward direction
				10			Switch from forward direction to reverse direction	Switch from forward direction to reverse direction
				11			Reverse direction	Reverse direction
			5	0	JOG		None	None
				1			On JOG	On JOG
			6	0	QSTOP		None	None
				1			On Quick Stop	On Quick Stop
			7	0	SERVO_ON		PWM OFF	PWM OFF
				1			PWM ON	PWM ON
			8	0	PRLOCK		Parameter is not locked	Parameter is not locked
				1			Parameter locked	Parameter locked
			9	0	WARN		No warning	No warning
1	Warning	Warning						
10	0	ERROR		No error	No error			
	1			Error	Error			
11	0	IGBT_OK		IGBT OFF	IGBT OFF			
	1			IGBT ON	IGBT ON			
15~11	-	-	-	-	-			
02h	R			Velocity cmd		Actual frequency output	Actual frequency output	










Index	sub	R/W	bit	Bit	Bit name	Limit	Speed	Torque mode
	03h	R			-			
	04h	R	-		Pos Cmd			
	05h	R					Actual position (Absolute)	Actual position (Absolute)
	06h	R			Torq Cmd			
	07h	R					Actual torque	Actual torque

DS402 Standard

Index	Sub	Definition	Factory Setting	R/W	Size	Unit	PD O Map	Mode	Note
6007h	0	Abort connection option code	2	RW	S16		Yes		0: No action 2: Disable Voltage, 3: quick stop
603Fh	0	Error code	0	R0	U16		Yes		
6040h	0	Control word	0	RW	U16		Yes		
6041h	0	Status word	0	R0	U16		Yes		
6042h	0	vl target velocity	0	RW	S16	rpm	Yes	vl	
6043h	0	vl velocity demand	0	RO	S16	rpm	Yes	vl	
6044h	0	vl control effort	0	RO	S16	rpm	Yes	vl	
604Fh	0	vl ramp function time	10000	RW	U32	1ms	Yes	vl	Unit must be: 100ms, and check if the setting is set to 0.
6050h	0	vl slow down time	10000	RW	U32	1ms	Yes	vl	
6051h	0	vl quick stop time	1000	RW	U32	1ms	Yes	vl	
605Ah	0	Quick stop option code	2	RW	S16		No		0 : disable drive function 1 :slow down on slow down ramp 2: slow down on quick stop ramp 5 slow down on slow down ramp and stay in QUICK STOP 6 slow down on quick stop ramp and stay in QUICK STOP
605Ch	0	Disable operation option code	1	RW	S16		No		0: Disable drive function 1: Slow down with slow down ramp; disable of the drive function
6060h	0	Mode of operation	2	RW	S8		Yes		1: Profile Position Mode 2: Velocity Mode 4: Torque Profile Mode 6: Homing Mode
6061h	0	Mode of operation display	2	RO	S8		Yes		Same as above
6064h	0	pp Position actual value	0	RO	S32		Yes	pp	
6071h	0	tq Target torque	0	RW	S16	0.1 %	Yes	tq	Valid unit: 1%
6072h	0	tq Max torque	150	RW	U16	0.1 %	No	tq	Valid unit: 1%
6075h	0	tq Motor rated current	0	RO	U32	mA	No	tq	
6077h	0	tq torque actual value	0	RO	S16	0.1 %	Yes	tq	
6078h	0	tq current actual value	0	RO	S16	0.1 %	Yes	tq	
6079h	0	tq DC link circuit voltage	0	RO	U32	mV	Yes	tq	

Index	Sub	Definition	Factory Setting	R/W	Size	Unit	PD O Map	Mode	Note
607Ah	0	pp Target position	0	RW	S32	1	Yes	pp	

16.5 CANopen Fault Code

Display	Fault code	Description	CANopen fault code	CANopen fault register (bit 0~7)
 ocd Oc at decel	000AH	Over-current during deceleration	2310H	1
 Fault ocn Oc at normal SPD	000BH	Over-current during steady status operation	2310H	1
 Fault GFF Ground fault	000CH	Ground fault. When (one of) the output terminal(s) is grounded, short circuit current is more than 50% of AC motor drive rated current. NOTE: The short circuit protection is provided for AC motor drive Protection, not for protection of the user.	2240H	1
 Fault occ Short Circuit	000DH	Short-circuit is detected between upper bridge and lower bridge of the IGBT module.	2240H	1
 Fault ocS Oc at stop	000EH	Over-current at stop. Hardware failure in current detection	2310H	1
 ovA Ov at accel	000FH	Over-current during acceleration. Hardware failure in current detection	3210H	2
 Fault ovn Ov at normal SPD	0010H	Over-current during steady speed. Hardware failure in current detection. 230V: 450Vdc; 460V: 900Vdc	3210H	2
 Fault ovS Ov at stop	0011H	Over-voltage at stop. Hardware failure in current detection	3210H	2
 Fault LvA Lv at accel	0012H	DC BUS voltage is less than Pr.06.00 during acceleration.	3220H	2

Fault Lvd Lv at decel	0013H	DC BUS voltage is less than Pr.06.00 during deceleration.	3220H	2
Fault Lvn Lv at normal SPD	0014H	DC BUS voltage is less than Pr.06.00 in constant speed.	3220H	2
Fault LvS Lv at stop	0015H	DC BUS voltage is less than Pr.06-00 at stop	3220H	2
Fault PHL Phase Lacked	0016H	Phase Loss.	3130H	2
Fault oH1 IGBT over heat	0017H	IGBT overheat IGBT temperature exceeds protection level. 1~15HP: 90°C 20~100HP: 100°C	4310H	3
Fault oH2 Heat Sink oH	0018H	Heatsink overheat Heat sink temperature exceeds 90oC	4310H	3
Fault tH1o Thermo 1 open	0019H	Temperature detection circuit error (IGBT) IGBT NTC	4300H	3
Fault tH2o Thermo 2 open	001AH	Temperature detection circuit error (capacity module) CAP NTC	4200H	3
Fault PWR Power RST OFF	001BH	Power RST off	3120H	2
Fault oL Inverter oL	001CH	Overload. The AC motor drive detects excessive drive output current. NOTE: The AC motor drive can withstand up to 150% of the rated current for a maximum of 60 seconds.	2310H	1
Fault EoL1 Thermal relay 1	001DH	Electronics thermal relay 1 protection	2310H	1

Fault EoL2 Thermal relay 2	001EH	Electronics thermal relay 2 protection	2310H	1
Fault oH3 Motor over heat	001FH	Motor overheating The AC motor drive detects that the internal temperature exceeds Pr.06-30 (PTC level)	7120H	1
Fault ot1 Over torque 1	0020H	These two fault codes will be displayed when output current exceeds the over-torque detection level (Pr.06.07 or Pr.06.10) and exceeds over-torque detection(Pr.06.08 or Pr.06.11) and it is set 2 or 4 in Pr.06-06 or Pr.06-09.	8311H	3
Fault ot2 Over torque 2	0021H		8311H	3
Fault UC1 Under torque 1	0022H	Low torque 1	8321H	1
Fault UC2 Under torque 2	0023H	Low torque 2	8321H	1
Fault cF1 EEPROM write Err	0024H	Internal EEPROM can not be programmed.	5530H	5
Fault cF2 EEPROM read Err	0025H	Internal EEPROM can not be read.	5530H	5
Fault cd0 Isum sensor Err	0026H	Current and calculation error	2300H	1
Fault cd1 Ias sensor Err	0027H	U-phase error	2300H	1
Fault cd2 Ibs sensor Err	0028H	V-phase error	2300H	1
Fault cd3 Ics sensor Err	0029H	W-phase error	2300H	1

Fault Hd0 cc HW Error	002AH	CC (current clamp) hardware error.	5000H	5
Fault Hd1 oc HW Error	002BH	OC hardware error.	5000H	5
Fault Hd2 ov HW Error	002CH	OV hardware error.	5000H	5
Fault Hd3 GFF HW Error	002DH	GFF hardware error.	5000H	5
Fault AUE Auto tuning Err	002DH	Auto tuning error	7120H	1
Fault AFE PID Fbk Error	002EH	PID loss (ACI)	7300H	7
Fault PGF1 PG Fbk Error	002FH	PG feedback error	7300H	7
Fault PGF2 PG Fbk Loss	0030H	PG feedback loss	7300H	7
Fault PGF3 PG Fbk Over SPD	0031H	PG feedback stall	7300H	7
Fault PGF4 PG Fbk deviate	0032H	PG slip error	7300H	7
Fault PGr1 PG ref Error	0033H	Pulse input error	7300H	7
Fault PGr2 PG ref loss	0034H	Pulse input loss	7300H	7

Fault ACE ACI loss	0035H	ACI loss	FF00H	1
Fault EF External Fault	0036H	External Fault When input EF (N.O.) on external terminal is closed to GND, AC motor drive stops output U, V, and W.	9000H	5
Fault EF1 Emergency stop	0037H	Emergency stop When the multi-function input terminals MI1 to MI6 are set to emergency stop, the AC motor drive stops output U, V, W and the motor coasts to stop	9000H	5
Fault bb Base block	0038H	External Base Block When the external input terminals MI1 to MI16 are set as bb and active, the AC motor drive output will be turned off	9000H	5
Fault Pcod Password Error	0039H	Password will be locked if three fault passwords are entered	6320H	5
Fault ccod SW code Error	003AH	Software error	6320H	5
Fault cE1 Modbus CMD err	0031H	Illegal function code	7500H	4
Fault cE2 Modbus ADDR err	0032H	Illegal data address (00H to 254H)	7500H	4
Fault cE3 Modbus DATA err	0033H	Illegal data value	7500H	4
Fault cE4 Modbus slave FLT	0034H	Data is written to read-only address	7500H	4

Fault cE10 Modbus time out	0035H	Modbus transmission timeout.	7500H	4
Fault cP10 Keypad time out	0036H	Keypad transmission timeout.	7500H	4
Fault bF Braking fault	0037H	Brake resistor fault	7110H	4
Fault Ydc Y-delta connect	0038H	Y-connection/ Δ -connection switch error	3330H	2
Fault oSL Over slip Error	0039H	Overslip error occurs when the slip exceeds Pr.05.26 limit and the time exceeds Pr.05.27 setting.	FF00H	7
Fault ocU Over Apm. unknow	003AH	Unknown over current	2310H	1
Fault ovU Over volt. Unknow	003BH	Unknown over voltage	3210H	2
Fault S1 S1-Emergy stop	003CH	External emergency stop	9000H	5
Fault aocc A phase short	003DH	A-phase short-circuit	2240H	1
Fault bocc B phase short	003EH	B-phase short-circuit	2240H	1
Fault cocc C phase short	003FH	C-phase short-circuit	2240H	1
Fault CGdE Guarding T-out	0040H	Guarding time-out 1	8130H	4

<p>Fault HAND CHbE Heartbeat T-out</p>	0041H	Heartbeat time-out	8130H	4
<p>Fault HAND CSyE SYNC T-out</p>	0042H	CAN synchrony error	8700H	4
<p>Fault HAND CbFE CAN/S bus off</p>	0043H	CAN bus off	8140H	4
<p>Fault HAND CIde CAN/S ldx exceed</p>	0044H	Can index exceed	8110H	4
<p>Fault HAND CAde CAN/S add. set</p>	0045H	CAN address error	0x8100	4
<p>Fault HAND CFde CAN/S FRAM fail</p>	0046H	CAN frame fail	0x8100	4

16.6 CANopen LED Function

There are two CANopen flash signs: RUN and ERR.

RUN LED:

LED status	Condition	CANopen State
OFF		Initial
Blinking		Pre-Operation
Single flash		Stopped
ON		Operation

ERR LED:

LED status	Condition/ State
OFF	No Error
Single flash	One Message fail
Double flash	Guarding fail or heartbeat fail
Triple flash	SYNC fail
ON	Bus off

Chapter 17 PLC Function

- 17.1 PLC Overview
- 17.2 Start-up
- 17.3 PLC Ladder Diagram
- 17.4 PLC Devices
- 17.5 Commands
- 17.6 Error Code and Troubleshooting
- 17.7 CANopen Master Application

17.1 PLC Overview

17.1.1 Introduction

The built in PLC function in CP2000 allows following commands: WPLSoft, basic commands and application commands; the operation methods are the same as Delta DVPPLC series. Other than that, CANopen master provides 8 station synchronous control and 126 asynchronous controls.



In CP2000, CANopen master synchronous control complies with DS402 standard and supports control mode as return to origin point, speed, torque and point to point control; CANopen slave supports two control modes, speed and torque.

17.1.2 Ladder Diagram Editor – WPLSoft

WPLSoft is a program editor of Delta DVP-PLC series and CP2000 series for WINDOWS. Besides general PLC program planning and general WINDOWS editing functions, such as cut, paste, copy, multi-windows, WPLSoft also provides various Chinese/English comment editing and other special functions (e.g. register editing, settings, the data readout, the file saving, and contacts monitor and set, etc.).

Following is the system requirement for WPLSoft:


Item	System Requirement
Operation System	Windows 95/98/2000/NT/ME/XP
CPU	Pentium 90 and above
Memory	16MB and above (32MB and above is recommended)
Hard Disk	Capacity: 50MB and above CD-ROM (for installing WPLSoft)
Monitor	Resolution: 640×480, 16 colors and above, It is recommended to set display setting of Windows to 800×600.
Mouse	General mouse or the device compatible with Windows
Printer	Printer with Windows driver
RS-232 port	At least one of COM1 to COM8 can be connected to PLC
Applicable Models	All Delta DVP-PLC series and CP2000 series

17.2 Start-up

17.2.1 The Steps for PLC Execution

Please operate PLC follows the five steps.

1. Press menu key on KPC-CC01 → select **3: PLC** → ENTER. (See the figure below)



NOTE

Operate the KPC-CE01 (the optional digital keypad) by following steps (switch PLC mode to PLC2 for program download/upload):

- A. Go to “PLC0” page by pressing the MODE key
- B. Change to “PLC2” by pressing the “UP” key and then press the “ENTER” key after confirmation
- C. If succeeded, “END” is displayed and back to “PLC2” after one or two seconds.


The PLC warning that is displayed before the program is downloaded to CP2000 can be ignored, please continue the operation.



2. Connection: Please connect the RJ-45 of AC motor drive to computer via RS485-to-RS232 converter.



3. Run the program.



- PLC function, select function 2 (PLC Run).

- 1: Disable (PLC0)
- 2: PLC Run (PLC1)
- 3: PLC Stop (PLC2)

Optional accessories: Digital keypad KPC-CE01, display PLC function as shown in the ().

When external input terminals (MI1~MI8) are set to PLC Mode select bit0 (51) or PLC Mode select bit1 (52), it will force to switch to PLC mode regardless the terminal is ON or OFF.

Meanwhile, switching via keypad is disabled. Please refer to the chart below:

PLC Mode	PLC Mode select bit1(52)	PLC Mode select bit0 (51)
Disable (PLC 0)	OFF	OFF
PLC Run (PLC 1)	OFF	ON
PLC Stop (PLC 2)	ON	OFF
Previous state	ON	ON

When KPC-CE01 execute PLC function:

1. When switching the page from PLC to PLC1, it will execute PLC. The motion of PLC (Execute/Stop) is controlled by WPL editor.
2. When switching the page from PLC to PLC2, it will stop PLC. Again the motion of PLC (Execute/Stop) is controlled by WPL editor.
3. The control of external terminals follows the same method.

NOTE

When input/output terminals (FWD REV MI1~MI8 MI10~15, Relay1, Relay2 RY10~RY15, MO1~MO2 MO10~MO11,) are used in PLC program, they cannot be used in other places. For example, when PLC program (PLC1 or PLC2) is activated, such as when it controls Y0, the corresponding output terminals Relay (RA/RB/RC) will be used. At this moment, Pr.03.00 setting will be invalid since the terminal has been used by PLC. Refer to Pr.02-52, 02-53, 03-30 to check which DI DO AO are occupied by PLC.

17.2.2 I/O Device Reference Table

Input device:

Device	X0	X1	X2	X3	X4	X5	X6	X7	X10	X11	X12	X13	X14	X15	X16	X17
1	FWD	REV	MI1	MI2	MI3	MI4	MI5	MI6	MI7	MI8						
2											MI10	MI11	MI12	MI13	MI14	MI15
3											MI10	MI11	MI12	MI13		

1: I/O extension card

2: I/O extension card EMC-D611A (D1022=4)

3: I/O extension card EMC-D42A (D1022=5)

Output device:

Device	Y0	Y1	Y2	Y3	Y4	Y5	Y6	Y7	Y10	Y11	Y12	Y13	Y14	Y15	Y16	Y17
1	RY1	RY2		MO1	MO2											
2						MO10	MO11									
3						RY10	RY11	RY12	RY13	RY14	RY15					


1: I/O extension card

2: I/O extension card EMC-D42A (D1022=5)


3: I/O extension card EMC-R6AA (D1022=6)

17.2.3 WPLSoft Installation

Download PLC program to CP2000: Refer to D.3 to D.7 for program coding and download the editor (WPLSoft V2.09) at DELTA website <http://www.delta.com.tw/industrialautomation/>



17.2.4 Program Input



17.2.5 Program Download

Please download the program by following steps:

Step 1. Press  button for compiler after inputting program in WPLSoft.

Step 2. After compiler is finished, choose the item "Write to PLC" in the communication items.

After finishing Step 2, the program will be downloaded from WPLSoft to the AC motor drive by the communication format.




17.2.6 Program Monitor

If you execute "start monitor" in the communication item during executing PLC, the ladder diagram will be shown as follows.



17.2.7 Restriction of PLC


1. The protocol of PLC is 7,N,2 ,9600, station number 2
2. Make sure that the AC drive is in stop status.
3. Stop the PLC before upload/download the program.
4. When using WPR command, do not change the value over 10^9 times or serious error would result.
5. Set Pr. 00.04 to 28 to display the value in PLC register D1043, as shown in the figure follows:

<p>Digital Keypad KPC-CC01 can display 0~65535</p> 	<p>Digital keypad KPC-CE01 can display 0~9999</p>  <p>When exceed 9999:</p> 
--	--

6. When PLC is Stop, communication RS-485 is occupied by PLC.
7. When PLC is in Run and Stop mode, Pr00.02 can not be set to 9 or 10, which means can not return to factory setting.
8. Set Pr.00.02 to 6, return to factory setting of PLC.

17.3 Ladder Diagram

17.3.1 Program Scan Chart of the PLC Ladder Diagram



17.3.2 Ladder Diagram

Ladder diagram is a diagram language that applied on the automatic control and it is also a diagram that made up of the symbols of electric control circuit. PLC procedures are finished after ladder diagram editor edits the ladder diagram. It is easy to understand the control flow that indicated with diagram and also accept by technical staff of electric control circuit. Many basic symbols and motions of ladder diagram are the same as mechanical and electrical equipments of traditional automatic power panel, such as button, switch, relay, timer, counter and etc.

The kinds and amounts of PLC internal equipment will be different with brands. Although internal equipment has the name of traditional electric control circuit, such as relay, coil and contact. It doesn't have the real components in it. In PLC, it just has a basic unit of internal memory. If this bit is 1, it means the coil is ON and if this bit is 0, it means the coil is OFF. You should read the corresponding value of that bit when using contact (Normally Open, NO or contact a). Otherwise, you should read the opposite state of corresponding value of that bit when using contact (Normally Closed, NC or contact b). Many relays will need many bits, such as 8-bits makes up a byte. 2 bytes can make up a word. 2 words make up double word. When using many relays to do calculation, such as add/subtraction or shift, you could use byte, word or double word. Furthermore, the two equipments, timer and counter, in PLC not only have coil but also value of counting time and times.


















In conclusion, each internal storage unit occupies fixed storage unit. When using these equipments, the corresponding content will be read by bit, byte or word.

Brief introduction to the internal devices of PLC:

Internal Device	Function
Input Relay	Input relay is the basic storage unit of internal memory that corresponds to external input point (it is the terminal that used to connect to external input switch and receive external input signal). Input signal from external will decide it to


	<p>display 0 or 1. You couldn't change the state of input relay by program design or forced ON/OFF via WPLSoft. The contacts (contact a, b) can be used unlimitedly. If there is no input signal, the corresponding input relay could be empty and can't be used with other functions.</p> <p><input checked="" type="checkbox"/> Equipment indication method: X0, X1...X7, X10, X11... The symbol of equipment is X and numbering in octal.</p>
Output Relay	<p>Output relay is the basic storage unit of internal memory that corresponds to external output point (it is used to connect to external load). It can be driven by input relay contact, the contact of other internal equipment and itself contact. It uses a normally open contact to connect to external load and other contacts can be used unlimitedly as input contacts. It doesn't have the corresponding output relay, if need, it can be used as internal relay.</p> <p><input checked="" type="checkbox"/> Equipment indication: Y0, Y1...Y7, Y10, Y11... The symbol of equipment is Y and numbering in octal.</p>
Internal Relay	<p>The internal relay doesn't connect directly to outside. It is an auxiliary relay in PLC. Its function is the same as the auxiliary relay in electric control circuit. Each auxiliary relay has the corresponding basic unit. It can be driven by the contact of input relay, output relay or other internal equipment. Its contacts can be used unlimitedly. Internal auxiliary relay can't output directly, it should output with output point.</p> <p><input checked="" type="checkbox"/> Equipment indication: M0, M1...M799. The symbol of equipment is M and numbering in decimal system.</p>
Counter	<p>Counter is used to count. It needs to set counter before using counter (i.e. the pulse of counter). There are coil, contacts and storage unit of counter in counter. When coil is from OFF to ON, that means input a pulse in counter and the counter should add 1. There are 16-bit, 32-bit and high-speed counter for user to use.</p> <p><input checked="" type="checkbox"/> Equipment indication: C0, C1... C79. The symbol of equipment is C and numbering in decimal system.</p>
Timer	<p>Timer is used to control time. There are coil, contact and timer storage. When coil is ON, its contact will act (contact a is close, contact b is open) when attaining desired time. The time value of timer is set by settings and each timer has its regular period. User sets the timer value and each timer has its timing period. Once the coil is OFF, the contact won't act (contact a is open and contact b is close) and the timer will be set to zero.</p> <p><input checked="" type="checkbox"/> Equipment indication: T0, T1...T159. The symbol of equipment is T and numbering in decimal system. The different number range corresponds with the different timing period.</p>
Data register	<p>PLC needs to handle data and operation when controlling each order, timer value and counter value. The data register is used to store data or parameters. It stores 16-bit binary number, i.e. a word, in each register. It uses two continuous number of data register to store double words.</p> <p><input checked="" type="checkbox"/> Equipment indication: D0, D1,...,D399. The symbol of equipment is D and numbering in decimal system.</p>

The structure of ladder diagram and information:

Ladder Diagram Structure	Explanation	Command	Device
	Normally open, contact a	LD	X, Y, M, T, C
	Normally closed, contact b	LDI	X, Y, M, T, C
	Serial normally open	AND	X, Y, M, T, C
	Parallel normally open	OR	X, Y, M, T, C
	Parallel normally closed	ORI	X, Y, M, T, C
	Rising-edge trigger switch	LDP	X, Y, M, T, C
	Falling-edge trigger switch	LDF	X, Y, M, T, C
	Rising-edge trigger in serial	ANDP	X, Y, M, T, C
	Falling-edge trigger in serial	ANDF	X, Y, M, T, C
	Rising-edge trigger in parallel	ORP	X, Y, M, T, C
	Falling-edge trigger in parallel	ORF	X, Y, M, T, C
	Block in serial	ANB	none
	Block in parallel	ORB	none
	Multiple output	MPS MRD MPP	none
	Output command of coil drive	OUT	Y, M
	Basic command, Application command	Basic command/ Application command	
	Inverse logic	INV	none


17.3.3 The Edition of PLC Ladder Diagram

The program edited method is from left power line to right power line. (The right power line will be omitted during the edited of WPLSoft.) After editing a row, go to editing the next row. The maximum contacts in a row are 11 contacts. If you need more than 11 contacts, you could have the new row and start with continuous line to continue more input devices. The continuous number will be produced automatically and the same input point can be used repeatedly. The drawing is shown as follows.



The operation of ladder diagram is to scan from left upper corner to right lower corner. The output handling, including the operation frame of coil and application command, at the most right side in ladder diagram.

Take the following diagram for example; we analyze the process step by step. The number at the right corner is the explanation order.



The explanation of command order:


- 1 LD X0
- 2 OR M0
- 3 AND X1
- 4 LD X3
- AND M1
- ORB
- 5 LD Y1
- AND X4

The explanation of command order:


- 6 LD T0
- AND M3
- ORB
- 7 ANB
- 8 OUT Y1
- TMR T0 K10

The detail explanation of basic structure of ladder diagram


1. **LD (LDI) command:** give the command LD or LDI in the start of a block.



The structures of command LDP and LDF are similar to the command LD. The difference is that command LDP and LDF will act in the rising-edge or falling-edge when contact is ON as shown in the following.




2. **AND (ANI) command:** single device connects to a device or a block in series.




The structures of ANDP and ANDF are the same but the action is in rising-edge or falling-edge.

3. **OR (ORI) command:** single device connects to a device or a block.




The structures of ORP and ORF are the same but the action is in rising-edge or falling-edge.

4. **ANB command:** a block connects to a device or a block in series.



5. **ORB command:** a block connects to a device or a block in parallel.




If there are several blocks when operate ANB or ORB, they should be combined to blocks or network from up to down or from left to right.

6. **MPS, MRD, MPP commands:** Divergent memory of multi-output. It can produce many various outputs.

7. The command MPS is the start of divergent point. The divergent point means the connection place between horizontal line and vertical line. We should determine to have contact memory command or not according to the contacts status in the same vertical line. Basically, each contact could have memory command but in some places of ladder diagram conversion will be omitted due to the PLC operation convenience and capacity limit. MPS command can be used for 8 continuous times

and you can recognize this command by the symbol “┘”.

8. MRD command is used to read memory of divergent point. Because the logical status is the same in the same horizontal line, it needs to read the status of original contact to keep on analyzing other ladder diagram. You can recognize the command MRD by the symbol “┘”.
9. MPP command is used to read the start status of the top level and pop it out from stack. Because it is the last item of the horizontal line, it means the status of this horizontal line is ending.




17.3.4 The Example for Designing Basic Program

Start, Stop and Latching

In the same occasions, it needs transient close button and transient open button to be start and stop switch. Therefore, if you want to keep the action, you should design latching circuit. There are several latching circuits in the following:


Example 1: the latching circuit for priority of stop

When start normally open contact X1=On, stop normally contact X2=Off, and Y1=On are set at the same time, if X2=On, the coil Y1 will stop acting. Therefore, it calls priority of stop.



Example 2: the latching circuit for priority of start


When start normally open contact X1=On, stop normally contact X2=Off and Y1=On (coil Y1 will be active and latching) are valid at the same time, if X2=On, coil Y1 will be active due to latched contact. Therefore, it calls priority of start.




Example 3: the latching circuit of SET and RST commands

The figure at the right side is latching circuit that made up of RST and SET command. It is top priority of stop when RST command is set behind SET command. When executing PLC from up to down, The coil Y1 is ON and coil Y1 will be OFF when X1 and X2 act at the same time, therefore it calls priority of stop. It is top priority of start when SET command is set after RST command. When X1 and X2 act at the same time, Y1 is ON so it calls top priority of start.

Top priority of stop





Top priority of start



The common control circuit



Example 4: condition control

X1 and X3 can start/stop Y1 separately, X2 and X4 can start/stop Y2 separately and they are all self latched circuit. Y1 is an element for Y2 to do AND function due to the normally open contact connects to Y2 in series. Therefore, Y1 is the input of Y2 and Y2 is also the input of Y1.




Example 5: Interlock control

The figure above is the circuit of interlock control. Y1 and Y2 will act according to the start contact X1 and X2. Y1 and Y2 will act not at the same time, once one of them acts and the other won't act. (This is called interlock.) Even if X1 and X2 are valid at the same time, Y1 and Y2 won't act at the same time due to up-to-down scan of ladder diagram. For this ladder diagram, Y1 has higher priority than Y2.




Example 6: Sequential Control



If add normally close contact Y2 into Y1 circuit to be an input for Y1 to do AND function. (as shown in the left side) Y1 is an input of Y2 and Y2 can stop Y1 after acting. In this way, Y1 and Y2 can execute in sequential.



Example 7: Oscillating Circuit

The period of oscillating circuit is $\Delta T + \Delta T$





The figure above is a very simple ladder step diagram. When starting to scan Y1 normally close contact, Y1 normally close contact is close due to the coil Y1 is OFF. Then it will scan Y1 and the coil Y1 will be ON and output 1. In the next scan period to scan normally close contact Y1, Y1 normally close contact will be open due to Y1 is ON. Finally, coil Y1 will be OFF. The result of repeated scan, coil Y will output the vibrating pulse with cycle time ΔT (On) + ΔT (Off).

The vibrating circuitry of cycle time ΔT (On) + ΔT (Off):





The figure above uses timer T0 to control coil Y1 to be ON. After Y1 is ON, timer T0 will be closed at the next scan period and output Y1. The oscillating circuit will be shown as above. (n is the setting of timer and it is decimal number. T is the base of timer. (clock period))

Example 8: Blinking Circuit





The figure above is common used oscillating circuit for indication light blinks or buzzer alarms. It uses two timers to control On/OFF time of Y1 coil. If figure, n1 and n2 are timer setting of T1 and T2. T is the base of timer (clock period)

Example 9: Triggered Circuit



In figure above, the rising-edge differential command of X0 will make coil M0 to have a single pulse of ΔT (a scan time). Y1 will be ON during this scan time. In the next scan time, coil M0 will be OFF, normally close M0 and normally close Y1 are all closed. However, coil Y1 will keep on being ON and it will make coil Y1 to be OFF once a rising-edge comes after input X0 and coil M0 is ON for a scan time. The timing chart is as shown above. This circuit usually executes alternate two actions with an input. From above timing: when input X0 is a square wave of a period T, output coil Y1 is square wave of a period 2T.



Example 10: Delay Circuit



When input X0 is ON, output coil Y1 will be ON at the same time due to the corresponding normally close contact OFF makes timer T10 to be OFF. Output coil Y1 will be OFF after delaying 100 seconds ($K1000 \times 0.1 \text{ seconds} = 100 \text{ seconds}$) once input X0 is OFF and T10 is ON. Please refer to timing chart above.



Example 11: Output delay circuit, in the following example, the circuit is made up of two timers.

No matter input X0 is ON or OFF, output Y4 will be delay.



Example 12: Extend Timer Circuit

In this circuit, the total delay time from input X0 is close and output Y1 is ON = $(n1+n2) \times T$. where T is clock period. Timer: T11, T12; Timer cycle: T.



17.4 PLC Devices Function

Items	Specifications	Remarks
Control Method	Stored program, cyclic scan system	
I/O Processing Method	Batch processing (when END instruction is executed)	I/O refresh instruction is available
Execution Speed	Basic commands (minimum 0.24 us)	Application commands (1 ~ dozens us)
Program Language	Instruction, Ladder Logic, SFC	
Program Capacity	1000 STEPS	
Commands	80 commands	30 basic commands 50 application commands
Input/Output Contact	Input (X): 10, output (Y): 4	

	Device	Item	Range	Function	
Relay [bit mode]	X	External Input Relay	X0~X17, 16 points, octal number system	Total is 32 points Correspond to external input point	
	Y	External Output Relay	Y0~Y17, 16 points, octal number system		Correspond to external output point
	M	Auxiliary	For general	M0~M799, 800 points	Total is 192 points Contacts can switch to On/Off in program
			For special	M1000~M1079, 80 points	
	T	Timer	100ms timer	T0~T159, 160 points	Total is 16 points When the timer indicated by TMR command attains the setting, the T contact with the same number will be On.
C	Counter	16-bit count up for general	C0~C79, 80 points	Total is 80 points When the counter indicated by CNT command attains the setting, the C contact with the same number will be On.	
Register [WORD data]	T	Present value of timer	T0~T15, 160 points	When timer attains, the contact of timer will be On.	
	C	Present value of counter	C0~C79, 16-bit counter, 80 points	When timer attains, the contact of timer will be On.	
	D	Data register	For latched	D0~D399, 400 points	Total is 1300 points It can be memory area for storing data.
For general			D1000~D1099, 100 points		
For special			D2000~D2799, 800 points		
Constant	K	Decimal	K-32,768 ~ K32,767 (16-bit operation)		
	H	Hexadecimal	H0000 ~ HFFFF (16-bit operation)		
Communication port (program read/write)			RS485 (slave)		
Analog input/output			Built-in 2 analog inputs and 1 analog output		
Function extension module (optional)			EMC-D42A; EMC-R6AA; EMCD611A		


17.4.1 Devices Functions

The Function of Input/output Contacts

The function of input contact X: input contact X reads input signal and enter PLC by connecting with input equipment. It is unlimited usage times for contact A or contact B of each input contact X in program. The On/Off of input contact X can be changed with the On/Off of input equipment but can't be changed by using peripheral equipment (WPLSoft).

The Function of Output Contact Y

The mission of output contact Y is to drive the load that connects to output contact Y by sending On/Off signal. There are two kinds of output contact: one is relay and the other is transistor. It is unlimited usage times for A or B contact of each output contact Y in program. But there is number for output coil Y and it is recommended to use one time in program. Otherwise, the output result will be decided by the circuit of last output Y with PLC program scan method.



The output of Y0 will be decided by circuit ②, i.e. decided by On/Off of X10.

Value, Constant [K] / [H]

Constant	K	Decimal	K-32,768 ~ K32,767 (16-bit operation)
	H	Hexadecimal	H0000 ~ HFFFF (16-bit operation)


There are five value types for DVP-PLC to use by the different control destination. The following is the explanation of value types.

Binary Number (BIN)

It uses binary system for the PLC internal operation or storage. The relative information of binary system is in the following.

Bit	Bit is the basic unit of binary system, the status are 1 or 0.
Nibble	It is made up of continuous 4 bits, such as b3~b0. It can be used to represent number 0~9 of decimal or 0~F of hexadecimal.
Byte	It is made up of continuous 2 nibbles, i.e. 8 bits, b7~b0. It can used to represent 00~FF of hexadecimal system.
Word	It is made up of continuous 2 bytes, i.e. 16-bit, b15~b0. It can used to represent 0000~FFFF of hexadecimal system.
Double Word	It is made up of continuous 2 words, i.e. 32-bit, b31~b0. It can used to represent 00000000~FFFFFFFF of hexadecimal system.

The relations among bit, nibble, byte, word, and double word of binary number are shown as follows.



➤ **Octal Number (OCT)**

The numbers of external input and output terminal of DVP-PLC use octal number.

Example:

External input: X0~X7, X10~X17... (device number)

External output: Y0~Y7, Y10~Y17... (device number)

➤ **Decimal Number, DEC**

The suitable time for decimal number to be used in DVP-PLC system.

- To be the setting value of timer T or counter C, such as TMR C0 K50. (K constant)
- To be the device number of M, T, C and D. For example: M10, T30. (device number)
- To be operand in application command, such as MOV K123 D0. (K constant)

➤ **Binary Code Decimal (BCD)**

It shows a decimal number by a unit number or four bits so continuous 16-bit can use to represent the four numbers of decimal number. BCD code is usually used to read the input value of DIP switch or output value to 7-segment display to be display.

➤ **Hexadecimal Number (HEX)**

The suitable time for hexadecimal number to be used in DVP-PLC system.

- To be operand in application command. For example: MOV H1A2B D0. (constant H)

➤ **Constant K:**

In PLC, it is usually have K before constant to mean decimal number. For example, K100 means 100 in decimal number.

Exception: The value that is made up of K and bit equipment X, Y, M, S will be bit, byte, word or double word. For example, K2Y10, K4M100. K1 means a 4-bit data and K2~K4 can be 8, 12 and 16-bit data separately.

➤ **Constant H:**

In PLC, it is usually have H before constant to mean hexadecimal number. For example, H100 means 100 in hexadecimal number.

The Function of Auxiliary Relay

There are output coil and A, B contacts in auxiliary relay M and output relay Y. It is unlimited usage times in program. User can control loop by using auxiliary relay, but can't drive external load directly. There are two types divided by its characteristics.

1. Auxiliary relay for general : It will reset to Off when power loss during running. Its state will be Off when power on after power loss.
2. Auxiliary relay for special : Each special auxiliary relay has its special function. Please don't use undefined auxiliary relay.

The Function of Timer

The unit of timer is 1ms, 10ms and 100ms. The count method is count up. The output coil will be On when the present value of timer equals to the settings. The setting is K in decimal number. Data register D can be also used as settings.

- The real setting time of timer = unit of timer * settings

The Features and Functions of Counter

Item	16-bit counters	32-bit counters	
Type	General	General	High speed
Count direction	Count up	Count up/down	
Settings	0~32,767	-2,147,483,648~+2,147,483,647	
Designate for constant	Constant K or data register D	Constant K or data register D (2 for designated)	
Present value change	Counter will stop when attaining settings	Counter will keep on counting when attaining settings	
Output contact	When count attains the settings value, contact will be On and latched.	When count up attains settings, contact will be On and latched. When count down attains settings, contact will reset to Off.	
Reset action	The present value will reset to 0 when RST command is executed and contact will reset to Off.		
Present register	16-bit	32-bit	
Contact action	After scanning, act together.	After scanning, act together. Act immediately when count attains. It has no relation with scan period.	


Functions:

When pulse input signal of counter is from Off to On, the present value of counter equals to settings and output coil is On. Settings are decimal system and data register D can also be used as settings.


16-bit counters C0~C79:

- Setting range of 16-bit counter is K0~K32, 767. (K0 is the same as K1. output contact will be On immediately at the first count.
- General counter will be clear when PLC is power loss. If counter is latched, it will remember the value before power loss and keep on counting when power on after power loss.
- If using MOV command, WPLSoft to send a value, which is large than setting to C0, register, at the next time that X1 is from Off to On, C0 counter contact will be On and present value will be set to the same as settings.
- The setting of counter can use constant K or register D (not includes special data register D1000~D1044) to be indirect setting.
- If using constant K to be setting, it can only be positive number but if setting is data register D, it can be positive/negative number. The next number that counter counts up from 32,767 is -32,768.

Example:



1. When X0=On, RST command is executed, C0 reset to 0 and output contact reset to Off.
2. When X1 is from Off to On, counter will count up (add 1).
3. When counter C0 attains settings K5, C0 contact is On and C0 = setting =K5. C0 won't accept X1 trigger signal and C0 remains K5.



17.4.2 Special Auxiliary Relays

Special M	Function	Read(R)/Write(W)
M1000	Normally open contact (a contact). This contact is On when running and it is On when the status is set to RUN.	Read only
M1001	Normally closed contact (b contact). This contact is Off when running and it is Off when the status is set to RUN.	Read only
M1002	On only for 1 scan after RUN. Initial pulse is contact a. It will get positive pulse in the RUN moment. Pulse width=scan period.	Read only
M1003	Off only for 1 scan after RUN. Initial pulse is contact a. It will get negative pulse in the RUN moment. Pulse width=scan period.	Read only
M1004	Reserved	-
M1005	Fault indication of the AC motor drives	Read only
M1006	Output frequency is 0, M1006 On	Read only
M1007	Operation direction of AC motor drives (FWD: M1007 Off, REV: M1007On)	Read only
M1008 ~ M1010	Reserved	-
M1011	10ms clock pulse, 5ms On/5ms Off	Read only
M1012	100ms clock pulse, 50ms On / 50ms Off	Read only
M1013	1s clock pulse, 0.5s On / 0.5s Off	Read only
M1014	1min clock pulse, 30s On / 30s Off	Read only
M1015	Frequency attained, M1015=On	Read only
M1016	Parameter read/write error, M1016=On	Read only
M1017	Succeed to write parameter, M1017 =On	Read only
M1018	Reserved	
M1019	Reserved	
M1020	Zero flag	Read only
M1021	Borrow flag	Read only

M1022	Carry flag	Read only
M1023	Divisor is 0	Read only
M1024	Reserved	-
M1025	RUN(ON) / STOP(OFF) the AC motor drive	Read/Write
M1026	The operation direction of the AC motor drive (FWD: OFF, REV: ON)	Read/Write
M1027	AC motor drive reset	Read/Write
M1028	Reserved	
M1029	Reserved	
M1030	Reserved	
M1031	Reserved	
M1032	Reserved	
M1033	Reserved	
M1034	Enable CANopen real time control	Read/Write
M1035 ~ M1039	Reserved	-
M1040	Power On	Read/Write
M1041	Reserved	-
M1042	Quick stop	Read/Write
M1043	Reserved	-
M1044	Halt	Read/Write
M1045 ~ M1047	Reserved	-
M1048	New position	Read/Write
M1049	Change now	Read/Write
M1050	Reserved	
M1051	Reserved	
M1052	Lock	Read/Write
M1053 ~ M1054	Reserved	-
M1055	Home	Read/Write
M1056	Power on ready	Read only
M1057	Reserved	-
M1058	On quick stopping	Read only
M1059	CANopen master setting complete	Read only
M1060	Initializing CANopen slave	Read only
M1061	Initialize CANopen slave failed	Read only
M1062	Reserved	-
M1063	Target torque attained	Read only
M1064	Target position attained	Read only
M1065	Set pos ack	Read only

M1066	Read/ Write CANopen data complete	Read only
M1067	Read/ Write CANopen data succeed	Read only
M1068 ~ M1070	Reserved	-
M1071	Home error	Read only
M1072	Reserved	
M1073 ~ M1079	Reserved	

17.4.3 Special Registers

Special D	Function	Read(R)/ Write(W)
D1000	Reserved	-
D1001	PLC firmware version	Read only
D1002	Program capacity	Read only
D1003	Checksum	Read only
D1004 ~ D1009	Reserved	-
D1010	Present scan time (Unit: 0.1ms)	Read only
D1011	Minimum scan time (Unit: 0.1ms)	Read only
D1012	Maximum scan time (Unit: 0.1ms)	Read only
D1013 ~ D1019	Reserved	-
D1020	Output frequency (0.000~600.00Hz)	Read only
D1021	Output current (####.#A)	Read only
D1022	The ID of the extension card: 0: no card 1: Relay Card(6 out) 2: I/O Card (4 in 2 out) 3~7: Reserved	Read only
D1023	The ID of the extension card: 0: no card 1: DeviceNet Slave 2: Profibus-DP Slave 3: CANopen Slave 4: Modbus-TCP Slave 5: EtherNet/IP Slave 6~8: Reserved	Read only
D1024 ~ D1026	Reserved	-
D1027	Frequency command of the PID control	Read only
D1028	The responsive value of AUI AVI (analog voltage input) (0.00~100.00%)	Read only
D1029	The responsive value of AUI ACI (analog current input) (0.0~100.00%)	Read only
D1030	The corresponding value for AUI (-100.0~100.00%)	Read only

Special D	Function	Read(R)/ Write(W)
D1031 ~ D1035	Reserved	-
D1036	AC motor drive error code	Read only
D1037	AC motor drive output frequency	Read only
D1038	DC Bus voltage	Read only
D1039	Output voltage	Read only
D1040	Analog output value AFM1 (-100.00~100.00%)	Read/Write
D1041 ~ D1042	Reserved	-
D1043	User defined (When Pr.00.04 is set to 28, the register data will be displayed as C xxx)	Read/Write
D1044	Reserved	-
D1045	Analog output value AFM2 (-100.00~100.00%)	Read/Write
D1046 ~ D1049	Reserved	-
D1050	Actual mode 0: Velocity mode 1: Position mode 2: Torque mode 3: Homing mode	Read only
D1051	Actual position (Low word)	Read only
D1052	Actual position (High word)	Read only
D1053	Actual torque	Read only
D1054 ~ D1059	Reserved	Read only
D1060	Mode setting 0: Velocity Mode 1: Position Mode 2: Torque Mode 3: Homing Mode	Read/Write
D1061	Reserved	-
D1062	Reserved	-
D1063	Year	Read only
D1064	Week	Read only
D1065	Month	Read only
D1066	Day	Read only
D1067	Hour	Read only
D1068	Minute	Read only
D1069	Second	Read only

CANopen Master Special D (It can be written only when PLC is at STOP)

Special D	Function	PDO Map	Power Failure Memory	Factory Setting	R/W
D1070	The station which completed CANopen initialization (bit0=Machine code0	NO	NO	0	R
D1071	The station which error occurs during CANopen initialization (bit0=Machine code0	NO	NO	0	R
D1072	Reserved	-	-		-

Special D	Function	PDO Map	Power Failure Memory	Factory Setting	R/W
D1073	CANopen station cut off (bit0=Machine code0	NO	NO		R
D1074	Error code of master error 0: no error 1: slave setting error 2: synchronous cycle setting error (the setting is too low)	NO	NO	0	R
D1075	Reserved	-	-		-
D1076	SDO fault (main index value)	NO	NO		R
D1077	SDO fault (sub-index value)	NO	NO		R
D1078	SDO fault (error code L)	NO	NO		R
D1079	SDO fault (error code H)	NO	NO		R
D1080	Reserved	-	-		-
D1081	Reserved	NO	NO		R
D1082	Reserved	NO	NO		R
D1083	Reserved	NO	NO		R
D1084	Reserved	NO	NO		R
D1085	Reserved	NO	NO		R
D1086	Reserved	NO	NO		R
D1087 ~ D1089	Reserved	-	-		-
D1090	Synchronous cycle setting	NO	YES	4	RW
D1091	The station for initialization during initializing process.	NO	YES	FFFFH	RW
D1092	Delay time before initializing	NO	YES	0	RW
D1093	Break off detection time	NO	YES	1000ms	RW
D1094	Times of Break off detection	NO	YES	3	RW
D1095 ~ D1096	Reserved	-	-		-
D1097	Type of P to P send (PDO) Setting range: 1~240	NO	YES	1	RW
D1098	Type of P to P received (PDO) Setting range: 1~240	NO	YES	1	RW
D1099	Delay time of initialization complete Setting range: 1~60000 sec.	NO	YES	15 sec	RW

Special D	Function	Read(R)/ Write(W)
D1100	Target frequency 1	Read only
D1101	Target frequency 2	Read only
D1102	Reference frequency	Read only
D1103	Reserved	-
D1104	Reserved	-
D1105	Target torque	Read only
D1106	Reserved	-

Special D	Function	Read(R)/ Write(W)
~ D1110		
D1111	Inner COM station cut off (bit0=Machine code0	Read only
D1112	The station which error occurs during inner COM initialization(bit0=Machine code0	Read only
D1113 ~ D1129	Reserved	-
D1130	Inner COM salve 1 control word	Read only
D1131	Inner COM salve 1 mode	Read only
D1132	Inner COM salve 1 reference command L	Read only
D1133	Inner COM salve 1 reference command H	Read only
D1134 ~ D1137	Reserved	-
D1138	Inner COM salve 1 response info L	Read only
D1139	Inner COM salve 1 response info H	Read only
D1140	Inner COM salve 2 control word	Read only
D1141	Inner COM salve 2 mode	Read only
D1142	Inner COM salve 2 reference command L	Read only
D1143	Inner COM salve 2 reference command H	Read only
D1144 ~ D1147	Reserved	-
D1138	Inner COM salve 2 response info L	Read only
D1139	Inner COM salve 2 response info H	Read only
D1140	Inner COM salve 3 control word	Read only
D1141	Inner COM salve 3 mode	Read only
D1142	Inner COM salve 3 reference command L	Read only
D1143	Inner COM salve 3 reference command H	Read only
D1144 ~ D1147	Reserved	-
D1138	Inner COM salve 3 response info L	Read only
D1139	Inner COM salve 3 response info H	Read only
D1140	Inner COM salve 4 control word	Read only
D1141	Inner COM salve 4 mode	Read only
D1142	Inner COM salve 4 reference command L	Read only
D1143	Inner COM salve 4 reference command H	Read only
D1144 ~ D1147	Reserved	-
D1138	Inner COM salve 4 response info L	Read only
D1139	Inner COM salve 4 response info H	Read only
D1170 ~ D1199	Reserved	-

CP2000 supports up to 8 CANopen protocol slaves; each slave occupies 100 of special D register and is numbered in 1~8. There are in total of 8 stations.

Slave No.	Slave No. 1	D2000	Station number
		D2001	Factory code(L)

Slave No. 2	~ D2099	~ Mapping address 4 (H)of receiving station
	D2100	Station number
	D2101	Factory code(L)
Slave No. 3	~ D2199	~ Mapping address 4(H) of receiving station 4
	D2200	Station number
	D2201	Factory code(L)
	~ D2299	~ Mapping address 4(H) of receiving station 4
	↓	
Slave No. 8	D2700	Station number
	D2701	Factory code(L)
	~ D2799	~ Mapping address 4(H)of receiving station 4

Slave No. 0~7

Special D	Function	PDO Map	Save	Pre-defined setting	R/W
D2000+100* n	Station number of slave No. n Setting range: 1~127 0: CANopen disable	NO		0	RW
D2001+100* n	The category of slave No. n 192H: AC motor drive/ AC servo motor and drive 191H: remote I/O module	NO		0	R
D2002+100* n	Factory code (L) of slave No. n	NO		0	R
D2003+100* n	Factory code (H) of slave No. n	NO		0	R
D2004+100* n	Factory product code (L) of slave No. n	NO		0	R
D2005+100* n	Factory product code (H) of slave No. n	NO		0	R

Basic definition

Slave No. 0~7

Special D	Function	PDO Map	Save	Pre-defined setting	CAN Index	PDO				R/W
						1	2	3	4	
D2006+100*n	Treatment for slave No. n communication disconnect	YES		0	6007H-001 0H	•		•	•	RW
D2007+100*n	Error code of slave No. n	YES		0	603FH-001 0H	•		•	•	R

D2008+100*n	Control word of slave No. n	YES		0	6040H-001 0H					RW
D2009+100*n	Status word of slave No. n	YES		0	6041H-001 0H					R
D2010+100*n	Control mode of slave No. n	YES		2	6060H-000 8H					RW
D2011+100*n	Actual mode of slave No. n	YES		2	6061H-000 8H					R

Speed Control

Slave No. 0~7

Special D	Function	PDO Map	Save	Pre-defined Setting	CAN Index	PDO				R/W
						1	2	3	4	
D2012+100*n	Target speed of slave No. n	YES		0	6042H-001 0H	•				RW
D2013+100*n	Actual speed of slave No. n	YES		0	6043H-001 0H	•				R
D2014+100*n	Speed deviation of slave No. n	YES		0	6044H-001 0H					R
D2015+100*n	Accel. Time of slave No. n	YES		1000	604FH-002 0H					R
D2016+100*n	Decel. Time of slave No. n	YES		1000	6050H-002 0H					RW

Torque control

Slave No. 0~7

Special D	Function	PDO Map	Save	Pre-defined Setting	CAN Index	PDO				R/W
						1	2	3	4	
D2017+100*n	Target torque of slave No. n	YES		0	6071H-001 0H				•	RW
D2018+100*n	Actual torque of slave No. n	YES		0	6077H-001 0H				•	R
D2019+100*n	Actual current of slave No. n	YES		0	6078H-001 0H					R

Position control

Slave No. 0~7

Special D	Function	PDO Map	Save	Pre-defined Setting	CAN Index	PDO				R/W
						1	2	3	4	
D2020+100*n	Target position(L) of slave No. n	YES		0	607AH-002					RW
D2021+100*n	Target position(H) of slave No. n	YES		0	0H			•		RW
D2022+100*n	Actual position(L) of slave No. n	YES		0	6064H-002			•		R

D2023+100*n	Actual position(H) of slave No. n	YES		0	0H					R
D2024+100*n	Speed diagram(L) of slave No. n	YES		10000	6081H-002					RW
D2025+100*n	Speed diagram (H) of slave No. n	YES		0	0H					RW

20XXH address corresponds to MI MO AI AO.

Slave No. n=0~7

Special D	Function	PDO Map	Save	Pre-defined Setting	CAN Index	PDO				R/W
						1	2	3	4	
D2026+100*n	MI status of slave No. n	YES		0	2026H-011 0H	•				RW
D2027+100*n	MO setting of slave No. n	YES		0	2026H-411 0H	•				RW
D2028+100*n	AI1 status of slave No. n	YES		0	2026H-611 0H	•				RW
D2029+100*n	AI2 status of slave No. n	YES		0	2026H-621 0H	•				RW
D2030+100*n	AI3 status of slave No. n	YES		0	2026H-631 0H	•				RW
D2031+100*n	AO1 status of slave No. n	YES		0	2026H-A11 0H	•				RW
D2032+100*n	AO2 status of slave No. n	YES		0	2026H-A2 10H	•				RW
D2033+100*n	AO3 status of slave No. n	YES		0	2026H-A3 10H	•				RW

Special D	Function	PDO Map	Save	Pre-defined Setting	R/W
D2034+100*n	Transmission setting of slave No. n	NO	YES	000AH	RW
D2035+100*n	The mapping address 1(L) for slave No. n transmitting station 1	NO	YES	0010H	RW
D2036+100*n	The mapping address 1(H) for slave No.n transmitting station 1	NO	YES	6040H	RW
D2037+100*n	The mapping address 2(L) for slave No. n transmitting station 1	NO	YES	0010H	RW
D2038+100*n	The mapping address 2(H) for slave No.n transmitting station 1	NO	YES	6042H	RW
D2039+100*n	The mapping address 3(L) for slave No. n transmitting station 1	NO	YES	0	RW
D2040+100*n	The mapping address 3(H) for slave No.n transmitting station 1	NO	YES	0	RW
D2041+100*n	The mapping address 4(L) for slave No. n transmitting station 1	NO	YES	0	RW
D2042+100*n	The mapping address 4(H) for slave No.n transmitting station 1	NO	YES	0	RW

Special D	Function	PDO Map	Save	Pre-defined Setting	R/W
D2043+100*n	The mapping address 1(L) for slave No. n transmitting station 2	NO	YES	0110H	RW
D2044+100*n	The mapping address 1(H) for slave No.n transmitting station 2	NO	YES	2026H	RW
D2045+100*n	The mapping address 2(L) for slave No. n transmitting station 2	NO	YES	6110H	RW
D2046+100*n	The mapping address 2(H) for slave No.n transmitting station 2	NO	YES	2026H	RW
D2047+100*n	The mapping address 3(L) for slave No. n transmitting station 2	NO	YES	6210H	RW
D2048+100*n	The mapping address 3(H) for slave No.n transmitting station 2	NO	YES	2026H	RW
D2049+100*n	The mapping address 4(L) for slave No. n transmitting station 2	NO	YES	6310H	RW
D2050+100*n	The mapping address 4(H) for slave No.n transmitting station 2	NO	YES	2026H	RW
D2051+100*n	The mapping address 1(L) for slave No. n transmitting station 3	NO	YES	0010H	RW
D2052+100*n	The mapping address 1(H) for slave No.n transmitting station 3	NO	YES	6040H	RW
D2053+100*n	The mapping address 2(L) for slave No. n transmitting station 3	NO	YES	0020H	RW
D2054+100*n	The mapping address 2(H) for slave No.n transmitting station 3	NO	YES	607AH	RW
D2055+100*n	The mapping address 3(L) for slave No. n transmitting station 3	NO	YES	0	RW
D2056+100*n	The mapping address 3(H) for slave No.n transmitting station 3	NO	YES	0	RW
D2057+100*n	The mapping address 4(L) for slave No. n transmitting station 3	NO	YES	0	RW
D2058+100*n	The mapping address 4(H) for slave No.n transmitting station 3	NO	YES	0	RW
D2059+100*n	The mapping address 1(L) for slave No. n transmitting station 4	NO	YES	0010H	RW
D2060+100*n	The mapping address 1(H) for slave No.n transmitting station 4	NO	YES	6040H	RW
D2061+100*n	The mapping address 2(L) for slave No. n transmitting station 4	NO	YES	0010H	RW
D2062+100*n	The mapping address 2(H) for slave No.n transmitting station 4	NO	YES	6071H	RW
D2063+100*n	The mapping address 3(L) for slave No. n transmitting station 4	NO	YES	0	RW
D2064+100*n	The mapping address 3(H) for slave No.n transmitting station 4	NO	YES	0	RW
D2065+100*n	The mapping address 4(L) for slave No. n transmitting station 4	NO	YES	0	RW
D2066+100*n	The mapping address 4(H) for slave No.n transmitting station 4	NO	YES	0	RW
D2067+100*n	Receiving setting of slave No. n	NO	YES	0000H	RW

Special D	Function	PDO Map	Save	Pre-defined Setting	R/W
D2068+100*n	The mapping address 1(L) for slave No. n receiving station 1	NO	YES	0010H	RW
D2069+100*n	The mapping address 1(H) for slave No.n receiving station 1	NO	YES	6041H	RW
D2070+100*n	The mapping address 2(L) for slave No. n receiving station 1	NO	YES	0010H	RW
D2071+100*n	The mapping address 2(H) for slave No.n receiving station 1	NO	YES	6043H	RW
D2072+100*n	The mapping address 3(L) for slave No. n receiving station 1	NO	YES	0	RW
D2073+100*n	The mapping address 3(H) for slave No.n receiving station 1	NO	YES	0	RW
D2074+100*n	The mapping address 4(L) for slave No. n receiving station 1	NO	YES	0	RW
D2075+100*n	The mapping address 4(H) for slave No.n receiving station 1	NO	YES	0	RW
D2076+100*n	The mapping address 1(L) for slave No. n receiving station 2	NO	YES	4110H	RW
D2077+100*n	The mapping address 1(H) for slave No.n receiving station 2	NO	YES	2026H	RW
D2078+100*n	The mapping address 2(L) for slave No. n receiving station 2	NO	YES	A110H	RW
D2079+100*n	The mapping address 2(H) for slave No.n receiving station 2	NO	YES	2026H	RW
D2080+100*n	The mapping address 3(L) for slave No. n receiving station 2	NO	YES	A210H	RW
D2081+100*n	The mapping address 3(H) for slave No.n receiving station 2	NO	YES	2026H	RW
D2082+100*n	The mapping address 4(L) for slave No. n receiving station 2	NO	YES	A310H	RW
D2083+100*n	The mapping address 4(H) for slave No.n receiving station 2	NO	YES	2026H	RW
D2084+100*n	The mapping address 1(L) for slave No. n receiving station 3	NO	YES	0010H	RW
D2085+100*n	The mapping address 1(H) for slave No.n receiving station 3	NO	YES	6041H	RW
D2086+100*n	The mapping address 2(L) for slave No. n receiving station 3	NO	YES	0020H	RW
D2087+100*n	The mapping address 2(H) for slave No.n receiving station 3	NO	YES	6064H	RW
D2088+100*n	The mapping address 3(L) for slave No. n receiving station 3	NO	YES	0	RW
D2089+100*n	The mapping address 3(H) for slave No.n receiving station 3	NO	YES	0	RW
D2090+100*n	The mapping address 4(L) for slave No. n receiving station 3	NO	YES	0	RW
D2091+100*n	The mapping address 4(H) for slave No.n receiving station 3	NO	YES	0	RW
D2092+100*n	The mapping address 1(L) for slave No. n receiving station 4	NO	YES	0010H	RW

Special D	Function	PDO Map	Save	Pre-defined Setting	R/W
D2093+100*n	The mapping address 1(H) for slave No.n receiving station 4	NO	YES	6041H	RW
D2094+100*n	The mapping address 2(L) for slave No. n receiving station 4	NO	YES	0010H	RW
D2095+100*n	The mapping address 2(H) for slave No.n receiving station 4	NO	YES	6077H	RW
D2096+100*n	The mapping address 3(L) for slave No. n receiving station 4	NO	YES	0	RW
D2097+100*n	The mapping address 3(H) for slave No.n receiving station 4	NO	YES	0	RW
D2098+100*n	The mapping address 4(L) for slave No. n receiving station 4	NO	YES	0	RW
D2099+100*n	The mapping address 4(H) for slave No.n receiving station 4	NO	YES	0	RW

17.4.4 Communication Address for PLC Devices

Device	Range	Type	Address (Hex)
X	00~17 (Octal)	bit	0400~040F
Y	00~17 (Octal)	bit	0500~050F
T	00~159	bit/word	0600~069F
M	000~799	bit	0800~0B1F
M	1000~1079	bit	0BE8~0C37
C	0~79	bit/word	0E00~0E47
D	00~399	word	1000~118F
D	1000~1099	word	13E8~144B
D	2000~2799	word	17D0~1AEF

Function Code

Function Code	Description	Supported Devices
01	Read coil status	Y, M, T, C
02	Read input status	X, Y, M, T, C
03	Read one data	T, C, D
05	Force changing one coil status	Y, M, T, C
06	Write in one data	T, C, D
0F	Force changing multiple coil status	Y, M, T, C
10	Write in multiple data	T, C, D

Only when PLC is at Stop status, PLC data can be read/write via communication device. When PLC

is at Run status, the communication address should be the mapping address, e.g. for Pr.04-00 it maps to 0400H.



When PLC function is activated, CP2000 can Read/Write the PLC and drive's parameter by different addresses (pre-defined station number for the AC motor drive is 1, for PLC station number is 2)

17.5 Commands

17.5.1 Basic Commands

Commands

Commands	Function	Operands
LD	Load contact A	X, Y, M, T, C
LDI	Load contact B	X, Y, M, T, C
AND	Series connection with A contact	X, Y, M, T, C
ANI	Series connection with B contact	X, Y, M, T, C
OR	Parallel connection with A contact	X, Y, M, T, C
ORI	Parallel connection with B contact	X, Y, M, T, C
ANB	Series connects the circuit block	--
ORB	Parallel connects the circuit block	--
MPS	Save the operation result	--
MRD	Read the operation result (the pointer is not moving)	--
MPP	Read the result	--

Output Command

Commands	Function	Operands
OUT	Drive coil	Y, M
SET	Action latched (ON)	Y, M
RST	Clear the contacts or the registers	Y, M, T, C, D

Timer and Counter

Commands	Function	Operands
TMR	16-bit timer	T-K or T-D
CNT	16-bit counter	C-K or C-D (16 bit)

Main Control Command

Commands	Function	Operands
MC	Connect the common series connection contacts	N0~N7
MCR	Disconnect the common series connection contacts	N0~N7

Rising-edge/falling-edge Detection Commands of Contact

Commands	Function	Operands
LDP	Rising-edge detection operation starts	X, Y, M, T, C
LDF	Falling-edge detection operation starts	X, Y, M, T, C
ANDP	Rising-edge detection series connection	X, Y, M, T, C
ANDF	Falling-edge detection series connection	X, Y, M, T, C
ORP	Rising-edge detection parallel connection	X, Y, M, T, C
ORF	Falling-edge detection parallel connection	X, Y, M, T, C

Rising-edge/falling-edge Output Commands

Commands	Function	Operands
PLS	Rising-edge output	Y, M
PLF	Falling-edge output	Y, M

End Command

Commands	Function	Operands
END	Program end	--

Other Command

Commands	Function	Operands
NOP	No function	--
INV	Inverse operation result	--
P	Indicator	P

17.5.2 Explanation for the Command


Mnemonic	Function					
LD	Load A contact					
Operand	X0~X17	Y0~Y17	M0~M799	T0~159	C0~C79	D0~D399
	✓	✓	✓	✓	✓	—

L The LD command is used on the A contact that has its start from the left BUS or the A contact that is the start of a contact circuit. Function of the command is to save present contents, and at the same time, save the acquired contact status into the accumulative register.

Explanation

Example

Ladder diagram



Command code Operation

LD	X0	Load contact A of X0
AND	X1	Connect to contact A of X1 in series
OUT	Y1	Drive Y1 coil

Mnemonic	Function					
LDI	Load B contact					
Operand	X0~X17	Y0~Y17	M0~M799	T0~159	C0~C79	D0~D399
	✓	✓	✓	✓	✓	—

The LDI command is used on the B contact that has its start from the left BUS or the B contact that is the start of a contact circuit. Function of the command is to save present contents, and at the same time, save the acquired contact status into the accumulative register.

Explanation

Example

Ladder diagram:



Command code: Operation:

LDI	X0	Load contact B of X0
AND	X1	Connect to contact A of X1 in series
OUT	Y1	Drive Y1 coil

Mnemonic	Function					
AND	Series connection- A contact					
Operand	X0~X17	Y0~Y17	M0~M799	T0~159	C0~C79	D0~D399
	✓	✓	✓	✓	✓	—

The AND command is used in the series connection of A contact. The function of the command is to readout the status of present specific series connection contacts first, and then to perform the “AND” calculation with the logic calculation result before the contacts, thereafter, saving the result into the accumulative register.

Explanation

Example

Ladder diagram:



Command code: Operation:

LDI	X1	Load contact B of X1
AND	X0	Connect to contact A of X0 in series
OUT	Y1	Drive Y1 coil

Mnemonic	Function					
ANI	Series connection- B contact					
Operand	X0~X17	Y0~Y17	M0~M799	T0~159	C0~C79	D0~D399
	✓	✓	✓	✓	✓	—

The ANI command is used in the series connection of B contact. The function of the command is to readout the status of present specific series connection contacts first, and then to perform the “AND” calculation with the logic calculation result before the contacts, thereafter, saving the result into the accumulative register.

Explanation

Example

Ladder diagram:



Command code: Operation:


LD	X1	Load contact A of X1
ANI	X0	Connect to contact B of X0 in series
OUT	Y1	Drive Y1 coil

Mnemonic	Function					
OR	Parallel connection- A contact					
Operand	X0~X17	Y0~Y17	M0~M799	T0~159	C0~C79	D0~D399
	✓	✓	✓	✓	✓	—

The OR command is used in the parallel connection of A contact. The function of the command is to readout the status of present specific series connection contacts, and then to perform the “OR” calculations with the logic calculation result before the contacts, thereafter, saving the result into the accumulative register.

Explanation

Ladder diagram:



Command code: Operation:

LD	X0	Load contact A of X0
OR	X1	Connect to contact A of X1 in parallel
OUT	Y1	Drive Y1 coil


Mnemonic	Function					
ORI	Parallel connection- B contact					
Operand	X0~X17	Y0~Y17	M0~M799	T0~159	C0~C79	D0~D399
	✓	✓	✓	✓	✓	—

The ORI command is used in the parallel connection of B contact. The function of the command is to readout the status of present specific series connection contacts, and then to perform the “OR” calculations with the logic calculation result before the contacts, thereafter, saving the result into the accumulative register.

Explanation

Example

Ladder diagram:



Command code: Operation:

LD	X0	Load contact A of X0
ORI	X1	Connect to contact B of X1 in parallel
OUT	Y1	Drive Y1 coil


Mnemonic	Function
ANB	Series connection (Multiple Circuits)
Operand	None

Explanation

To perform the “ANB” calculation between the previous reserved logic results and contents of the accumulative register.

Example

Ladder diagram:



Command code: Operation:

LD	X0	Load contact A of X0
ORI	X2	Connect to contact B of X2 in parallel
LDI	X1	Load contact B of X1
OR	X3	Connect to contact A of X3 in parallel
ANB		Connect circuit block in series
OUT	Y1	Drive Y1 coil


Mnemonic	Function
ORB	Parallel connection (Multiple circuits)
Operand	None

Explanation

ORB is to perform the “OR” calculation between the previous reserved logic results and contents of the accumulative register.

Example

Ladder diagram:



Command code:	Operation:
LD X0	Load contact A of X0
ANI X1	Connect to contact B of X1 in series
LDI X2	Load contact B of X2
AND X3	Connect to contact A of X3 in series
ORB	Connect circuit block in parallel
OUT Y1	Drive Y1 coil

Mnemonic	Function
MPS	Store the current result of the internal PLC operations
Operand	None

Explanation

To save contents of the accumulative register into the operation result. (the result operation pointer pluses 1)

Mnemonic	Function
MRD	Reads the current result of the internal PLC operations
Operand	None

Explanation

Reading content of the operation result to the accumulative register. (the pointer of operation result doesn't move)


Mnemonic	Function
MPP	Reads the current result of the internal PLC operations
Operand	None

Explanation

Reading content of the operation result to the accumulative register. (the stack pointer will decrease 1)

Example

Ladder diagram:



Command code:	Operation:
LD X0	Load contact A of X0
MPS	Save in stack
AND X1	Connect to contact A of X1 in series
OUT Y1	Drive Y1 coil
MRD	Read from the stack (without moving pointer)
AND X2	Connect to contact A of X2 in series
OUT M0	Drive M0 coil
MPP	Read from the stack
OUT Y2	Drive Y2 coil
END	End program

Mnemonic	Function					
OUT	Output coil					
Operand	X0~X17	Y0~Y17	M0~M799	T0~159	C0~C79	D0~D399
	—	✓	✓	—	—	—

Explanation

Output the logic calculation result before the OUT command to specific device.

Motion of coil contact:

Operation result	OUT command		
	Coil	Contact	
		A contact (normally open)	B contact (normally closed)
FALSE	Off	Non-continuity	Continuity
TRUE	On	Continuity	Non-continuity

Example

Ladder diagram:



Command code: Operation:

LD	X0	Load contact B of X0
AND	X1	Connect to contact A of X1 in series
OUT	Y1	Drive Y1 coil

Mnemonic	Function					
SET	Latch (ON)					
Operand	X0~X17	Y0~Y17	M0~M799	T0~159	C0~C79	D0~D399
	—	✓	✓	—	—	—

Explanation

When the SET command is driven, its specific device is set to be “ON,” which will keep “ON” whether the SET command is still driven. You can use the RST command to set the device to “OFF”.

Example

Ladder diagram:



Command code: Operation:

LD	X0	Load contact A of X0
AN	Y0	Connect to contact B of Y0 in series
SET	Y1	Y1 latch (ON)

Mnemonic	Function					
RST	Clear the contacts or the registers					
Operand	X0~X17	Y0~Y17	M0~M799	T0~159	C0~C79	D0~D399
	—	✓	✓	✓	✓	✓


Explanation

When the RST command is driven, motion of its specific device is as follows:

Device	Status
Y, M	Coil and contact will be set to “OFF”.
T, C	Present values of the timer or counter will be set to 0, and the coil and contact will be set to “OFF.”
D	The content value will be set to 0.

When the RST command is not driven, motion of its specific device is unchanged.

Example



Command code:	Operation:
LD X0	Load contact A of X0
RST Y5	Clear contact Y5

Mnemonic	Function
TMR	16-bit timer
Operand	T-K T0~T159, K0~K32,767
	T-D T0~T159, D0~D399


Explanation

When TMR command is executed, the specific coil of timer is ON and timer will start to count. When the setting value of timer is attained (counting value >= setting value), the contact will be as following

NO(Normally Open) contact	Open collector
NC(Normally Closed) contact	Close collector

When the RST command is not driven, motion of its specific device remains unchanged.

Example



Command code:	Operation:
LD X0	Load contact A of X0
TMR T5 K1000	Setting of T5 counter is K1000.

Mnemonic	Function
CNT	Clear contact or register
Operand	C-K C0~C79, K0~K32,767
	C-D C0~C79, D0~D399


Explanation

When the CNT command is executed from OFF→ON, which means that the counter coil is driven, and 1 should thus be added to the counter's value; when the counter achieved specific set value (value of counter = the setting value), motion of the contact is as follows:

NO(Normally Open) contact	Open collector
NC(Normally Close) contact	Close collector

If there is counting pulse input after counting is attained, the contacts and the counting values will be unchanged. To re-count or to conduct the CLEAR motion, please use the RST command.

Example



Command code:	Operation
LD X0	Load contact A of
CNT C2 K100	Setting of C2 counter is K100.

Mnemonic	Function
MC/MCR	Master control Start/Reset
Operand	N0~N7

Explanation

1. MC is the main-control start command. When the MC command is executed, the execution of commands between MC and MCR will not be interrupted. When MC command is OFF, the motion of the commands that between MC and MCR is described as follows:


Command	Description
Timer	The counting value is set back to zero, the coil and the contact are both turned OFF
Accumulative timer	The coil is OFF, and the timer value and the contact stay at their present condition
Subroutine timer	The counting value is back to zero. Both coil and contact are turned OFF.
Counter	The coil is OFF, and the counting value and the contact stay at their present condition
Coils driven up by the OUT command	All turned OFF
Devices driven up by the SET and RST commands	Stay at present condition
Application commands	All of them are not acted , but the nest loop FOR-NEXT command will still be executed for times defined by users even though the MC-MCR commands is OFF.

2. MCR is the main-control ending command that is placed at the end of the main-control program and there should not be any contact commands prior to the MCR command.

3. Commands of the MC-MCR main-control program support the nest program structure, with 8 layers as its greatest. Please use the commands in order from N0~N7, and refer to the following:

Example

Ladder Diagram:




Command code:	Operation:
LD X0	Load A contact of X0
MC N0	Enable N0 common series connection contact
LD X1	Load A contact of X1
OUT Y0	Drive Y0 coil
:	
LD X2	Load A contact of X2
MC N1	Enable N1 common series connection contact
LD X3	Load A contact of X3
OUT Y1	Drive Y1 coil
:	
MCR N1	Disable N1 common series connection contact

MCR	N0	Disable N0 common series connection contact	
LD	X10	Load A contact of X10	
MC	N0	Enable N0 common series connection contact	
LD	X11	Load A contact of X0	
OUT	Y10	Enable N0 common series connection contact	
		Load A contact of X1	
MCR	N0	Drive Y0 coil	

Mnemonic	Function					
LDP	Rising-edge detection operation					
Operand	X0~X17	Y0~Y17	M0~M799	T0~159	C0~C79	D0~D399
	✓	✓	✓	✓	✓	—

Explanation Usage of the LDP command is the same as the LD command, but the motion is different. It is used to reserve present contents and at the same time, saving the detection status of the acquired contact rising-edge into the accumulative register.




Command code: Operation:

LDP	X0	Start X0 rising-edge detection
AND	X1	Series connection A contact of X1
OUT	Y1	Drive Y1 coil

Remarks Please refer to the specification of each model series for the applicable range of operands.
If rising-edge status is ON when PLC power is off, then the rising-edge status will be TRUE when PLC power is on.

Mnemonic	Function					
LDF	Falling-edge detection operation					
Operand	X0~X17	Y0~Y17	M0~M799	T0~159	C0~C79	D0~D399
	✓	✓	✓	✓	✓	—

Explanation Usage of the LDF command is the same as the LD command, but the motion is different. It is used to reserve present contents and at the same time, saving the detection status of the acquired contact falling-edge into the accumulative register.



Command code: Operation:


LDF	X0	Start X0 falling-edge detection
AND	X1	Series connection A contact of X1
OUT	Y1	Drive Y1 coil

Mnemonic	Function					
ANDP	Rising-edge series connection					
Operand	X0~X17	Y0~Y17	M0~M799	T0~159	C0~C79	D0~D399
	✓	✓	✓	✓	✓	—

Explanation ANDP command is used in the series connection of the contacts' rising-edge detection.

Ladder diagram:

Example



Command code:

Operation:


LD	X0	Load A contact of X0
ANDP	X1	X1 rising-edge detection in series connection
OUT	Y1	Drive Y1 coil

Mnemonic	Function					
ANDF	Falling-edge series connection					
Operand	X0~X17	Y0~Y17	M0~M799	T0~159	C0~C79	D0~D399
	✓	✓	✓	✓	✓	—

Explanation ANDF command is used in the series connection of the contacts' falling-edge detection.

Ladder diagram:

Example



Command code:

Operation:

LD	X0	Load A contact of X0
ANDF	X1	X1 falling-edge detection in series connection
OUT	Y1	Drive Y1 coil


Mnemonic	Function					
ORP	Rising-edge parallel connection					
Operand	X0~X17	Y0~Y17	M0~M799	T0~159	C0~C79	D0~D399
	✓	✓	✓	✓	✓	—

The ORP commands are used in the parallel connection of the contact's rising-edge detection.

Explanation

Ladder diagram:

Example



Command code:

Operation:


LD	X0	Load A contact of X0
ORP	X1	X1 rising-edge detection in parallel connection
OUT	Y1	Drive Y1 coil

Mnemonic	Function					
ORF	Falling-edge parallel connection					
Operand	X0~X17	Y0~Y17	M0~M799	T0~159	C0~C79	D0~D399
	✓	✓	✓	✓	✓	—

Explanation

The ORF commands are used in the parallel connection of the contact's falling-edge detection.

Ladder diagram:

Example

Command code: Operation:


LD	X0	Load A contact of X0
ORF	X1	X1 falling-edge detection in parallel connection
OUT	Y1	Drive Y1 coil

Mnemonic	Function					
PLS	Rising-edge output					
Operand	X0~X17	Y0~Y17	M0~M799	T0~159	C0~C79	D0~D399
	—	✓	✓	—	—	—

Explanation

When X0=OFF→ON (rising-edge trigger), PLS command will be executed and M0 will send the pulse of one time which the length is the time needed for one scan cycle.


Ladder diagram:

Example

Command code: Operation:

LD	X0	Load A contact of X0
PLS	M0	M0 rising-edge output
LD	M0	Load the contact A of M0
SET	Y0	Y0 latched (ON)

Timing diagram:




Mnemonic	Function					
PLF	Falling-edge output					
Operand	X0~X17	Y0~Y17	M0~M799	T0~159	C0~C79	D0~D399
	—	✓	✓	—	—	—

Explanation

When X0= ON→OFF (falling-edge trigger), PLF command will be executed and M0 will send the pulse of one time which the length is the time for scan one time.


Ladder diagram:

Example

Command code: Operation:

LD	X0	Load contact A of X0
PLF	M0	M0 falling-edge output
LD	M0	Load contact A of M0
SET	Y0	Y0 latched (ON)

Timing Diagram:



Mnemonic	Function
END	Program End
Operand	None

Explanation

It needs to add the END command at the end of ladder diagram program or command program. PLC will scan from address 0 to END command, after the execution it will return to address 0 and scan again.

Mnemonic	Function
NOP	No action
Operand	None


Explanation

NOP command does no operation in the program; the result of executing this command will remain the logic operation. Use NOP command if user wants to delete certain command without changing the length of the program.

Example

Ladder diagram:

NOP command will be simplified and not displayed when the ladder diagram is displayed.



Command code: Operation:

LD	X0	Load contact B of X0
NOP		No function
OUT	Y1	Drive Y1 coil

Mnemonic	Function
INV	Inverse operation result
Operand	None

Explanation

The operation result (before executing INV command) will be saved inversely into cumulative register.

Example

Ladder diagram:



Command code: Operation:

LD	X0	Load contact A of X0
INV		Operation result inverted
OUT	Y1	Drive Y1 coil


Mnemonic	Function
P	Indicator
Operand	P0~P255

Explanation

Indicator P allows API 00 CJ command and API 01 CALL command to skip from 0. Though it is not necessary to start from number 0, same number can not be used twice or serious error would occur.

Example

Ladder diagram:



Command code:	Operation:
LD X0	Load contact A of X0
CJ P10	Skip command CJ to P10
:	
P10	Indicator P10
LD X1	Load contact A of X1
OUT Y1	Drive Y1 coil

17.5.3 Description of the Application Commands

	API	Mnemonic Codes		P Command	Function	STEPS	
		16-bit	32-bit			16bit	32bit
Loop control	01	CALL	-	✓	CALL subroutine	3	-
	06	FEND	-	-	The end of main program	1	-
Transmission Comparison	10	CMP	-	✓	Compare	7	13
	11	ZCP	-	✓	Zone compare	9	17
	12	MOV	-	✓	Data Move	5	9
	15	BMOV	-	✓	Block move	7	-
Four Fundamental Operations of Arithmetic	20	ADD	-	✓	Perform the addition of BIN data	7	13
	21	SUB	-	✓	Perform the subtraction of BIN data	7	13
	22	MUL	-	✓	Perform the multiplication of BIN data	7	13
	23	DIV	-	✓	Perform the division of BIN data	7	13
	24	INC	-	✓	Perform the addition of 1	3	5
	25	DEC	-	✓	Perform the subtraction of 1	3	5
Rotation and Displacement	30	ROR	-	✓	Rotate to the right	5	-
	31	ROL	-	✓	Rotate to the left	5	-
Data Processing	40	ZRST	-	✓	Zero Reset	5	-
Contact type logic operation	215	LD&	DLD&	-	Contact Logical Operation LD#	5	9
	216	LD	DLD	-	Contact type logic operation LD #	5	9
	217	LD^	DLD^	-	Contact Logical Operation LD#	5	9
	218	AND&	DAND&	-	Contact Logical Operation AND#	5	9
	219	ANDI	DANDI	-	Contact Logical Operation AND#	5	9
	220	AND^	DAND^	-	Contact Logical Operation AND#	5	9
	221	OR&	DOR&	-	Contact Logical Operation OR #	5	9
	222	OR	DOR	-	Contact Logical Operation OR #	5	9


	223	OR [^]	DOR [^]	-	Contact Logical Operation OR #	5	9
Contact Type Comparison	224	LD=	DLD=	-	Load Compare LD※	5	9
	225	LD>	DLD>	-	Load Compare LD※	5	9
	226	LD<	DLD<	-	Load Compare LD※	5	9
	228	LD<>	DLD<>	-	Load Compare LD※	5	9
	229	LD<=	DLD<=	-	Load Compare LD※	5	9
	230	LD>=	DLD>=	-	Load Compare LD※	5	9
	232	AND=	DAND=	-	AND Compare※	5	9
	233	AND>	DAND>	-	AND Compare※	5	9
	234	AND<	DAND<	-	AND Compare※	5	9
	236	AND<>	DAND<>	-	AND Compare※	5	9
	237	AND<=	DAND<=	-	AND Compare※	5	9
	238	AND>=	DAND>=	-	AND Compare※	5	9
	240	OR=	DOR=	-	OR compare ※	5	9
	241	OR>	DOR>	-	OR compare ※	5	9
	242	OR<	DOR<	-	OR compare ※	5	9
244	OR<>	DOR<>	-	OR compare ※	5	9	
245	OR<=	DOR<=	-	OR compare ※	5	9	
246	OR>=	DOR>=	-	OR compare ※	5	9	
Special command for AC motor drive	139	RPR	-	✓	Read the parameters	5	-
	140	WPR	-	✓	Write the parameters	5	-
	141	FPID	-	✓	Drive PID control	9	-
	142	FREQ	-	✓	Control the drive frequency	7	-
	261	CANRX	-	✓	Read CANopen Slave data	9	-
	263	TORQ	-	✓	Set target torque	5	-
	264	CANTX	-	✓	Write CANopen Slave data	9	-
	265	CANFLS	-	✓	Update the mapping special D of CANopen	3	-

Example


3

To avoid coincidence of the device numbers to be moved designated by the two operands and cause confusion, please be aware of the arrangement on the designated device numbers.

When $S > D$, the BMOV command is processed in the order as ①→②→③



When $S < D$, the BMOV command is processed in the order as ③→②→①



API											
20	D	ADD	P	(S1)	(S2)	(D)	BIN Addition				

	Bit Devices			Word devices								16-bit command (7 STEPS)	
	X	Y	M	K	H	KnX	KnY	KnM	T	C	D	ADD	ADDP
S ₁				*	*	*	*	*	*	*	*		
S ₂				*	*	*	*	*	*	*	*		
D							*	*	*	*	*		

Operands: None

Flag signal: M1020 Zero flag
M1021 Borrow flag
M1022 Carry flag

Explanation

1. S₁: Summand S₂: Addend D: Sum
2. This instruction adds S₁ and S₂ in BIN format and store the result in D.
3. The highest bit is symbolic bit 0 (+) and 1 (-), which is suitable for algebraic addition, e.g. 3 + (-9) = -6.
4. Flag changes in binary addition
 - 16-bit command:
 - A. If the operation result = 0, zero flag M1020 = On.
 - B. If the operation result < -32,768, borrow flag M1021 = On.
 - C. If the operation result > 32,767, carry flag M1022 = On.

Example

16-bit command:

When X0 = On, the content in D0 will plus the content in D10 and the sum will be stored in D20.



API												
215~ 217	D	LD#		(S1)	(S2)							Contact Logical Operation LD#

	Bit Devices			Word devices								16-bit command (5 STEPS)	
	X	Y	M	K	H	KnX	KnY	KnM	T	C	D	LD#	ZRSTP
S ₁				*	*	*	*	*	*	*	*		
S ₂				*	*	*	*	*	*	*	*		
Operands: #: &, , ^												32-bit command (9 STEPS)	
Please refer to the specifications of each model for the range of operands.												DLD#	
												Flag signal: none	

Explanation


1. S₁: Data source device 1 S₂: Data source device 2
2. This instruction compares the content in S₁ and S₂. If the result is not "0", the continuity of the instruction is enabled. If the result is "0", the continuity of the instruction is disabled.
3. LD# (#: &, |, ^) instruction is used for direct connection with BUS.

API No.	16-bit instruction	32-bit instruction	Continuity condition	No-continuity condition
215	LD&	DLD&	S ₁ & S ₂ ≠ 0	S ₁ & S ₂ = 0
216	LD	DLD	S ₁ S ₂ ≠ 0	S ₁ S ₂ = 0
217	LD^	DLD^	S ₁ ^ S ₂ ≠ 0	S ₁ ^ S ₂ = 0

4. &: Logical "AND" operation
5. |: Logical "OR" operation
6. ^: Logical "XOR" operation

Example

1. When the result of logical AND operation of C0 and C10 ≠ 0, Y10 = On.
2. When the result of logical OR operation of D200 and D300 ≠ 0 and X1 = On, Y11 = On will be retained.



API											
218~220	D	AND#		(S1)	(S2)						Contact Logical Operation AND#

	Bit Devices			Word devices							16-bit command (5 STEPS)		
	X	Y	M	K	H	KnX	KnY	KnM	T	C	D	AND#	ZRSTP
S ₁				*	*	*	*	*	*	*	*		
S ₂				*	*	*	*	*	*	*	*		
Operands: #: &, , ^												32-bit command (9 STEPS)	
Please refer to the specifications of each model for the range of operands.												DAND# - - -	
												Flag signal: none	

Explanation


1. S₁: Data source device 1 S₂: Data source device 2
2. This instruction compares the content in S₁ and S₂. If the result is not “0”, the continuity of the instruction is enabled. If the result is “0”, the continuity of the instruction is disabled.
3. AND# (#: &, |, ^) is an operation instruction used on series contacts.

API No.	16-bit instruction	32-bit instruction	Continuity condition	No-continuity condition
218	AND&	DAND&	S ₁ & S ₂ ≠ 0	S ₁ & S ₂ = 0
219	AND	DAND	S ₁ S ₂ ≠ 0	S ₁ S ₂ = 0
220	AND^	DAND^	S ₁ ^ S ₂ ≠ 0	S ₁ ^ S ₂ = 0

4. &: Logical “AND” operation
5. |: Logical “OR” operation
6. ^: Logical “XOR” operation

Example

1. When X0 = On and the result of logical AND operation of C0 and C10 ≠ 0, Y10 = On.
2. When X1 = Off and the result of logical OR operation of D10 and D0 ≠ 0 and X1 = On, Y11 = On will be retained.
3. When X2 = On and the result of logical XOR operation of 32-bit register D200 (D201) and 32-bit register D100 (D101) ≠ 0 or M3 = On, M50 = On.



API											
224~230	D	LD※		(S1)	(S2)						Load Compare※

Bit Devices			Word devices								16-bit command (5 STEPS)		
	X	Y	M	K	H	KnX	KnY	KnM	T	C	D	LD※	ZRSTP
S ₁				*	*	*	*	*	*	*	*		
S ₂				*	*	*	*	*	*	*	*		
Operands: ※: =, >, <, <>, ≤, ≥												32 位 bits command (9 STEPS)	
Please refer to the specifications of each model for the range of operands.												DLD※ - - -	
												Flag signal: none	


Explanation

1. S₁: Data source device 1 S₂: Data source device 2
2. This instruction compares the content in S₁ and S₂. Take API224 (LD=) for example, if the result is "=", the continuity of the instruction is enabled. If the result is "≠", the continuity of the instruction is disabled.
3. LD※ (※: =, >, <, <>, ≤, ≥) instruction is used for direct connection with BUS.

API No.	16-bit instruction	32-bit instruction	Continuity condition	No-continuity condition
224	LD=	DLD=	S ₁ = S ₂	S ₁ ≠ S ₂
225	LD>	DLD>	S ₁ > S ₂	S ₁ ≤ S ₂
226	LD<	DLD<	S ₁ < S ₂	S ₁ ≥ S ₂
228	LD<>	DLD<>	S ₁ ≠ S ₂	S ₁ = S ₂
229	LD≤	DLD≤	S ₁ ≤ S ₂	S ₁ > S ₂
230	LD≥	DLD≥	S ₁ ≥ S ₂	S ₁ < S ₂

Example

1. When the content in C10 = K200, Y10 = On.
2. When the content in D200 > K-30 and X1 = On, Y11= On will be retained.



API											
240~ 246	D	OR※		(S1)	(S2)						OR Compare※

	Bit Devices			Word devices							16-bit command (5 STEPS)		
	X	Y	M	K	H	KnX	KnY	KnM	T	C	D	OR※	ZRSTP
S ₁				*	*	*	*	*	*	*	*		
S ₂				*	*	*	*	*	*	*	*		
Operands: ※: =, >, <, <>, ≤, ≥												32-bit command (9 STEPS)	
Please refer to the specifications of each model for the range of operands.												DOR※	
												Flag signal: none	


Explanation

1. S₁: Data source device 1 S₂: Data source device 2
2. This instruction compares the content in S₁ and S₂. Take API240 (OR=) for example, if the result is "=", the continuity of the instruction is enabled. If the result is "≠", the continuity of the instruction is disabled.
3. OR※ (※: =, >, <, <>, ≤, ≥) is an comparison instruction used on parallel contacts.

API No.	16-bit instruction	32-bit instruction	Continuity condition	No-continuity condition
232	AND=	DAND=	S ₁ = S ₂	S ₁ ≠ S ₂
233	AND>	DAND>	S ₁ > S ₂	S ₁ ≤ S ₂
234	AND<	DAND<	S ₁ < S ₂	S ₁ ≥ S ₂
236	AND<>	DAND<>	S ₁ ≠ S ₂	S ₁ = S ₂
237	AND≤	DAND≤	S ₁ ≤ S ₂	S ₁ > S ₂
238	AND≥	DAND≥	S ₁ ≥ S ₂	S ₁ < S ₂

Example

1. When X1 = On and the present value of C10 = K200, Y0 = On.
2. When X1 = Off and the content in D0 ≠ K-10, Y11= On will be retained.
3. M50 will be On when X2=On and the content of 32-bit register D0(D11) <678,493 or M3= On.



API						(S1) (S2) (S3) (S) (D)						Time Compare
160		TCMP		P								

	Bit Devices			Word Devices							
	X	Y	S	K	H	KnX	KnY	KnM	T	C	D
S₁				*	*	*	*	*	*	*	*
S₂				*	*	*	*	*	*	*	*
S₃				*	*	*	*	*	*	*	*
S									*	*	*
D		*	*								

Operands: **S₁**, **S₂**, **S₃**; Range: **S₁**=K0~K23, **S₂**=**S₃**=K0~K59
 S will occupy 3 consecutive devices;
 D will occupy 3 consecutive points

Please refer to the specifications of each model for the range of operands

16-bit command (11 STEP)

TCMP TCMP
P

32-bit command

— — — —

Flag signal: None

Explanation	<ol style="list-style-type: none"> S₁: "Hour" for comparison (K0~K23). S₂: "Minute" for comparison (K0~K59). S₃: "Second" for comparison (K0~K59). S: current time of RTC. D: Comparison result. S₁, S₂ and S₃ are compared with the present values of "hour", "minute" and "second" starting from S. The comparison result is stored in D. S is the "hour" of the current time (K0 ~ K23) in RTC; S + 1 is the "minute" (K0 ~ K59) and S + 2 is the "second" (K0 ~ K59). S is read by TRD instruction and the comparison is started by TCMP instruction. If S exceeds the range, the program will regard this as an operation error and the instruction will not be executed, M1068 = On
-------------	---

Example	<ol style="list-style-type: none"> When X10= On, the instruction will compare the current time in RTC (D20 ~ D22) with the set value 12:20:45 and display the result in M10 ~ M12. When X10 goes from On to Off, the instruction will not be executed, but the On/Off status prior to M10 ~ M12 will remain. Connect M10 ~ M12 in series or in parallel to obtain the result of \geq, \leq, and \neq.
---------	--

M10	ON when 12:20:45 >	D20 hour
		D21 minute
		D22 second
M11	ON when 12:20:45 =	D20 hour
		D21 minute
		D22 second
M12	ON when 12:20:45 <	D20 hour
		D21 minute
		D22 second


API	TZCP											(S1) (S2) (S) (D)	Time Zone Compare	
161	P													
	Bit Devices			Word Devices									16-bit command (9 STEP)	
	X	Y	M	K	H	KnX	KnY	KnM	T	C	D	TZCP	TZCPP	
	S ₁								*	*	*			
	S ₂								*	*	*			
	S								*	*	*			
D		*	*									32-bit command		
Operands: S₁ , S₂ , S will occupy 3 consecutive devices. The content in S₁ must be less than the content in S₂ . D will occupy 3 consecutive points.													Flag signal: None	
Please refer to the specifications of each model for the range of operands														

Explanation

1. **S₁**: Lower bound of the time for comparison; **S₂**: Upper bound of the time for comparison **S**: Current time of RTC; **D**: Comparison result
2. **S** is compared with **S₁** and **S₂**. The comparison result is stored in **D**.
3. **S₁**, **S₁ + 1**, **S₁ + 2**: The “hour”, “minute” and “second” of the lower bound of the time for comparison.
4. **S**, **S + 1**, **S + 2**: The “hour”, “minute” and “second” of the current time of RTC.
5. D0 designated by S is read by TRD instruction and the comparison is started by TZCP instruction. If **S₁**, **S₂**, and **S** exceed their ranges, the program will regard this as an operation error and the instruction will not be executed, M1068 = On.
6. When **S < S₁** and **S < S₂**, D will be On. When **S > S₁** and **S > S₂**, D + 2 will be On. In other occasions, D + 1 will be On.

Example

When X10= On, TZCP instruction will be executed and one of M10 ~ M12 will be On.
When X10 = Off, TZCP instruction will not be executed and the status of M10 ~ M12 prior to X10 = Off will remain unchanged.




API		TADD		(S1)	(S2)	(D)	Time Addition					
162			P									
	Bit Devices			Word Devices								16-bit command (7 STEPs) TADD TADDP
	X	Y	M	K	H	KnX	KnY	KnM	T	C	D	
S₁									*	*	*	Flag Signal: M1020 Zero flag M1022 Carry flag
S₂									*	*	*	
D									*	*	*	
Operands: S₁ , S₂ , and D will occupy 3 consecutive devices. Please refer to the specifications of each model for the range of operands												

Explanation


1. **S₁**: Time summand **S₂**: Time addend **D**: Time sum
2. **S₁ + S₂ = D**. The hour, minute, and second of the RTC designated in **S₁** plus the hour, minute, and second designated in **S₂**. The result is stored in the hour, minute, and second of the register designated in **D**.
3. If **S₁** and **S₂** exceed their ranges, the program will regard this as an operation error and the instruction will not be executed, M1068 = On.
4. If the sum is larger than 24 hours, the carry flag M1022 will be On and the value in **D** will be the result of “sum minus 24 hours”.
5. If the sum equals 0 (00:00:00), the zero flag M1020 will be On.

Example

1. When X10= On, TADD instruction will be executed and the hour, minute and second in RTC designated in D0 ~ D2 will plus the hour, minute and second in RTC designated in D10 ~ D12. The sum is stored in the hour, minute and second of the register designated in D20 ~ D22.



2. If the sum is larger than 24 hours, M1022 will be On.



API					(S1) (S2) (S3) (S4)	PID control for the AC motor drive
141		FPID		P		


	Bit Devices			Word devices								16-bit command (9 STEPS)	
	X	Y	M	K	H	KnX	KnY	KnM	T	C	D	FPID	FPIDP
S₁				*	*						*		
S₂				*	*						*	<u>32-bit command</u>	
S₃				*	*						*	—	—
S₄				*	*						*		
Operands: None												Flag signal: None	

Explanation

- S₁**: PID Set Point Selection(0-4), **S₂**: Proportional gain P (0-100), **S₃**: Integral Time I (0-10000), **S₄**: Derivative control D (0-100)
- This command FPID can control the PID parameters of the AC motor drive directly, including Pr.08.00 PID set point selection, Pr.08.01 Proportional gain (P), Pr.08.02 Integral time (I) and Pr.08.03 Derivative control (D)

Example

- Assume that when M0=ON, **S₁** is set to 0 (PID function is disabled), **S₂**=0, **S₃**=1 (unit: 0.01 seconds) and **S₄**=1 (unit: 0.01 seconds).
- Assume that when M1=ON, **S₁** is set to 0 (PID function is disabled), **S₂**=1 (unit: 0.01), **S₃**=0 and **S₄**=0.
- Assume that when M2=ON, **S₁** is set to 1(frequency is inputted by digital keypad), **S₂**=1 (unit: 0.01), **S₃**=0 and **S₄**=0.
- D1027: frequency command after PID calculation.



API				(S1) (S2) (S3)	Operation control of the AC motor drive
142	FREQ	P			

	Bit Devices			Word devices								16-bit command (7 STEPS)	
	X	Y	M	K	H	KnX	KnY	KnM	T	C	D	FREQ	FREQP
S ₁				*	*								
S ₂				*	*								
S ₃				*	*								

Operands: None

32-bit command

Flag signal: M1028


Explanation

- S₁: frequency command, S₂: acceleration time, S₃: deceleration time
- This command can control frequency command, acceleration time and deceleration time of the AC motor drive. Special register control is shown as following:

- M1025: controls RUN (On)/STOP (Off) of the drive. (Run is valid when Servo is On (M1040 On).)
- M1026: Operation directions FWD (On)/REV (Off) of the drive.
- M1040: controls Servo On (On)/ Servo Off (Off).
- M1042: enable quick stop(ON)/ disable quick stop(Off)
- M1044: enable Stop (On)/ disable stop(Off)
- M1052: frequency locked (On)/ disable frequency locked(Off)

Example

- M1025: controls RUN (On)/STOP (Off) of the drive. M1026: operation direction FWD (On)/REV (Off) of the drive. M1015: frequency attained.
- When M10=ON, setting frequency command of the AC motor drive to K300(3.00Hz) and acceleration/deceleration time is 0.
- When M11=ON, setting frequency command of the AC motor drive to K3000(30.00Hz), acceleration time is 50 and deceleration time is 60.



API	CANRX	P	(S1)	(S2)	(S3)	(D)	Read CANopen slave data			
261										

	Bit Devices			Word devices							16-bit command (7 STEPS)		
	X	Y	M	K	H	KnX	KnY	KnM	T	C	D	FREQ	FREQP
S ₁				*	*							32-bit command	
S ₂				*	*							— — — —	
S ₃				*	*								
D									*	*	*	Flag signal: M1028	


Operand: none

Explanation

1. **S₁**: Slave station number, **S₂**: main index, **S₃**: sub-index + bit length, **D**: save address
2. Command CANRX can read the corresponding slave. Index. When executing this command, it will send SDO message to the slave. At this time, M1066 and M1067 are 0 but when reading is complete M1066 will set to 1. If the slave replied an accurate response, the value will be written to the designated register and M1067 is now set to 1. However, if the slave replied an inaccurate response, this error message will be recorded in D1076~D1079.

Example

M1002: touch once to activate PLC and change K4M400=K1. After the change, different message will be displayed when M1066 is set to 1.



API	CANTX	P	(S1) (S2) (S3) (S4)	Write CANopen slave data
264				

	Bit Devices			Word devices										
	X	Y	M	K	H	KnX	KnY	KnM	T	C	D			
S₁				*	*							16-bit command (7 STEPS) FREQ FREQP		
S₂				*	*				*	*	*	32-bit command — — — —		
S₃				*	*									
S₄				*	*							Flag signal: M1028		
Operands: None														

- Explanation
- S₁**: slave station number, **S₂**: the address to write, **S₃**: main index, **S₄**: sub-index+ bit length.
 - Command CANTX can read the corresponding index of the slave. When executing this command, it will send SDO message to the slave. At this time, M1066 and M1067 are 0 but when reading is complete M1066 will set to 1. If the slave replied an accurate response, the value will be written to the designated register and M1067 is now set to 1. However, if the slave replied an inaccurate response, this error message will be recorded in D1076~D1079.

API 265	CANFLS	P	(D)	Update the mapping special D of CANopen
------------	---------------	----------	-----	---

	Bit Devices			Word devices							16-bit command (7 STEPS)		
	X	Y	M	K	H	KnX	KnY	KnM	T	C	D	FREQ	FREQP
D				*	*								
Operands: None												32-bit command	
												— — — —	
												Flag signal: M1028	

Explanation

1. **D**: the special D for update.
2. CANFLS can update the Special D command. When it executes in read only mode, it sends equivalent message as CANRX to the slave and saves the slave response to this particular Special D. When it executes in read/write mode, it sends equivalent message as CANTX to the slave and saves this special D value to the corresponding slave.
3. M1066 and M1067 are both 0. When reading is complete, M1066 will be 1 and this value will write to the designated register if the slave replies an accurate response. When slave replies a fault response then M1067 will be 0 and this error message will be recorded to D1076~D1079.

17.6 Error Code and Troubleshooting

Fault	ID	Fault Descript	Corrective Action
PLod	50	Data write error	Check if there is error in the program and download the program again.
PLSv	51	Data write error when executing	Re-apply the power and download the program again.
PLdA	52	Program upload error	Upload again. If error occurs continuously, please return to the factory.
PLFn	53	Command error when download program	Check if there is error in the program and download the program again.
PLor	54	Program capacity exceeds memory capacity	Re-apply the power and download the program again.
PLFF	55	Command error when executing	Check if there is error in the program and download the program again.
PLSn	56	Check sum error	Check if there is error in the program and download the program again.
PLEd	57	There is no "END" command in the program	Check if there is error in the program and download the program again.
PLCr	58	The command MC is continuous used more than 9 times	Check if there is error in the program and download the program again.
PLdF	59	Download program error	Check if there is error in the program and download the program again.
PLSF	60	PLC scan time over-time	Check if the program code is inaccurately written and download the program again.

17.7 CANopen Master Application

Simple control of multiple-axes for certain application can be done by CP2000 if the device supports CANopen protocol. One of the CP2000 could acts as Master to perform simple synchronous control, e.g. position, speed, zero return, and torque control. The setup can be done in 7 steps:

Step 1: Activate CANopen Master

1. Set Pr.09-45 to 1. (To activate Master function, turn off the power after setting and reboot. The digital keypad KPC-CC01 status will display “CAN Master”.)
2. Set Pr.00-02 to 6 for PLC reset. (Note: This action will erase the program and PLC register and will be set to factory setting.)
3. Turn off the power and reboot.
4. Set PLC control to **“PLC Stop mode”** by digital keypad KPC-CC01. (If the digital keypad is KPC-CE01 series, set PLC control to “PLC 2”. If the drive just came out of the factory, since PLC program is not yet installed, the digital keypad will show PLFF warning code.)

Step 2: Configuration of the Special D in Master


Each slave occupies 100 of Special D space and is numbered 1 to 8. There are in total of 8 stations. Please refer to 4-3 Special Register in this chapter for Special D register definition.

Slave No.	Slave No.	Register	Description
Slave No. 1	Slave No. 1	D2000	Station number
		D2001	Factory code(L)
		~	~
		D2099	The mapping address 4(H) of receiving station 4
Slave No. 2	Slave No. 2	D2100	Station number
		D2101	Factory code(L)
		~	~
		D2199	The mapping address 4 (H)of receiving station 4
Slave No. 3	Slave No. 3	D2200	Station number
		D2201	Factory code(L)
		~	~
		D2299	The mapping address 4 (H)of receiving station 4
Slave No. 8	Slave No. 8	D2700	Station number
		D2701	Factory code(L)
		~	~
		D2799	The mapping address 4(H) of receiving station 4


1. When communication cable 485 is connected, set PLC status to “stop” by WPL soft. (If PLC had already switched to “PLC Stop” mode then PLC status should be “stop” already.)

2. To control the slave address and corresponding station. For example, control 2 stations of the slave (max. 8 stations synchronous control), if the station number is 21 and 22, set D2000 and D2100 to 20 and 21 and then set D2200, D2300, D2400, D2500, D2600 and D2700 to 0. The setting can be done via PLC software editor WPL, follow the steps shown:

- Open WPL Editor > communication> Edit Register Memory(T C D)



- When the “Register” window appears, click “Transmit”.



- When transmission window appear, select “read” and input the range D2000~D2799 then press enter. The value in D2000~D2799 will be read. If communication failed, check the communication format (pre-defined PLC station is 2, 9600, 7N2, ASCII).
- Insert the slave station for control. Set D2000 and D2100 to 20 and 21 then set D2200, D2300, D2400, D2500, D2600 and D2700 to 0.
- Click”Transmit” again. When transmission window appears, input the range D2000~D2799 and enter. The value in D2000~D2799 will be write (If communication error occur and display failed, it means PLC is not in “stop” status. The value can only

be write in “stop” status, pleas switch PLC to “stop”.)

- Another method is by setting D1091. Set the corresponding bit of the excluding slave to 0 (slave station range from No.1~8). For example, if the user wants to exclude slave No. 2, 6 and 7, please set D1091 = 003B by following steps: WPL Editor > communication> Edit Register Memory(T C D)

3. Setup the communication setting. If following conditions apply to you then no additional setting needs to be done:

- If the only control in this application is the speed mode of AC motor drive.** (For other control such as position and torque control, D2000~D2799 should be set. Please refer to synchronous control on position, torque and zero return for more set up detail.

To perform synchronous control on position for the slave, please enable the corresponding function PDO 3. (P to P function is not yet supported by CP2000.)

- To activate PDO 3 TX (Master sending command to Slave), please set up bit 8~11 of the PLC address D2034+n*100. This special D register is defined as below:

	PDO4		PDO3		PDO2		PDO1	
	Torque		Position		Remote I/O		Speed	
Bit	15	14 ~ 12	11	10 ~ 8	7	6 ~ 4	3	2 ~ 0
Definition	En	Number	En	Number	En	Number	En	Number

The pre-defined setting of PDO 3 TX has corresponded to CANopen control word “Index 6040”and CANopen target position” Index 607A”. If position control is the only control in this application then simply set Special D register value to 0x0A00.

- To activate PDO 3 RX (Slave response with the status to Master), please set up bit 8~11 of the PLC address D2067+n*100. This special D register is defined as below:

	PDO4		PDO3		PDO2		PDO1	
	Torque		Position		Remote I/O		Speed	
Bit	15	14 ~ 12	11	10 ~ 8	7	6 ~ 4	3	2 ~ 0
Definition	En	Number	En	Number	En	Number	En	Number

The pre-defined setting of PDO 3 TX has corresponded to CANopen control word “Index 6041”and CANopen actual position” Index 6064”. If position control is the only control in this application then simply set Special D register value to 0x0A00.

In same theory, to perform torque control, please enable the mapping function PDO4.

- The speed for 1 corresponding cycle is 8ms. (When shorten the cycle time to < 8ms, make sure the time is enough for the data to be transmitted.

User should calculate the corresponding PDO quantity before setting the cycle. The PDO quantity should not be greater than the N. The quantity can be calculated by the following formula.

$$N = (1 \text{ cycle (ms)} * \text{rate (kbs)}) / 250$$

Example: 1 cycle is 2ms, speed= 1000k, max PDO value is $2*1000/250 = 8$. If user wants to set the cycle time to 2ms, turns off 4 of the C type AC motor drive slave stations must be turned off (since the pre-defined setting is 8 slaves, half of the slave station would be 4). The slave station can be turned off by setting the $D2000+n*100$ of the unused slaves to 0.

☑ **Number of control station ≤ 8 .**

Controlling 8 slave stations at once can only be done by asynchronous control where to Read/Write the slave is done by CANRX and CANTX command. This is similar to the Read/Write action of Modbus protocol.

☑ **The slave complies with DS402 standard.**

☑ **Does not control Slave IO terminal.**

☑ If above conditions do not apply, please set up the slave corresponding addresses manually by open WPL editor > communication> Edit Register Memory (**T C D**).

Step 3: Set up Master station number and communication speed.

- ☑ Set up the station number for the Master (the default setting of Pr.09-46=100). Do not to set the same station number as the Slave.
- ☑ Set up CANopen communication parameter Pr.09-37. It does not matter if the drive is defined as a Master or a Slave, communication speed is set by Pr.09-37 in both case.

Step 4: Coding

Real-time corresponding action: the data can be Read/Write directly to the corresponding special "D" register.

Non Real-time corresponding action:

Read: Reading is made by CANRX command. When reading process is complete, M1066=1. If reading succeeded, M1067 =1; if reading failed, M1067= 0.

Write: Writing is made by CANTX command. When writing process is complete, M1066 =1. If writing succeeded, M1067=1; if reading failed, M1067 =0.

Update: Updating the data is made by CANFLS command. (If special D register is defined as RW type, Master will write the value into the slave. If special D register is defined as RO type, then the data in the Slave will be read and write into the Master.) When updating process is complete, M1066 will be 1. If updating succeeded, M1067=1; if updating failed, M1067=0.

 **NOTE**

When executing CANRX, CANTX and CANFLS commands, the device will wait till M1066 is completed before the next CANRX, CANT or CANFLS begins. When the commands completed, download the program to the drive. (Note: The factory setting of PLC communication protocol is ASCII 7N2 9600 and station number is 2. Please change WPL Editor setting at Setting> Communication Setting)

Step 5: Setting the Slave station number, communication speed, operation source and command source

CANopen communication is supported by Delta CP2000 series and EC series AC motor drive.

The corresponding slave and CANopen speed are shown as below:

	Corresponding Parameter of Drive		Value	Definition
	CP2000	E-C		
Slave address	09-36	09-20	0	Disable CANopen Hardware Interface
			1~127	CANopen communication address
CANopen speed	09-37	09-21	0	1M
			1	500K
			2	250K
			3	125K
			4	100K
			5	50K
Source of operation command	00-21		3	
		02-01	5	
Source of frequency command	00-20		6	
		02-00	5	
Torque command	11-34		3	


The only servo motor and drive that supports CANopen communication interface is A2 series.

The corresponding slave station number and communication speed are shown as below:

	Corresponding Parameter of Drive		Value	Definition
	A2			
Slave address	03-00		1~127	CANopen communication address
CANopen speed	bit8~11 of Pr.03-01 XRXX		R= 0	125K
			R= 1	250K
			R= 2	500K
			R= 3	750K
			R= 4	1M
Control/Command Source	01-01		B	

Step 6: Hardware connection

The terminating resistor must be installed at the two farthest ends as shown in the figure below:



Step 7: Activate PLC Control Function

Download the program after coding is complete and switch PLC mode to Run status. Then reboots the power for Slave and Master. Please refer to CANMaster Test 1 vs. 2 driver.dvp.

➤ Example:

CP2000 AC motor drive (1 master vs. 2 slave control)

Step 1: Activate CANopen Master

- ☑ Set Pr.09-45 to 1. (To activate Master function, turn off the power after setting and reboot. The digital keypad KPC-CC01 status will display "CAN Master".)
- ☑ Set Pr.00-02 to 6 for PLC reset. (Note: This action will erase the program and PLC register and will be set to factory setting.)
- ☑ Turn off the power and reboot.
- ☑ Set PLC control to "PLC Stop mode" by digital keypad KPC-CC01. (If the digital keypad is KPC-CE01 series, set PLC control to "PLC 2". If the drive just came out of the factory, since PLC program is not yet installed, the digital keypad will show PLFF warning code.)

Step 2: Configuration of the Special D in Master

- ☑ Open WPL editor
- ☑ Set PLC mode to PLC Stop (PLC2) via the keypad
- ☑ WPL editor read D1070~D1099 and D2000~D2799
- ☑ Set D2000=10 and D2100=11
- ☑ Set D2100, 2200, 2300 2400 2500 2600 2700=0
- ☑ Download D2000~D2799 setting

Step 3: Set up Master station number and communication speed

- ☑ Set up the station number for the Master (the default setting of Pr.09-46=100). Do not to set the same station number as the Slave.
- ☑ Set up CANOpen communication speed to 1 M (parameter Pr.09-37= 0). It does not matter if the drive is defined as a Master or a Slave, communication speed is set by Pr.09-37 in both case.

Step 4: Coding

Real-time corresponding action: the data can be Read/Write directly to the corresponding special “D” register.

Non Real-time corresponding action:

Read: Reading is made by CANRX command. When reading process is complete, M1066=1. If reading succeeded, M1067 =1; if reading failed, M1067= 0.

Write: Writing is made by CANTX command. When writing process is complete, M1066 =1. If writing succeeded, M1067=1; if reading failed, M1067 =0.

Update: Updating the data is made by CANFLS command. (If special D register is defined as RW type, Master will write the value into the slave. If special D register is defined as RO type, then the data in the Slave will be read and write into the Master.) When updating process is complete, M1066 will be 1. If updating succeeded, M1067=1; if updating failed, M1067=0.

NOTE

When executing CANRX, CANTX and CANFLS commands, the device will wait till M1066 is completed before the next CANRX, CANT or CANFLS begins. When the commands completed, download the program to the drive. (Note: The factory setting of PLC communication protocol is ASCII 7N2 9600 and station number is 2. Please change WPL setting at setting> communication setting)


Step 5: Set Slave station number and communication speed.

Slave No.1: Pr.09-37 = 0(speed 1M), Pr.09-36=10 (station number 10)

Slave No.2: Pr. 09-37 = 0(speed 1M), Pr.09-36=10 (station number 11)

Step 6: Hardware connection

The terminating resistor must be installed at the two farthest ends as shown in the figure below:



Step 7: Activate PLC Control Function

Download the program after coding is complete and switch PLC mode to Run status. Then reboots the power for Slave and Master. Please refer to CAN Master Test 1 vs. 2 driver.dvp.

18 Introduction to BACnet

1. About BACnet:

BACnet is an ASHRAE communication protocol for **building automation and control networks**. (ASHRAE: **American Society of Heating, Refrigerating and Air-Conditioning Engineers, Inc.**). CP2000's BACnet is based on version 20004.

BACnet's regulations are related to several kind of physical layers' interfaces. The physical layers built inside CP200 are achieved via MS/TP interface.

The BACnet of CP2000 supports a device type called B-ASC. B-ASC supports five types of services such as DS-RP-B, DS-WP-B, DM-DDB-B, DM-DOB and DM-DCC-B.

2. Definition of BACnet's ICS:

CP2000-Object:

Property Type	Object Type supported		
	Device	Analog Value	Binary Value
	Supported	Supported	Supported
Object Identifier ;	V	V	V
Object Name	V	V	V
Object Type	V	V	V
System Status	V		
Vendor Name	V		
Vendor Identifier	V		
Model Name	V		
Firmware Revision	V		
Appl Software revision	V		
Protocol Version	V		
Protocol Revision	V		
Services Supported	V		
Object Types supported	V		
Object List	V		
Max APDU Length	V		
Segmentation Support	V		

APDU Timeout	V		
Number ADPU Retries	V		
Device Address Binding	V		
Database Revision	V		
Preset Value		V	V
Status Flags		V	V
Event State		V	V
Out-of-Service		V	V
Units		V	
Priority Array		V*	V*
Relinquish Default		V*	V*
Active Text			V
Inactive Text			V
* Only with commendable values			

Analog Values

Control of Analog Values

Address	Pro- perty	Unit	bit	limit	Value	Note	
						Speed mode	Torque mode
AV0	C	NO_UNITS	1~0		00	0 : No function	0 : No function
					01	1 : Stop	1 : Stop
					10	2 : Enable	2 : Enable
					11	3 : No function	3 : No function
			3~2			No function	No function
			5~4		00	No function	
					01	Fwd command	
					10	Reverse command	
11	Direction changing command						
15~6			Reserved				
AV1	C	HERTZ				Frequency Command	
AV2	C	NO_UNITS	0		0	E.F. ON	
					1	E.F. OFF	
			1		Pulse 1	Reset command	
			2		0	External interrupt (B.B) OFF	
					1	External interrupt (B.B) ON	
15~3			Reserved				

BACnet		Unit	bit	Limit	Value	Note	
Address	Property					Speed mode	Torque mode
AV 30	C	NO_UNITS	0	4	0	fcmd =0	
					1	fcmd = Fset(Fpid)	
			1	4	0	Fwd command	
					1	Reverse command	
			2			No function	No function
			3	3	0	Continue running to target speed	Free(Continue running to target torque)
					1	Follow deceleration setting, stop temporary	Torque stops at current speed
			4	4	0	Continue running to target speed	
					1	Frequency stops at current frequency	
			5	4		No function	No function
			6	2	0	None	None
					1	Quick Stop	Quick Stop
			7	1	0	Servo OFF	Servo OFF
1	Servo ON	Servo ON					
14~8			No function	No function			
15	4	Pulse 1	Clear error code	Clear error code			
AV 31	C	NO_UNITS					
AV 32	C	HERTZ				Speed command (unsigned numbers)	Profile velocity(unsigned numbers)
AV 33	C	NO_UNITS					
AV 34	C	NO_UNITS					
AV 35	C	NO_UNITS					
AV 36	C	NO_UNITS					Torque command (signed numbers)
AV 37	C	NO_UNITS					Speed limit

*Property C means Commandable which has properties such as priority array and relinquish default.

Display of Analog Values

Address	Property	Unit	bit	Value	Note
AV100	R	NO_UNITS			Error code
AV101	R	NO_UNITS	1~0	00	Drive stops.
				01	Drive decelerates
				10	Drive standby
				11	Drive in operation
			2	0	Jog command OFF
				1	Jog command ON
			4~3	00	Drive forward
				01	From reverse to forward
				10	From forward to reverse
				11	Drive reverse
			7 ~ 5		Reserved
			8	1	Source of main frequency communication interface
			9	1	Input main frequency from analog/external terminal signal
10	1	Operation command from communication interface			
15 ~ 11		Reserved			
AV102	R	HERTZ			Frequency command (F)
AV103	R	HERTZ			Output frequency (H)
AV104	R	AMPERE			Output current (AXXX.X)
AV105	R	VOLTS			DC-BUS voltage (UXXX.X)
AV106	R	VOLTS			Output voltage (EXXX.X)
AV107	R	HERTZ			Current running speed of the multi-speed command
AV108	R	NO_UNITS			
AV109	R	NO_UNITS			Attribute value
AV110	R	DEGREE S_ANGU LAR			Power factor angle
AV111	R	NO_UNITS			Output torque
AV112	R	NO_UNITS			Output rotational speed (rpm)
AV113	R	NO_UNITS			Reserved
AV114	R	NO_UNITS			Reserved
AV115	R	KILOWA TT			Output power

AV116	R	NO_UNITS			User defined value
AV117	R	NO_UNITS			User defined page
AV118~119	R	NO_UNITS			Reserved

Address	Property	Unit	bit	Value	Note	
AV130	R	NO_UNITS	0	0	Frequency command not reached	Torque command not reached
				1	Frequency command reached	Torque command reached
			1	0	Forward	Forward
				1	Reverse	Reverse
			2	0	No warning	No warning
				1	Warning	Warning
			3	0	No error	No error
				1	Error	Error
			5	0	None	None
				1	On JOG	On JOG
			6	0	None	None
				1	On Quick Stop	On Quick Stop
7	0	PWM OFF	PWM OFF			
	1	PWM ON	PWM ON			
15~8	—	—	—			
AV131	R	NO_UNITS		—	—	
AV132	R	HERTZ			Actual output frequency	
AV133	R	NO_UNITS		—	—	
AV134	R	NO_UNITS				
AV135	R	NO_UNITS			Reserved	
AV136	R	NO_UNITS			Actual torque	
AV137~139	R	NO_UNITS			Reserved	
AV145	R	NO_UNITS			ID code of the AC motor drive	

BACnet		Modbus	Unit	Value	Note
Addresses	Properties	Addresses			
AV150	R	2200H	AMPERES		Display output from drive to motors
AV151	R	2201H	NO_UNITS		Display attribute value at TRG terminal
AV152	R	2202H	HERTZ		Display actual output frequency
AV153	R	2203H	VOLTS		Display the DC voltage value detected in the drive
AV154	R	2204H	VOLTS		Display output value of U,V,W of this drive
AV155	R	2205H	NO_UNITS		Display power factor angles of U,V,W
AV156	R	2206H	KILOWATTS		Display output power of U,V,W (kW)
AV157	R	2207H	REVOLUTIONS PER_MINUTE		Display estimated (r 00: fwd rotational speed ; - 00: reverse rotational speed)
AV158	R	2208H	NEWTON METER		Display estimated N-m (t 0.0: fwd torque ; - 0.0 : reverse torque)
AV159	R	2209H	NO_UNITS		
AV160	R	220AH	PERCENT		When PID function is enabled, display PID feedback value in %.
AV161	R	220BH	PERCENT		Display AVI1 analog input terminal signal, 0~10V and 0~100%
AV162	R	220CH	PERCENT		Display ACI analog input terminal signal, 4~20mA/0~10V and 0~100%
AV163	R	220DH	PERCENT		Display AVI2 analog input terminal signal, 0V~10V and 0~100%
AV164	R	220EH	DEGREES CELSIUS		Display IGBT's temperature in °C
AV165	R	220FH	DEGREES CELSIUS		Display capacitor's temperature in °C
AV166	R	2210H	NO_UNITS		Digital input, ON/OFF status, see Pr02-10
AV167	R	2211H	NO_UNITS		Digital output ON/OFF status, see 02-15
AV168	R	2212H	NO_UNITS		Display current speed of the multi-speed
AV169	R	2213H	NO_UNITS		Corresponding CPU Pin status to digital input
AV170	R	2214H	NO_UNITS		Corresponding CPU Pin status to digital output
AV171	R	2215H	NO_UNITS		
AV172	R	2216H	NO_UNITS		
AV173	R	2217H	NO_UNITS		
AV174	R	2218H	NO_UNITS		
AV175	R	2219H	NO_UNITS		Display number of times of over load. (0.)
AV176	R	221AH	PERCENT		Display GFF's value in % (G.)
AV177	R	221BH	NO_UNITS		
AV178	R	221CH	NO_UNITS		Display value of D1043, the register of PLC (C)
AV179	R	221DH	NO_UNITS		
AV180	R	221EH	NO_UNITS		User's physical output

AV181	R	221FH	NO_UNITS		Output value of Pr00-05
-------	---	-------	----------	--	-------------------------

Analog Values' Parameter Setting


BACnet		Preset value	BACnet		Preset value	Note
Address	Pro- perty		Address	Pro- perty		
AV 200	W	NULL	AV 300	C	----	no-corresponding terms
AV 201	W	NULL	AV 301	C	----	no-corresponding terms
AV 202	W	NULL	AV 302	C	----	no-corresponding terms
AV 203	W	NULL	AV 303	C	----	no-corresponding terms
AV 204	W	NULL	AV 304	C	----	no-corresponding terms
AV 205	W	NULL	AV 305	C	----	no-corresponding terms
AV 206	W	NULL	AV 306	C	----	no-corresponding terms
AV 207	W	NULL	AV 307	C	----	no-corresponding terms
AV 208	W	NULL	AV 308	C	----	no-corresponding terms
AV 209	W	NULL	AV 309	C	----	no-corresponding terms
AV 210	W	NULL	AV 310	C	----	no-corresponding terms
AV 211	W	NULL	AV 311	C	----	no-corresponding terms
AV 212	W	NULL	AV 312	C	----	no-corresponding terms
AV 213	W	NULL	AV 313	C	----	no-corresponding terms
AV 214	W	NULL	AV 314	C	----	no-corresponding terms
AV 215	W	NULL	AV 315	C	----	no-corresponding terms
AV 216	W	NULL	AV 316	C	----	no-corresponding terms
AV 217	W	NULL	AV 317	C	----	no-corresponding terms
AV 218	W	NULL	AV 318	C	----	no-corresponding terms
AV 219	W	NULL	AV 319	C	----	no-corresponding terms

Binary Values :

**For Present Value Access Types, R = Read-only, W = Writable, C = Commandable.
Commandable values support priority arrays and relinquish defaults.**

3.Steps to set up BACnet in CP2000

1. Set Pr09-31 =1 so the COM1 protocol becomes BACnet.(Note that RJ45 and RS485 shares the same PIN, so when BACnet is enabled, Modbus, PLC upload/download functions, VFDSOft and VFD Explorer will be disabled.). When that is set, the COM1 Communication Protocol stays at 8N1 (See Pr.09-04 = 6).
2. Set Pr00-20 =1 , Source of the master frequency command = RS485 serial communication.
3. Set Pr00-21=2, RS485 serial communication.
4. Set PR09-50, BACnet's MS/TP station number 0~127
5. Set Pr09-51, BACnet baud rate, 9600, 19200 or 38400.
6. Set device instance, setting range 0~4194303. It is a combination of Pr09-52 and Pr09-53, for example, Pr09-53=78 and Pr09-52 =1234, then the device instance's value = 781234.
7. When you need to set up main station, use Pr09-55 to search for range of station number.
8. If you need to set up a password, use Pr09-56 to set it up. If set up is successful, keypad will display 8888.
9. Then connect a communication cable as shown in the diaram below.



10. At Pr09-30, choose a communication decoding method, 20XX or 60XX.

20XX decoding method: to control AV100 ~ AV102

60XX decoding method: to control AV150 to AV157

11. When the 10 points above are done, you now just need to control corresponding Analog Value.

4. Description of the Analog Value

BACnet		Modbus	bit	Limit	Value	Note	
Address	Property	Address				Speed mode	Torque mode
AV0	C	2000H	1~0		00	0 : No function	0 : No function
					01	1 : Stop	1 : Stop
					10	2 : Enable	2 : Enable
					11	3 : No function	3 : No function
			3~2			No function	No function
			5~4		00	No function	
					01	Fwd command	
					10	Reverse command	
					11	Direction changing command	
			15~6			Reserved	
AV1	C	2001H				Frequency Command	
AV2	C	2002H	0		0	E.F. ON	
					1	E.F. OFF	
			1		Pulse 1	Reset command	
			2		0	External interrupt (B.B) OFF	
					1	External interrupt (B.B) ON	
15~3			Reserved				

*Property C means Commandable which has properties such as priority array and relinquish default

BACnet		Modbus	bit	Limi	Value	Note	
Address	Property	Address				Speed mode	Torque mode
AV30	C	6000h	0	4	0	fcmd =0	
					1	fcmd = Fset(Fpid)	
			1	4	0	Fwd command	
					1	Reverse command	
			2			No function	No function
			3	3	0	Continue running to target speed	Continue running to target speed
					1	Follow deceleration setting, stop temporary	Follow deceleration setting, stop temporary
			4	4	0	Continue running to target speed	
					1	Continue running to target	

						speed	
			5	4		No function	No function
			6	2	0	None	None
					1	Quick Stop	Quick Stop
			7	1	0	Servo OFF	Servo OFF
					1	Servo ON	Servo ON
			14~8			No function	No function
			15	4	Pulse 1	Clear error code	Clear error code
AV31	C	6001h					
AV32	C	6002h				Speed command (unsigned numbers)	Profile velocity((unsigned numbers))
AV33	C	6003h					
AV34	C	6004h					
AV35	C	6005h					
AV36	C	6006h					Torque command (signed numbers)
AV37	C	6007h					Speed limit

*Property C means Commandable which has properties such as priority array and relinquish default

Display of the Analog Value

BACnet		Modbus	bit	Value	Note
Address	Property	Address			
AV100	R	2100H			Error code
AV101	R	2101H	1~0	00	Drive stops.
				01	Drive decelerates
				10	Drive standby
				11	Drive in operation
			2	0	Jog command OFF
				1	Jog command ON
			4~3	00	Drive forward
				01	From reverse to forward
				10	From forward to reverse
				11	Drive reverse
			7~5		Reserved
8	1	Source of main frequency communication interface			
9	1	Input main frequency from analog/external terminal signal			
10	1	Operation command from communication interface			
15~11		Reserved			
AV102	R	2102H			Frequency command (F)
AV103	R	2103H			Output frequency (H)
AV104	R	2104H			Output current (AXXX.X)

AV105	R	2105H			DC-BUS voltage (UXXX.X)
AV106	R	2106H			Output voltage (EXXX.X)
AV107	R	2107H			Current running speed of the multi-speed command
AV108	R	2108H			
AV109	R	2109H			Attribute value
AV110	R	210AH			Power factor angle
AV111	R	210BH			Output torque
AV112	R	210CH			Output rotational speed (rpm)
AV113	R	210DH			Reserved
AV114	R	210EH			Reserved
AV115	R	210FH			Output power
AV116	R	2116H			User defined value
AV117	R	211BH			User defined page
AV118~AV119	R	----			Reserved

BACnet		Modbus	bit	Value	Note	
Address	Property	Address			Speed	Torque
AV130	R	6100h	0	0	Frequency command not reached	Torque command not reached
				1	Frequency command reached	Torque command reached
			1	0	Forward	Forward
				1	Reverse	Reverse
			2	0	No warning	No warning
				1	Warning	Warning
			3	0	No error	No error
				1	Error	Error
			5	0	None	None
				1	On JOG	On JOG
			6	0	None	None
				1	On Quick Stop	On Quick Stop
7	0	PWM OFF	PWM OFF			
		PWM ON	PWM ON			
15~8		—	—			
AV131	R	6101h		—	—	
AV132	R	6102h		Actual output frequency	Actual output frequency	
AV133	R	6103h		—	—	
AV134	R	6105h/6104h				
AV135	R	----			Reserved	

AV136	R	6106h		Actual torque	Actual torque
AV137~139	R	----		Reserved	
Av145	R	0000h		ID code of the AC motor drive	

BACnet		Modbus	Value	Note
Address	Property	Address		
AV150	R	2200H		Display output from drive to motors
AV151	R	2201H		Display attribute value at TRG terminal
AV152	R	2202H		Display actual output frequency
AV153	R	2203H		Display the DC voltage value detected in the drive
AV154	R	2204H		Display output value of U,V,W of this drive
AV155	R	2205H		Display power factor angles of U,V,W
AV156	R	2206H		Display output power of U,V,W (kW)
AV157	R	2207H		Display estimated (r 00: fwd rotational speed ; - 00: reverse rotational speed)
AV158	R	2208H		Display estimated N-m (t 0.0: fwd torque ; - 0.0 : reverse torque)
AV159	R	2209H		
AV160	R	220AH		When PID function is enabled, display PID feedback value in %.
AV161	R	220BH		Display AVI1 analog input terminal signal, 0~10V and 0~100%
AV162	R	220CH		Display ACI analog input terminal signal, 4~20mA/0~10V and 0~100%
AV163	R	220DH		Display AVI2 analog input terminal signal, 0V~10V and 0~100%
AV164	R	220EH		Display IGBT's temperature in °C
AV165	R	220FH		Display capacitor's temperature in °C
AV166	R	2210H		Digital input, ON/OFF status, see Pr02-10
AV167	R	2211H		Digital output ON/OFF status, see 02-15
AV168	R	2212H		Display current speed of the multi-speed
AV169	R	2213H		Corresponding CPU Pin status to digital input
AV170	R	2214H		Corresponding CPU Pin status to digital output
AV171	R	2215H		
AV172	R	2216H		
AV173	R	2217H		
AV174	R	2218H		
AV175	R	2219H		Display number of times of over load. (0.)
AV176	R	221AH		Display GFF's value in % (G.)
AV177	R	221BH		
AV178	R	221CH		Display value of D1043, the register of PLC (C)
AV179	R	221DH		


AV180	R	221EH		User's physical output
AV181	R	221FH		Output value of Pr00-05

Parameter Setting of Analog Value


BACnet		Preset	BACnet		Preset	Note
Address	Property		Address	Property		
AV 200	W	NULL	AV 220	C	----	no-corresponding terms
AV 201	W	NULL	AV 221	C	----	no-corresponding terms
AV 202	W	NULL	AV 222	C	----	no-corresponding terms
AV 203	W	NULL	AV 223	C	----	no-corresponding terms
AV 204	W	NULL	AV 224	C	----	no-corresponding terms
AV 205	W	NULL	AV 225	C	----	no-corresponding terms
AV 206	W	NULL	AV 226	C	----	no-corresponding terms
AV 207	W	NULL	AV 227	C	----	no-corresponding terms
AV 208	W	NULL	AV 228	C	----	no-corresponding terms
AV 209	W	NULL	AV 229	C	----	no-corresponding terms

19. PT100 Thermistor Operation Guide

1. At Group 3 Analog Input, select Pr03-00=11 or Pr03-02 = 11 for PT100 input. You also can select Pr03-01=11, but you need to set Pr03-29=1 and switch ACI selection (SW4) as 0~10V on the control terminal.
2. At Pr03-23, AFM2, select 23 for AFM2 Constant Current Output and switch AFM2 selection (SW2) as 0~20mA on the control terminal. Set AFM2 constant current output as 9mA (Pr03-33=45%)
3. The wiring diagram of PT100 is as below.



4. There are two kinds of action level at PT100. The diagram of PT100 protecting action is shown as below.



5. When Pr06-58 = 0Hz, PT100 function is disabled.

When connecting RTD signal (PT100) to VFD-CP2000, the parameter setting of the auto-frequency decreasing function while the temperature is too high is shown as below

When the temperature of RTD is higher than 135°C (275°F), VFD will decrease automatically the frequency to selected frequency. It stays at that selected frequency until the temperature goes lower than 135°C (275°F). If the temperature is higher than 150°C (302°F), VFD will decrease the output and decelerating to stop. The error message (OH3) will also be recorded.

The PT100 detection level of Pr06-56 is set at 1.37.

